



CAPABILITIES AND
FIXED PRICES CATALOGUE



Capabilities and Fixed Prices
Catalogue 2024 for
PW4000
valid until December 31, 2024

© SR Technics. All rights reserved

7X-XX-XX	PW4000	664337	4	28	5 50A294 50A314 50A737 50D144 50D294 50D304 50D307 50D314 50D626-01 50D779 50D797 50D838-01 50D849 50D872-01 50D893 50D928-01 50D958-01 50G104 50G653 50G858L10 50G858CL6 50G859 50G895 50G896 50G923 50G937 50G960-01 50U042-01 50U732-01 50U763-01 51D967-01 51D968-01 51G093 51G290-01 51G325-01 51G977 51U687-01 52D373-01 52D374-01 52D572-01 52D584-01 52G196 52G220-01 52T796 52T882-01 530254 53D530 53D876-01 53T356-01 53T518-01 53T520-01 53T523 53T525-01 53T527-01 53T528-01 53T531-01 53T537-01 53T538-01 53T698-01 53T699-01 53T751-01 54T781-01 54T866-01 54T887-01 55T346 55T837-01 55T838-01 55T840-01 56T663-01 57T318-01 57T320-01 57T473-01 57T889-01 57T950-01 57T975-01 58T258-01 58T516-01 58T517-01 58T520-01 58T521-01 58T612-01 58T674-01 59T046-01 59T111-01 59T459-01 614995	PW4000 INSPECTION OF VARIOUS PARTS ACC.	Package A	CLN/INSP	CLEANING & INSPECTION	-	
7X-XX-XX	PW4000	664337	4	28	5 50A294 50A314 50A737 50D144 50D294 50D304 50D307 50D314 50D626-01 50D779 50D797 50D838-01 50D849 50D872-01 50D893 50D928-01 50D958-01 50G104 50G653 50G858L10 50G858CL6 50G859 50G895 50G896 50G923 50G937 50G960-01 50U042-01 50U732-01 50U763-01 51D967-01 51D968-01 51G093 51G290-01 51G325-01 51G977 51U687-01 52D373-01 52D374-01 52D572-01 52D584-01 52G196 52G220-01 52T796 52T882-01 530254 53D530 53D876-01 53T356-01 53T518-01 53T520-01 53T523 53T525-01 53T527-01 53T528-01 53T531-01 53T537-01 53T538-01 53T698-01 53T699-01 53T751-01 54T781-01 54T866-01 54T887-01 55T346 55T837-01 55T838-01 55T840-01 56T663-01 57T318-01 57T320-01 57T473-01 57T889-01 57T950-01 57T975-01 58T258-01 58T516-01 58T517-01 58T520-01 58T521-01 58T612-01 58T674-01 59T046-01 59T111-01 59T459-01 614995	PW4000 INSPECTION OF VARIOUS PARTS ACC.	Package B				230
7X-XX-XX	PW4000	664337	4	28	5 50A294 50A314 50A737 50D144 50D294 50D304 50D307 50D314 50D626-01 50D779 50D797 50D838-01 50D849 50D872-01 50D893 50D928-01 50D958-01 50G104 50G653 50G858L10 50G858CL6 50G859 50G895 50G896 50G923 50G937 50G960-01 50U042-01 50U732-01 50U763-01 51D967-01 51D968-01 51G093 51G290-01 51G325-01 51G977 51U687-01 52D373-01 52D374-01 52D572-01 52D584-01 52G196 52G220-01 52T796 52T882-01 530254 53D530 53D876-01 53T356-01 53T518-01 53T520-01 53T523 53T525-01 53T527-01 53T528-01 53T531-01 53T537-01 53T538-01 53T698-01 53T699-01 53T751-01 54T781-01 54T866-01 54T887-01 55T346 55T837-01 55T838-01 55T840-01 56T663-01 57T318-01 57T320-01 57T473-01 57T889-01 57T950-01 57T975-01 58T258-01 58T516-01 58T517-01 58T520-01 58T521-01 58T612-01 58T674-01 59T046-01 59T111-01 59T459-01 614995	PW4000 INSPECTION OF VARIOUS PARTS ACC.	Package B	-	REPLACE NUTPLATES (SPM)	-	
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package A				360
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package A	CLN/INSP	CLEANING & INSPECTION	-	
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package B				135
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package B	-	REPLACE INSERTS (SPM)	-	
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package C				155
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package C	-	REPLACE NUTPLATES (SPM)	-	
7X-XX-XX	PW4000	664520	3	28	50G958 50R349-01 50R384-01 50U225-01 50U643-01 51R079-01 51R080 51U177-01 51U628-01 51U631-01 51U802-01 52G263 52T079 52T456-01 52T703 52U653-01 52U868-01 53T488-01 53T612-01 53T866-01 53T906-01 53T907-01 53T908-01 53U013-01 54T152-01 55T235-01 55T792-01 58T237 58T255-01 58T555-01 58T693 58T902-01 59T198-01 59T241-01 59T482-01 59T504-01 59T777-01 59T779-01 59T840-01 59T941 59T942-01 59T951-01 70R153 70R523 70R631	PW4 VARIOUS GEARBOX BRACKETS GENERAL SP	Package D	-	REPLACE SPRING TENSION CLIP	-	
7X-XX-XX	PW4000	668484	3	28	51T197 53T754	PW4000 INSPECTION OF PARTS IN MODUL INSP	Package A				90
7X-XX-XX	PW4000	668484	3	28	51T197 53T754	PW4000 INSPECTION OF PARTS IN MODUL INSP	Package A	CLN/INSP	CLEANING & INSPECTION	-	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AA				910
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AA	015	INSTALL INSERTS IN ANGLE GEARBOX MOUNT PAD	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AB				2450
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AB	016	REPLACE NO.1 BRG. SUPPORT FLANGE HELICAL COIL INSERTS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AC				2645
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AC	017	REPLACE REAR INNER FLANGE ANGE HELICAL COIL INSERTS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AD				920
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AD	018	REPLACE INNER FAN EXIT CASE MOUNTING FLANGE HELICAL COIL INSERTS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AE				910
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AE	019	REPAIR THREADED BOSS HOLES	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AF				1240
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AF	020	BLEND THE SURFACE DAMAGE	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AG				510
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AG	021	REPLACE NUT PLATE ON FRONT FAN EXIT CASE BRACKET ASSEMBLY B	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AH				1245
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AH	022	REPLACE A FAIRING WITH NO RIVETS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AI				2645
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AI	023	REPLACE 4TH STATOR MOUNTING FLANGE HELICAL COIL INSERTS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AJ				945
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AJ	024	REPLACE HELICAL COIL NSERTS AT 2.4. AND 8 O'CLOCK POSITIONS	72-34-01	
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AK				445
7X-XX-XX	PW4000	672311	6	21	33_34_MOD_INSP_94	FAN AND IINTERMEDIATE CASE ASSY 94*	Package AK	026	REPLACE THE FRONT FAN EXIT CASE BRACKET ASSEMBLIES	72-34-01	

71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB02	PW4NAC 71-58	REPLACEMENT OF STOP BOLTS	IN CONJUNCTION WITH PACKAGE HEAVY OR OVERHAUL	
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB03				105
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB03	PW4NAC 71-77	REPLACEMENT OF MAIN BEAM AND BEARING	IN CONJUNCTION WITH PACKAGE HEAVY OR OVERHAUL	
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB04				110
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB04	PW4MD11 71-36	MODIFICATION OF RETAINER ASSEMBLY	IN CONJUNCTION WITH PACKAGE LIGHT, MEDIUM, HEAVY OR OVERHAUL	
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB05				105
71-20-04	PW4000	138122	20	21	221-4049-503 221-4049-507 221-4086-15 221-4086-17 221-4086-19 221-4086-25 221-4086-507 221-4086-509 221-4086-515 221-4086-517 221-4086-523	FWD ENGINE MOUNT - ASSEMBLY - 94"	Package SB05	PW4NAC 71-163	REPLACE ATTACHMENT HARDWARE WITH SERIALIZED PARTS	-	
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package A				1085
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package F				340
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package F	005	NICKS, GOUGES AND SCRATCHES REPAIR	-	
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package I				920
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package I	008	APPLICATION OF CORROSION RESISTANT FINISHES TO SUPPORT	-	
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package J				1570
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package J	009	BUSHING REPLACEMENT	-	
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package J	010	BUSHING REPLACEMENT	FOR PN 221-4047-507	1570
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package SB00				120
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package SB00	PW4NAC 71-74	INSPECTION AND ELECTRO ETCHING	-	120
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package SB01				1570
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package SB01	PW4MD11 71-104	BERYLLIUM COPPER BUSHING INSTALLATION	MD11	1570
71-20-04	PW4000	138162	25	21	221-4047-503 221-4047-505 221-4047-507	FWD ENGINE MOUNT - MOUNT SUPPORT - 94"	Package SB01	PW4NAC 71-152	BERYLLIUM COPPER BUSHING INSTALLATION	AIRBUS	
71-20-04	PW4000	138164	4	21	221-4004-503	PW4 ENG FWD MOUNT CROSSBEAM	Package A				345
71-20-04	PW4000	138164	4	21	221-4004-503	PW4 ENG FWD MOUNT CROSSBEAM	Package A	CLN/INSP	CLEANING & INSPECTION	-	
71-20-04	PW4000	138164	4	21	221-4004-503	PW4 ENG FWD MOUNT CROSSBEAM	Package D				1945
71-20-04	PW4000	138164	4	21	221-4004-503	PW4 ENG FWD MOUNT CROSSBEAM	Package D	003	BUSHING REPLACEMENT	-	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package A				1030
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package C				1610
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package C	002	BEARING REPLACEMENT	ITEM 320	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package D				1610
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package D	002	BEARING REPLACEMENT	ITEM 330	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package E				1225
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package E	003	BLEND REPAIR FOR MINOR DAMAGES	-	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package SB01				925
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package SB01	APW4MD11 A71-86	AFT ENGINE MOUNT LINK - INSP/REPL	AD 94-13-07	
71-20-05	PW4000	2730	22	21	221-0262-501 221-0262-503	AFT ENGINE MOUNT - LINK ASSY - 94"	Package SB01	APW4NAC 71-138	AFT ENGINE MOUNT LINK - INSP/REPL	-	925
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package A				1010
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1010
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package B				1860
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package B	001	BUSHING REPLACEMENT	-	1860
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package B	001	ORIGINAL BUSHING REPLACEMENT	-	
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package C				4115
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package C	001	INSTALLATION OF OVERSIZE BUSHING	-	
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package D				1015
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package D	001	WORK DISTANCE BUSHING	-	
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package E				905
71-20-05	PW4000	3463	21	21	221-0261-501 221-0261-503	AFT ENGINE MOUNT - BEAM ASSY - 94"	Package E	003	BLEND REPAIR	-	
71-20-05	PW4000	15167	4	21	221-0264-501 221-0264-503	PW4 AFT ENGINE MOUNT PIN ITEM 1-300	Package A				105
71-20-05	PW4000	15167	4	21	221-0264-501 221-0264-503	PW4 AFT ENGINE MOUNT PIN ITEM 1-300	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-20-05	PW4000	18887	4	21	80876-20-5 80876-20-6	AFT MOUNT MD-11 PIN & BOLTS	Package A				205
71-20-05	PW4000	18887	4	21	80876-20-5 80876-20-6	AFT MOUNT MD-11 PIN & BOLTS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-20-05	PW4000	129947	3	21	80168-1414 80805-1216 VM400B098	PW4 BARREL NUT, AFT MOUNT	Package A				150
71-20-05	PW4000	129947	3	21	80168-1414 80805-1216 VM400B098	PW4 BARREL NUT, AFT MOUNT	Package A	CLN/INSP	CLEANING & INSPECTION	-	

71-21-12	PW4000	139862	24	21	52U420 54T658 54T659 59T794	FWD ENGINE MOUNT - BEARING RETAINER, BUSHING AND HOUSING - 100"	Package B	001	BEARING HOUSING BUSHING REPLACEMENT REPAIR	-	
71-21-12	PW4000	139862	24	21	52U420 54T658 54T659 59T794	FWD ENGINE MOUNT - BEARING RETAINER, BUSHING AND HOUSING - 100"	Package C				695
71-21-12	PW4000	139862	24	21	52U420 54T658 54T659 59T794	FWD ENGINE MOUNT - BEARING RETAINER, BUSHING AND HOUSING - 100"	Package C	002	SURFACE DAMAGE BLEND REPAIR	-	
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package A				330
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package B				350
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package B	001	BLEND THE SURFACE DAMAGE	-	
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package C				3710
71-21-13	PW4000	139751	24	21	56T081 59T795	FWD ENGINE MOUNT - THRUST LINK BEAM ASSEMBLY - 100"	Package C	002	OVERSIZE BUSHING REPAIR	-	
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package A				335
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package B				2215
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package B	001	BEARING REPLACEMENT REPAIR	-	
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package C				345
71-21-14	PW4000	144727	24	21	56T082 59T796	FWD ENGINE MOUNT - THRUST LINK ASSEMBLY - 100"	Package C	002	SURFACE DAMAGE BLEND REPAIR	-	
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package A				400
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package B				1370
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package B	001	MOUNT SET SURFACE DAMAGE BLEND REPAIR	-	
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package C				525
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package C	002	MOUNT SET HALVES SURFACE DAMAGE BLEND REPAIR	-	
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package E				540
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package E	004	REPLACE THE ANTIGALLING COMPOUND REPAIR	-	
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package E				275
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package SBD4				
71-21-15	PW4000	139860	25	21	54T656-01 59T792-01	FWD ENGINE MOUNT - MOUNT SET ASSY - 100"	Package SBD4	PW4G-100-71-26	APPLICATION OF ANTI-GALLANT COMPOUND TO THE MOUNT MAIN BEAM (SNOUT)	-	
71-21-16	PW4000	1777	15	21	51U615 54T670	FWD ENGINE MOUNT - BOLT - 100"	Package A				265
71-21-16	PW4000	1777	15	21	51U615 54T670	FWD ENGINE MOUNT - BOLT - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package A				240
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package B				615
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package B	2-1	BEARING REPLACEMENT	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package C				615
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package C	2-1	BUSHING REPLACEMENT	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package D				1015
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package D	2-2	BUSHING HOLE REPAIR	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package E				760
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package E	2-2	BEARING HOLE REPAIR	-	
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package F				495
71-21-16	PW4000	130632	19	21	310T4022-1 310T4022-2 310T4022-3 310T4022-4	FWD ENGINE MOUNT - EVENER BAR ASSY - 94"	Package F	2-2	SCRATCH AND GOUGE REPAIR	-	
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package A				1385
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package A	CLN/INSP	CLEAN AND INSPECTION	-	
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package D				1455
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package D	LIGHT	DISASSEMBLY, CLEANING, INSPECTION, ASSEMBLY. EXCLUDED PIECE PART REPAIRS	EXAMPLE: LINK ASSY REPLACEMENT (1EA)	
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package E				2925
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package E	MEDIUM	DISASSEMBLY, CLEANING, INSPECTION, ASSEMBLY. EXCLUDED PIECE PART REPAIRS	EXAMPLE: LINK ASSY REPLACEMENT (2EA)	
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package F				3315
71-21-16	PW4000	132768	20	21	310T4020-11 310T4020-14 310T4020-16 310T4020-2 310T4020-24 310T4020-3 310T4020-7 310U4020-2 310U4020-3 310U4020-5 310U4020-6	AFT ENGINE MOUNT - ASSEMBLY - 94"	Package F	HEAVY	DISASSEMBLY, CLEANING, INSPECTION, ASSEMBLY. EXCLUDED PIECE PART REPAIRS	EXAMPLE: HANGER ASSY REPLACEMENT	

71-21-16	PW4000	137856	4	21	310T3037-4	PW4 BOEING AFT ENGINE MOUNT SHEAR PIN	Package B	12-1	CHROME PLATE REPAIR	-	
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package A				1060
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package B				570
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package B	4-1	BEARING REPLACEMENT	-	
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package C				820
71-21-16	PW4000	137924	19	21	310T4025-2	FWD ENGINE MOUNT - BEARING HOUSING - 94"	Package C	4-1	SCRATCH AND GOUGE REPAIR	-	
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package A				1110
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package B				530
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package B	8-1	BUSHING REPLACEMENT	-	
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package C				2035
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package C	8-1	APPLICATION OF PROTECTIVE COATING	-	
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package C	8-2	SCRATCH AND GOUGE REPAIR	-	2035
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package D				1750
71-21-16	PW4000	137925	11	21	310U4031-1 310U4031-11 310U4031-13 310U4031-15 310U4031-17 310U4031-19 310U4031-3 310U4031-5 310U4031-7 310U4031-9	PW4 AFTER ENGINE MOUNT HANGER ASSY	Package D	8-2	BUSHING HOLE REPAIR	-	1750
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package A				1245
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1245
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package B				2010
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package B	5-1	BUSHING REPLACEMENT	-	2010
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package C				2640
71-21-16	PW4000	138149	22	21	310T4031-1 310T4031-10 310T4031-2 310T4031-5	AFT ENGINE MOUNT - HANGER ASSY - 94"	Package C	5-2	BUSHING HOLE REPAIR	-	2640
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package A				295
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	295
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package B				1205
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package B	7-1	BEARING REPLACEMENT	-	1205
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package C				255
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package C	7-1	BLEND REPAIR	-	255
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package D				1815
71-21-16	PW4000	138382	19	21	310T3033-1 310T3033-2 310T3033-3 310T3033-7	AFT ENGINE MOUNT - CENTER LINK ASSY - 94"	Package D	7-2	REPAIR FOR OVERSIZE BEARING	-	1815
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package A				210
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	210
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package B				475
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package B	14-1	BUSHING REPLACEMENT	-	475
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package C				990
71-21-16	PW4000	138383	3	21	310T4032-14	PW4 HANGER FLEX MOUNT	Package C	14-2	REP 14-2 BUSHING REPLACEMENT AND HOLE REPAIR	-	990
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package A				240
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	240
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package B				570
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package B	3-1	BEARING REPLACEMENT	-	570
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package C				1135
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package C	3-1	BUSHING REPLACEMENT	-	1135
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package D				2015
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package D	3-2	BUSHING HOLE REPAIR	-	2015
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package E				760
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package E	3-2	BEARING HOLE REPAIR	-	760
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package F				520
71-21-16	PW4000	144420	19	21	310T4023-1 310T4023-2 310T4023-3 310T4023-5 310T4023-6 310T4023-7 310T4023-8	FWD ENGINE MOUNT - THRUST LINK ASSY - 94"	Package F	3-2	SCRATCH AND GOUGE REPAIR	-	520
71-22-00	PW4000	134178	19	21	51U714 52U362 54T734	AFT ENGINE MOUNT - ASSEMBLY - 100"	Package C				340
71-22-00	PW4000	134178	19	21	51U714 52U362 54T734	AFT ENGINE MOUNT - ASSEMBLY - 100"	Package C		PREINSPECTION OF FORWARD ENGINE MOUNT ASSEMBLY	IN CONJUNCTION WITH PACKAGE LIGHT, MEDIUM OR HEAVY	340
71-22-00	PW4000	134178	19	21	51U714 52U362 54T734	AFT ENGINE MOUNT - ASSEMBLY - 100"	Package D				765
71-22-00	PW4000	134178	19	21	51U714 52U362 54T734	AFT ENGINE MOUNT - ASSEMBLY - 100"	Package D	LIGHT	DISASSEMBLY, CLEANING, INSPECTION, ASSEMBLY. EXCLUDED PIECE PART REPAIRS	-	765

71-51-01	PW4000	610743	20	21	Z1W4132-505 Z1W4132-507	ELECTRICAL HARNESS - FIRE DETECTOR, ENGINE TO PYLON WIRE HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	3135
71-51-01	PW4000	610743	20	21	Z1W4132-505 Z1W4132-507	ELECTRICAL HARNESS - FIRE DETECTOR, ENGINE TO PYLON WIRE HARNESS	Package F				3580
71-51-01	PW4000	610743	20	21	Z1W4132-505 Z1W4132-507	ELECTRICAL HARNESS - FIRE DETECTOR, ENGINE TO PYLON WIRE HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	3580
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package C				505
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	505
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package D				3375
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	3375
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package E				5655
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	5655
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package F				8075
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	8075
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package S800				985
71-51-01	PW4000	610744	20	21	Z1W4120-507 Z1W4120-511 Z1W4120-515 Z1W4120-521	EEC, A CHANNEL WIRE HARNESS	Package S800	PW4NAC 71-155	REWORK OF EEC WIRE HARNESS (W1W2 AND SUPPLEMENTAL CONTROL UNIT (SCU) CONFIGURATION ONLY)	IN CONJUNCTION WITH PACKAGE MEDIUM OR HEAVY	985
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package C				410
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	410
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package D				3135
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	3135
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package E				4010
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	4010
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package F				4885
71-51-01	PW4000	610745	20	21	Z1W4118-507 Z1W4118-511 Z1W4118-513 Z1W4118-515	ELECTRICAL HARNESS - EEC, B CHANNEL WIRE HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	4885
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package C				535
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	535
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package D				2140
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	2140
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package E				4325
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	4325
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package F				5015
71-51-01	PW4000	610746	20	21	Z1W4116-503 Z1W4116-505 Z1W4116-507	ELECTRICAL HARNESS - THRUST REVERSE INLET ANTI-ICE WIRE HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	5015
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package C				555
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	555
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package D				3375
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	3375
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package E				5655
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	5655
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package F				8075
71-51-01	PW4000	610747	20	21	Z1W4114-507 Z1W4114-509	ELECTRICAL HARNESS - IDG CONTROL WIRE HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	8075
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package C				410
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	410
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package D				1700
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1700
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package E				2390
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	2390
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package F				3135
71-51-01	PW4000	610748	20	21	Z1W4083-501 Z1W4083-503	ELECTRICAL HARNESS - BAROSWITCH HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	3135

71-51-02	PW4000	610832	19	21	221W5068-503 221W5068-505 221W5068-507	ELECTRICAL HARNESS - FAN CATEGORY I/IV HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	4865
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C				715
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	715
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D				1675
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1675
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E				4310
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	4310
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F				5425
71-51-02	PW4000	610835	19	21	221W5102-505 221W5102-509 221W5102-515 221W5102-517	ELECTRICAL HARNESS - CORE MISC. HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	5425
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C				425
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	425
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D				1095
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1095
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E				2320
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	2320
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F				2800
71-51-02	PW4000	610841	19	21	-	ELECTRICAL HARNESS - EEC CHANNEL "B" HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	2800
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C				625
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	625
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D				1640
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1640
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E				3920
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	3920
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F				4865
71-51-02	PW4000	610845	19	21	221W5144-513	ELECTRICAL HARNESS - THRUST REVERSER RH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	4865
71-51-02	PW4000	610847	19	21	221W5146-513	THRUST REVERSER LH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C				555
71-51-02	PW4000	610847	19	21	221W5146-513	THRUST REVERSER LH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	555
71-51-02	PW4000	610847	19	21	221W5146-513	THRUST REVERSER LH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D				1370
71-51-02	PW4000	610847	19	21	221W5146-513	THRUST REVERSER LH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1370
71-51-02	PW4000	610847	19	21	221W5146-513	THRUST REVERSER LH LVDT HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E				3315

71-51-02	PW4000	610876	19	21	221-5190-505 221-5190-507 221-5190-509	ELECTRICAL HARNESS - THRUST REVERSER JUNCTION BOX HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	4095
71-51-02	PW4000	610876	19	21	221-5190-505 221-5190-507 221-5190-509	ELECTRICAL HARNESS - THRUST REVERSER JUNCTION BOX HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F				5035
71-51-02	PW4000	610876	19	21	221-5190-505 221-5190-507 221-5190-509	ELECTRICAL HARNESS - THRUST REVERSER JUNCTION BOX HARNESS ASSEMBLY - MC DONNELL DOUGLAS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	5035
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package A				400
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	400
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package C				495
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package C	002	Restore PWA 73 Coating	-	495
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package H				540
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package H	007	Stud Replacement	-	540
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package S801				360
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package S802	72-513	3RD STG DUCT SEAL SUPPORT MODIF.	-	360
72□53□18	PW4000	137750	5	28	50N257 50N332 50N535	PW4 STAGE 3 LPT(INNER) DUCT ASSEMBLY	Package S802	PW4G-100-72-41	LPT STG3 INNER DUCT - & SEAL RING PLASMA	-	360
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package A				340
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	340
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package B				1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package B	001	UPPER BEARING JOURNAL CHROMIUM PLATE	-	1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package C				1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package C	002	LOWER BEARING JOURNAL CHROMIUM PLATE	-	1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package D				1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package D	003	UPPER BEARING SHOULDER CHROMIUM PLATE	-	1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package E				1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package E	004	LOWER BEARING SHOULDER CHROMIUM PLATE	-	1490
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package F				180
72□62□02	PW4000	137743	5	28	50G005 50G949	PW4 ANGLE GEARBOX BEVEL GEAR ASSY	Package F	005	SURFACE DAMAGE BLEND REPAIR	-	180
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package A				580
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	580
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package B				3775
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package B	LIGHT	REFURBISHMENT OF REMOVED SET OF PARTS	LESS THAN 4 OF FOLLOWING ENG. MODULS PARTIALLY/FULLY DISASSEMBLED (31,33 OR 34,41,51,52,53,54,61,62)	3775
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package C				15040
72-00-00	PW4000	139603	22	28	4023115 4023116 4023466 503414 50A287 50H354 511105 53T020 53T583 53T932 545962 564705 647797 656568 743534 760548 776440 776441 776703 793423 800844 MS9201-06 MS9201-08 MS9209-18 MS9209-28 MS9218-06 MS9360-11 MS9364-11 MS9574-04 MS9575-05 MS9575-06 MS9575-07 MS9575-08 MS9575-09 MS9575-10 MS9575-14 MS9576-04 MS9715-06 MS9715-08 MS9715-09 MS9715-10 MS9715-12 ST1074-09 ST1258-12 ST1258-13 ST1390-05 ST1415-05 ST1416-16 ST1418-12 ST1420-05 ST1420-06 ST1420-08 ST1420-09 ST1420-10 ST1420-11 ST1420-12 ST1420-18 ST1420-27 ST1421-11 ST1421-15 ST1421-18 ST1422-14 ST1426-10 ST1503-07 ST1503-10 ST1503-12 ST1503-13 ST1803-12 ST2162-12 ST2162-16 ST2196-020 ST2348-08 ST2348-11 ST2601-08 ST2601-12 ST2785-09 ST2785-10 ST2785-11 ST2785-13 ST5124-05	ENGINE GENERAL - COMMON PARTS - SCREWS, NUTS AND SPACERS REFURBISHMENT	Package C	MEDIUM	REFURBISHMENT OF REMOVED SET OF PARTS	MODUL 33 AND 34 PARTIALLY/FULLY DISASSEMBLED OR NOT LIGHT CONDITION	15040

72-00-00	PW4000	663441	12	28	30377-450 30377-500 30377-600 30398-200 30398-400 30550-400 30659-200 30659-400 30679-450 30679-500 30679-600 30759-200 30766-400 31046-150 31073-150 34H40-600 50U366 50U367 50U368 50U370 50U372 50U373 50U374 51U749 51U888 56T561 57Y938 58T054 58T886 59T331 728879-2	ENGINE GENERAL - COMMON PARTS - MISCELLANEOUS CLAMPS GENERAL (SPM)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	205
72-00-00	PW4000	663441	12	28	30377-450 30377-500 30377-600 30398-200 30398-400 30550-400 30659-200 30659-400 30679-450 30679-500 30679-600 30759-200 30766-400 31046-150 31073-150 34H40-600 50U366 50U367 50U368 50U370 50U372 50U373 50U374 51U749 51U888 56T561 57Y938 58T054 58T886 59T331 728879-2	ENGINE GENERAL - COMMON PARTS - MISCELLANEOUS CLAMPS GENERAL (SPM)	Package B				155
72-00-00	PW4000	663441	12	28	30377-450 30377-500 30377-600 30398-200 30398-400 30550-400 30659-200 30659-400 30679-450 30679-500 30679-600 30759-200 30766-400 31046-150 31073-150 34H40-600 50U366 50U367 50U368 50U370 50U372 50U373 50U374 51U749 51U888 56T561 57Y938 58T054 58T886 59T331 728879-2	ENGINE GENERAL - COMMON PARTS - MISCELLANEOUS CLAMPS GENERAL (SPM)	Package B		REPLACE DEFECT INSERTS	-	155
72-00-00	PW4000	663441	12	28	30377-450 30377-500 30377-600 30398-200 30398-400 30550-400 30659-200 30659-400 30679-450 30679-500 30679-600 30759-200 30766-400 31046-150 31073-150 34H40-600 50U366 50U367 50U368 50U370 50U372 50U373 50U374 51U749 51U888 56T561 57Y938 58T054 58T886 59T331 728879-2	ENGINE GENERAL - COMMON PARTS - MISCELLANEOUS CLAMPS GENERAL (SPM)	Package C				155
72-00-00	PW4000	663441	12	28	30377-450 30377-500 30377-600 30398-200 30398-400 30550-400 30659-200 30659-400 30679-450 30679-500 30679-600 30759-200 30766-400 31046-150 31073-150 34H40-600 50U366 50U367 50U368 50U370 50U372 50U373 50U374 51U749 51U888 56T561 57Y938 58T054 58T886 59T331 728879-2	ENGINE GENERAL - COMMON PARTS - MISCELLANEOUS CLAMPS GENERAL (SPM)	Package C		REPLACE DEFECT NUTPLATES	-	155
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package B				280
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package B		REPLACE INSERTS ENGINE	-	280
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package C				280
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package C		REPLACE INSERTS MODULE	-	280
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package D				310
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package D		REPLACE INSERTS TEST CELL	-	310
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package E				280
72-00-00	PW4000	673760	3	28	PW4000 BASIS ENGINE	REPLACEMENT OF HELICOIL ON ENGINE/MODULE	Package E		REPLACE INSERTS QTL	-	280
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package A				495
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package A	CLN/INSP	CLEANING & INSPECTION	-	495
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package B				695
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package B	INSP-02	INSPECTION/CHECK	PW 4168	695
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package C				695
72-00-52	PW4000	20803	3	28	SOL171 50L471 50L671 50L771 51L371 51L671 53L181 53L281	PW4 TURBINE ROTOR-ASSEMBLY, 1,ST STAGE	Package C	INSP-03	INSPECTION/CHECK	PW 40XX, PW 41XX, PW 44XX	695
72-00-52	PW4000	20806	15	28	SOL172 50L472 50L572 50L972 51L372 51L472 51L572 51L592 54L682	ENGINE GENERAL - COMMON PARTS - HIGH PRESSURE TURBINE - ASSEMBLY 2ND STAGE	Package A				1980
72-00-52	PW4000	20806	15	28	SOL172 50L472 50L572 50L972 51L372 51L472 51L572 51L592 54L682	ENGINE GENERAL - COMMON PARTS - HIGH PRESSURE TURBINE - ASSEMBLY 2ND STAGE	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1980
72-00-52	PW4000	20806	15	28	SOL172 50L472 50L572 50L972 51L372 51L472 51L572 51L592 54L682	ENGINE GENERAL - COMMON PARTS - HIGH PRESSURE TURBINE - ASSEMBLY 2ND STAGE	Package A	INSP-02	VISUAL INSPECTION	PW4168	
72-00-52	PW4000	20806	15	28	SOL172 50L472 50L572 50L972 51L372 51L472 51L572 51L592 54L682	ENGINE GENERAL - COMMON PARTS - HIGH PRESSURE TURBINE - ASSEMBLY 2ND STAGE	Package A	INSP-03	VISUAL INSPECTION	PW40XX,PW41XX,PW44XX	1980
72-09-00	PW4000	139328	25	21	14510-113 1A8431 221-4352-501 221-4352-503 221-5357-501 312T2359-25 332T4714-1 332T4714-3 332T4714-7 332T4714-9 332T4911-42 332T4911-58 332T4911-62 332T4911-77 332T4911-79 332T4921-219 332T4921-223 332T4921-241 332T4922-286 332T4922-369 332T4922-414 332T4922-416 332T4922-456 332T4922-632 332T4922-640 332T4922-96 332T4925-10 332T4925-24 50A619 50D729-01 50D747-01 50G959-01 50J208 50J601 50J804-01 50J831-01 50J832-01 50N581-01 50P287-01 50P304-01 50P305-01 50P411-01 50P412-01 50P419-01 50R359-01 50T193 50T534 50U005-001 50U005-01 50U037-01 50U053-01 50U054-01 50U056-01 50U057-01 50U058-01 50U060-01 50U062-01 50U063-01 50U064-01 50U144-01 50U359-01 50U360-01 50U390-01 50U397-01 50U417-01 50U419 50U458-01 50U493-01 50U593-01 50U725-01 50U731-01 50U734-01 50U757-01 50U761-01 50U764-01 50U780-01 50U948-01 51D671-01 51G427-01 51H396-01 51H397-01 51H398-01 51H484-01 51H596-01 51H872 51H995-01 51H995-03 51L142-01 51R131-01 51T150 51T47 51T306 51T758 51U070-01 51U089-01 51U099-01 51U115-01 51U580-01 51U602-01 51U676-01 51U700-01 51U737-01 51U923-01 51U941-01 51U952-01 51U984 52G069-01 52T044-01 52T067 52T265 52T268 52T270 52T361 52T362 52T478 52T480-01 52T614-01 52T686 52T698-01 52T704-01 52T720-01 52T728 52T771 52T877 52T878-01 52T900-01 52T909 52T963 52U018-01 52U019-01 52U224-01 52U390-01 52U461-01 52U467-01 52U468-01 52U568-01 52U626-01 52U884-01 52U885-01 52U886-01 52U888-01 52U889-01 52U903-01 52U904-01 52U905-01 52U906-01 52U907-01 52U908-01 52U909-01 52U978-01 52U988-01 53T006 53T018-01 53T066-01 53T102-01 53T123 53T261 53T263-01 53T264-01 53T283-01 53T332-01 53T400-01 53T420-01 53T421-01 53T498-01 53T506-01 53T514 53T521-01 53T532-01 53T534-01 53T626 53T626-01 53T639-01 53T672-01 53T689-01 53T950-01 53T999 54H125-01 54H768-01 54H772-01 54T005-01 54T015-01 54T032 54T037-01 54T040-01 54T044-01 54T078-01 54T079-01 54T089-01 54T229-01 54T230-01 54T233 54T237-01 54T345-01 54T348-01 54T415-01 54T469-01 54T518-01 54T621-01 54T647-01 54T724-01 54T771-01 54T783-01 54T833-01 54T899-01 55H303-01 55T289-01 55T441-01 55T472-01 55T502-01 55T637-01 55T641-01 55T677-01 55T678-01 55T679-01 55T680-01 55T681-01 55T696-01 55T815-01 56T161 56T220-01 56T248-01 56T258 56T272-01 56T438-01 56T469-01 56T604-01 56T681-01 56T712-01 56T776-01 56T814-01 56T831-01 56T832-01 56T835-01 56T966-01 57T003-01 57T005-01 57T026-01 57T089-01 57T231-01 57T348-01 57T360-01 57T459-01 57T494-01 57T503-01 57T582-01 57T583-01 57T658-01 57T663-01 57T711-01 57T760-01 57T778-01 57T783-01 57T819-01 57T836-01 57T870-01 57T883-01 57T891-01 57T945-01 57T946-01 57T947-01 57T948-01 57T949-01 58T136-01 58T165-01 58T206-01 58T231-01 58T233 58T257-01 58T262-01 58T264-01 58T267-01 58T304-01 58T312-01 58T315-01 58T316 58T380 58T529-01 58T530-01 58T531-01 58T532-01 58T567-01 58T577-01 58T626-01 58T635-01 58T661-01 58T719-01 58T763-01 58T767-01 58T774-01 58T779-01 58T903-01 59T023-01 59T032-01 59T062-01 59T067-01 59T091 59T109-01 59T124 59T128-01 59T139-01 59T153-01 59T171 59T172-01 59T191-01 59T192-01 59T199-01 59T230-01 59T242-01 59T368-01 59T402-01 59T403-01 59T447-01 59T567-01 59T591-01 59T604-01 59T672-01 59T691-01 59T758-01 59T768-01 59T771-01 59T789-01 59T801-01 59T802-01 59T803-01 59T803-01 59T818-01 59T823-01 59T871-01 59T872-01 59T873-01 59T884 59T889-01 59T921-01 59T922-01 59T934-01 59T936-01 59T938-01 59T950-01 59T964-01 59T981-01 59T982-01 710767 TA12700019	ENGINE GENERAL - COMMON PARTS - VARIOUS ENGINE BRACKETS AND COMMON NON SPECIFIED HARDWARE	Package A				105

72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package A	INSP-05	INSPECTION CHECK 05	PRESSURE TEST	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package B				80
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package B	001	APPLY ANTI-SIZE COMPOUND	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package C				395
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package C	002	TUBE NUT THRUST WIRE INSTALLATION	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package D				230
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package D	004	BLEND REPAIR SURFACE DAMAGE	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package E				1435
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package E	005	DENT REPAIR	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package F				905
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package F	007	LINER,NUT,REDUCER,ELBOW,SLEEVE REPLACEMENT	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package G				280
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package G	011	REPAIR OF DAMAGED AREA ON HEAT SHIELD	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package H				280
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package H	013	MINOR GOUGE, TEAR, CUT OF FLEXIBLE TUBE FIRE SLEEVE REPAIR	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package I				780
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package I	018	FLANGE COAT REPLACEMENT	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package J				375
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package J	020	STRAINER ELEMENT HOUSING ASSY FLA	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package K				220
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package K	SPM	REPLACE DEFECT INSERTS	-	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package L				425
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package L	SPM	REPAIR OF THE TUBE CONICAL SEAT	SPM 70-00-00 REP-22	
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package M				355
72-09-71	PW4000	672812	4	21	52T576-01 53T209-01 58T362-01	PW4 TUBES (REPAIR HEAVY) CCP > 4000 USD	Package M	SPM	REPLACE RIVETED STOP NUT	SPM 70-43-00	
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package A				420
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package A	INSP-05	INSPECTION CHECK 05	PRESSURE TEST	420
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package B				80
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package B	001	APPLY ANTI-SIZE COMPOUND	-	80
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package C				285
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package C	002	TUBE NUT THRUST WIRE INSTALLATION	-	285
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package D				125
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package D	004	BLEND REPAIR SURFACE DAMAGE	-	125
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package E				1490
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package E	005	DENT REPAIR WITHOUT REMOVABLE PARTS	-	1490
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package F				280
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package F	011	REPAIR OF DAMAGED AREA ON HEAT SHIELD	-	280
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package G				685
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package G	048	OIL TUBE, COATING REPAIR	-	685
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package H				425
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package H	SPM	REPAIR OF THE TUBE CONICAL SEAT	SPM 70-00-00 REP-22	425
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package I				355
72-09-71	PW4000	672813	4	21	53T165-01	PW4 TUBES (REPAIR MEDIUM) CCP 2000-4000	Package I	SPM	REPLACE RIVETED STOP NUT ACC.	SPM 70-43-00	355
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package A				260
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package A	CLN/INSP	CLEANING & INSPECTION	-	260
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package A	INSP-05	PRESSURE TEST	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package B				80
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package B	001	APPLY ANTI-SIZE COMPOUND	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package C				290
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package C	002	TUBE NUT THRUST WIRE INSTALLATION	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package D				145

72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package D	004	BLEND REPAIR OF SURFACE DAMAGE	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package E				1490
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package E	005	DENT REPAIR	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package F				240
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package F	011	REPAIR OF DAMAGED AREA ON HEAT SHIELD TUBE	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package G				685
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package G	048	OIL TUBE COATING REPAIR	-	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package H				350
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package H	SPM	REPAIR OF THE TUBE CONICAL SEAT	SPM 70-00-00 REP-22	
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package I				290
72-09-71	PW4000	672814	6	21	50G809 50G811 51G864-01 51U930-01 57T896-01 58T064-01	PW4 TUBES	Package I	SPM	REPLACE RIVETED STOP NUT	SPM 70-43-00	
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package A				420
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package A	INSP-05	PRESSURE TEST	-	420
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package B				80
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package B	001	APPLY ANTI-SIZE COMPOUND	-	80
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package C				285
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package C	002	TUBE NUT THRUST WIRE INSTALLATION	-	285
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package D				425
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package D	SPM	REPAIR CONICAL SEAT	-	425
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package E				285
72-09-71	PW4000	672815	4	21	56T656-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 20	Package E	SPM	REPLACE RIVETED STOP NUT ACC.	SPM 70-43-00	285
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package A				420
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package A	CLN/INSP	CLEANING AND INSPECTION	-	420
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package A	INSP-05	PRESSURE TEST	-	
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package B				80
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package B	001	APPLY ANTI-SIZE COMPOUND	-	
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package C				395
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package C	002	TUBE NUT THRUST WIRE INSTALLATION	-	
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package D				425
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package D	SPM	REPAIR CONICAL SEAT	-	
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package E				355
72-09-71	PW4000	672816	5	21	51G818-01 51G819-01 51G822-01 51G862-01 53T684-01	PW4 TUBES (REPAIR LIGHT) CCP 800 - 2000	Package E	SPM	REPLACE RIVETED STOP NUT ACC.	SPM 70-43-00	
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package A				315
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package A	INSP-05	PRESSURE TEST	-	315
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package B				80
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package B	001	APPLY ANTI-SIZE COMPOUND	-	80
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package C				305
72-09-71	PW4000	672817	5	21	51G861 52G126-01	PW4 TUBES (INSPECTION ONLY) CCP <800	Package C	SPM	REPAIR CONICAL SEAT	-	305
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package A				230
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	230
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package B				1270
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package B	001	WELD REPAIR OF DAMAGED COOLING DUCT	-	1270
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package D				1210
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package D	003	WELD REPAIR OF AIR STARTER VALVE DUCT ASSEMBLY KEY	-	1210
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package E				1305
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package E	004	REPLACE AIR STARTER VALVE DUCT ASSEMBLY KEY	-	1305
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package F				120
72-09-72	PW4000	139715	22	28	50U039-01 52U600-01 58T116-01 58T768-01 58T770-01 58T770-101 59T454-01	ENGINE GENERAL - COMMON PARTS - EXTERNAL DUCTS	Package F	-	REPLACE RIVETED PARTS	-	120
72-09-73	PW4000	137365	3	21	50A349 50A653	PW4 BRACKET, ASSY OF TRANSDUCER	Package A				190
72-09-73	PW4000	137365	3	21	50A349 50A653	PW4 BRACKET, ASSY OF TRANSDUCER	Package A	CLN/INSP	CLEANING & INSPECTION	-	190
72-09-73	PW4000	137365	3	21	50A349 50A653	PW4 BRACKET, ASSY OF TRANSDUCER	Package B				605

72-09-73	PW4000	672831	6	21	51D768-01 51D772-01 52D375-01 52D376-01 52D377-01 52D378-01	PW4 ENGINE BRACKET	Package A	CLN/INSP	CLEANING AND INSPECTION	-	315
72-09-73	PW4000	672831	6	21	51D768-01 51D772-01 52D375-01 52D376-01 52D377-01 52D378-01	PW4 ENGINE BRACKET	Package O				685
72-09-73	PW4000	672831	6	21	51D768-01 51D772-01 52D375-01 52D376-01 52D377-01 52D378-01	PW4 ENGINE BRACKET	Package O	014	ANTI SLIP STRIP ADHESIVE REPLACEMENT	-	685
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package A				380
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	380
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B				1950
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B	001	WELD REPAIR TURBINE CASE COOLING MANIFOLD	-	1950
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B	002	REPLACE THE BRACKET AND PIN	-	
72-09-75	PW4000	137625	27	28	50T060 50T061 50T062 50T063 50T064 50T065 50T066 51T277 51T321 52T889 52T890 52T891 52T892 52T893 52T894 52T895 52T896 52T897 53T745-01 53T746-01 53T747-01 53T748-01 53T749-01 57T547-01 57T571-01 59T036-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B	003	NUTPLATE REPLACEMENT REPAIR	-	1950
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package A				380
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	380
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B				1420
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package B	001	WELD REPAIR	-	1420
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package C				550
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package C	001	COLD STRAIGHTENING REPAIR	-	550
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package D				1210
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package D	002	REPLACE WORN TUBE REPAIR	-	1210
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package E				955
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package E	003	REPLACE WORN GUIDES REPAIR	-	955
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package F				670
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package F	004	REPLACE WORN TCC MANIFOLD (FRONT) BRACKET REPAIR	-	670
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package G				555
72-09-76	PW4000	137621	30	28	50T085 50T086 50T087 50T088 50T089 50T090 50T091 50T092 50T093 50T094 50T095 50T097 50T098 50T099 50T120 50U143-01 52T972-01 52T973-01 55T561 55T563 56T331 59T865-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING MANIFOLD ASSEMBLY	Package G	SPM	REPAIR OF DEFECT NUTS, GUIDES, BRACKETS AND RIVETS ACCORDING SPM	-	555
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package A				380
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	380
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package B				540
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package B	001	REPLACE LOOSE OR MISSING RIVETS REPAIR - TCC DUCT ASSEMBLY	-	540
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package C				745
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package C	002	WELD DAMAGED ON ELONGATED RIVET HOLES REPAIR - TCC DUCT ASSEMBLY	-	745
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package D				1995
72-09-77	PW4000	144406	24	28	50T218 52T926 55T351-01	ENGINE GENERAL - COMMON PARTS - TURBINE CASE COOLING DUCT ASSEMBLY	Package D	003	TURBINE CASE COOLING DUCT BOTTOM SEGMENT REPAIR	-	1995
72-21-59	PW4000	133511	4	21	1A6716 HAD18286	THERMOCOUPLE (DOT 3)	Package B				760
72-21-59	PW4000	133511	4	21	1A6716 HAD18286	THERMOCOUPLE (DOT 3)	Package B	-	OVERHAUL	-	760
72-31-02	PW4000	139784	26	28	52B313	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 LPC BLADE - 100"	Package E				60
72-31-02	PW4000	139784	26	28	52B313	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 LPC BLADE - 100"	Package E	-	WEIGH AND MATCH BLADES	-	60
72-31-03	PW4000	138241	25	28	50B426 51B026 53B516 53B516-001 55B116 55B116-001	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.6 LPC BLADE - 94"	Package A				60
72-31-03	PW4000	138241	25	28	50B426 51B026 53B516 53B516-001 55B116 55B116-001	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.6 LPC BLADE - 94"	Package A	CLN/INSP	CLEANING 001 AND INSPECTION 001	-	60

72-31-08	PW4000	137541	28	28	50B422 51B022-01 53B200-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY	Package SB00	PW4ENG 72-665	REPETITIVE EDDY CURRENT INSPECTION OF THE BLADE LEADING EDGE	ONLY BLADED DISK		885
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package A					1385
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-		1385
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package B					1275
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package B	001	STRAIGHTEN KNIFE-EDGE SEAL	-		1275
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package C					945
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package C	002	BLEND REPAIR KNIFE EDGE SEAL	-		945
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package D					2095
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package D	003	SURFACE DAMAGE BLEND REPAIR	-		2095
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package E					890
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package E	004	BLEND REPAIR BALANCE FLANGE	-		890
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package H					4810
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package H	007	PLASMA SPRAY FRONT SNAP DIAMETER	-		4810
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package I					3415
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package I	008	TIEROD HOLES REPAIR	-		3415
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package J					3810
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package J	009	SHOTPEEN DRUM ROTOR DISK SLOTS	-		3810
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package L					550
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package L	011	BALANCE COUNTERWEIGHT REMOVAL AND INSTALLATION REPAIR	-		550
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package SB00					330
72-31-08	PW4000	139760	16	28	50B882-01	LOW PRESSURE COMPRESSOR (LPC) - DRUM ROTOR DISK ASSEMBLY - 100"	Package SB00	72-EQ-520295	LPC, 3RD STG BLADES: INSP. BLADE ROOT	-		330
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package A					920
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-		920
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AA					10020
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AA	026	REPLACE DAMAGED STATOR VANE REPAIR	-		10020
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AC					7255
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AC	028	REPLACE INDIVIDUAL INNER SHROUD SEGMENT REPAIR	-		7255
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AE					1760
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AE	030	BOLT HOLE FUSION WELD REPAIR	-		1760
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AG					5690
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AG	032	WELD OVERSIZED VANE ATTACHMENT RIVET HOLES	-		5690
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AI					2925
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AI	034	BENT FLANGE STRAIGHTENING REPAIR	-		2925

72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AJ				3410
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AJ	042	OUTER SHROUD PWA 36003 SILICONE RUBBER REPLACEMENT REPAIR	-	3410
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AK				1740
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AK	040	OUTER SHROUD SURFACE DAMAGE WELD REPAIR	-	1740
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AL				855
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package AL	041	FAIRING TO INNER SHROUD CRACK REPAIR	-	855
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package B				510
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package B	001	ANODIZE TOUCH-UP	-	510
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Q				855
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Q	016	BLEND REPAIR VANES AND OUTER SHROUD	-	855
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package S				1545
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package S	018	CRACK REPAIR LPC STAGE 1 COMPRESSOR STATOR ASSEMBLY INNER SHROUD	-	1545
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package T				2245
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package T	019	REPLACE LPC (STAGE 1) COMPRESSOR STATOR ASSEMBLY INNER AIRSEAL	-	2245
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package V				2435
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package V	021	FAIRING SCUFFING, FRAYING, NICKS, CHIPS AND DENTS REPAIR	-	2435
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Y				2680
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Y	024	REPLACE DAMAGED VANE POTTING COMPOUND REPAIR	-	2680
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Z				2345
72-31-09	PW4000	139733	33	28	51B571-001 51B571-01 55B051-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 COMPRESSOR STATOR ASSEMBLY - 100"	Package Z	025	FAIRING POTTING FILLER COMPOUND VOID AND CRACK REPAIR	-	2345
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package A				1110
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1110
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AE				9120
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AE	030	DAMAGED VANE POTTING (DRY ROTTED) COMPOUND REPLACEMENT REPAIR	-	9120
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AF				3055
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AF	039	BENT FLANGE STRAIGHTENING REPAIR	-	3055
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AI				8320
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AI	046	MISSING SILICONE RUBBER SEALANT REPLACEMENT REPAIR	-	8320
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AJ				8540
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AJ	047	INNER AIRSEAL REPLACEMENT REPAIR	-	8540
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AK				14580
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AK	048	INNER SHROUD REPLACEMENT REPAIR	-	14580
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AL				20735
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package AL	037	REMOVAL OF CORROSION	-	20735
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package B				535
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package B	001	ANODIZE TOUCH-UP	-	535
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package C				1375
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package C	002	BLEND REPAIR VANES	-	1375
72-31-10	PW4000	672854	6	28	51B426-01 54B916 55B021-01 56B016-001 56B016-01 56B116 56B116-003	PW4000 94" LPC COMPRESSOR STG. 1.6.2 & 3	Package C	005	BLEND REPAIR OUTER SHROUD	-	

72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB01				12785
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB01	PW4G-100-72-189	REPLACEMENT OR MODIFICATION TO INCORPORATE IMPROVED INNER SHROUD RUBSTRIPS	-	
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB02				600
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB02	PW4G-100-72-259	REPLACEMENT OR MODIFICATION TO INCREASE THE 3RD STAGE BLADE TIP TO OUTER AIR SEAL (OAS) CLEARANCE	-	
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB03				8005
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package SB03	PW4G-100-72-259	C3STATOR INCREASED BLADE TIP CLEARANCE	-	
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package T				495
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package T	019	CRACK REPAIR LPC STAGE 1.6, 2 AND 3 COMPRESSOR STATOR ASSEMBLY INNER SHROUD	-	
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package U				8480
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package U	020	REPLACE THE INNER AIRSEAL REPAIR	-	
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package V				16640
72-31-10	PW4000	672857	5	28	518626-001 518626-002 518626-01 538186 538226-01 598816-001 598816-01	PW4000 100" LPC COMPRESSOR STG 1.6 - 3	Package V	021	REPLACE VANE REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package A				1005
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package B				370
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package B	001	ANODIZE TOUCH-UP LPC STAGE 4 DUCT	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package C				3495
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package C	002	REPLACE SILICONE RUBBER RUBSTRIP	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package F				2125
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package F	005	PLASMA SPRAY LPC STAGE 4 DUCT FRONT ID SNAP DIAMETER	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package G				2815
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package G	006	SILICONE RUBBER AIRSEAL REPAIR - LPC STAGE 4 DUCT	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package J				810
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package J	009	BOLT HOLE FUSION WELD REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package L				3755
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package L	011	FUSION WELD REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package M				2565
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package M	012	BENT FLANGE STRAIGHTENING REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package O				6220
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package O	014	HOOK CRACKS AND GASPATH FOD DAMAGE WELD REPAIR	PW 94 INCH	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package P				2125
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package P	015	O-RING GROOVE FLANGE WELD REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package S				600
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package S	018	BLEND REPAIR	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB00				910
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB00	PW4ENG 72-39	MODIFICATION OF 4TH STAGE LPC DUCT AND INNER FAN EXIT CASE	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB01				3495
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB01	PW4ENG 72-666	LPC IMPROVED RUBBER AIRSEAL MODIFICATION	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB02				2315
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package SB02	PW4G-100-72-119	LPC STATOR RUBBER REPLACEMENT	-	
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package T				1940
72-31-11	PW4000	137539	35	28	508023 508023-001 508227 508230 518150 518154	LOW PRESSURE COMPRESSOR (LPC) - STAGE 4 DUCT	Package T	019	OUTER DIAMETER LUG DAMAGE WELD REPAIR	-	
72-31-12	PW4000	139759	27	28	508043 508880 538023	LOW PRESSURE COMPRESSOR (LPC) - (DRUM TO HUB) TIEROD	Package A				95
72-31-12	PW4000	139759	27	28	508043 508880 538023	LOW PRESSURE COMPRESSOR (LPC) - (DRUM TO HUB) TIEROD	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-31-12	PW4000	139759	27	28	508043 508880 538023	LOW PRESSURE COMPRESSOR (LPC) - (DRUM TO HUB) TIEROD	Package B				85
72-31-12	PW4000	139759	27	28	508043 508880 538023	LOW PRESSURE COMPRESSOR (LPC) - (DRUM TO HUB) TIEROD	Package B	001	RESTORE ANTIGALLANT	-	
72-31-12	PW4000	139759	27	28	508043 508880 538023	LOW PRESSURE COMPRESSOR (LPC) - (DRUM TO HUB) TIEROD	Package B	002	RESTORE ANTIGALLANT	-	85
72-31-13	PW4000	137362	25	28	1A4953 1A4954 1A4955 1A6670 50B249 50B256 50B257 50B258 81377-624 H51903-6	LOW PRESSURE COMPRESSOR (LPC) - TIEROD NUT	Package A				55

72-31-13	PW4000	137362	25	28	1A4953 1A4954 1A4955 1A6670 50B249 50B256 50B257 50B258 81377-624 H51903-6	LOW PRESSURE COMPRESSOR (LPC) - TIEROD NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	55
72-31-13	PW4000	137362	25	28	1A4953 1A4954 1A4955 1A6670 50B249 50B256 50B257 50B258 81377-624 H51903-6	LOW PRESSURE COMPRESSOR (LPC) - TIEROD NUT	Package B				115
72-31-13	PW4000	137362	25	28	1A4953 1A4954 1A4955 1A6670 50B249 50B256 50B257 50B258 81377-624 H51903-6	LOW PRESSURE COMPRESSOR (LPC) - TIEROD NUT	Package B	001	RESTORE ANTIGALLING COMPOUND	-	115
72-31-14	PW4000	137768	17	28	50B110 50B233 50B234 50B235 50B239 50B797 50B798 51B156	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BALL BEARING - 94" & 100"	Package A				475
72-31-14	PW4000	137768	17	28	50B110 50B233 50B234 50B235 50B239 50B797 50B798 51B156	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BALL BEARING - 94" & 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	475
72-31-14	PW4000	137768	17	28	50B110 50B233 50B234 50B235 50B239 50B797 50B798 51B156	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BALL BEARING - 94" & 100"	Package SB00				480
72-31-14	PW4000	137768	17	28	50B110 50B233 50B234 50B235 50B239 50B797 50B798 51B156	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BALL BEARING - 94" & 100"	Package SB00	PWAENG 72-768	BRG NO.1 BALL-RECONDITIONING OF BEARING	-	480
72-31-15	PW4000	137367	29	28	50B040	LOW PRESSURE COMPRESSOR (LPC) - BEARING (INNER RACE) RETAINING NUT	Package A				730
72-31-15	PW4000	137367	29	28	50B040	LOW PRESSURE COMPRESSOR (LPC) - BEARING (INNER RACE) RETAINING NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	730
72-31-15	PW4000	137367	29	28	50B040	LOW PRESSURE COMPRESSOR (LPC) - BEARING (INNER RACE) RETAINING NUT	Package B				1370
72-31-15	PW4000	137367	29	28	50B040	LOW PRESSURE COMPRESSOR (LPC) - BEARING (INNER RACE) RETAINING NUT	Package B	001	REPLACE SILVER PLATE	INCL. CLEANING AND INSPECTION	1370
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package A				105
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	105
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package C				915
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package C	002	REPLACE THE CLINCH NUTS	-	915
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package D				1670
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package D	003	PLASMA SPRAY OD SNAP (TITANIUM PART)	-	1670
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package SB00				155
72-31-17	PW4000	137814	24	28	50B199 50B247 50B275 50B772 51B170	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING (CARBON) SEAL ASSEMBLY	Package SB00	PWAENG-72-237	REPLACEMENT OR MODIFICATION OF, TO IMPROVE RESITANCE TO OIL LEAKS	-	155
72-31-17	PW4000	656432	8	28	50B046	PIN NO. 1 BRG SEAL ASSY	Package A				80
72-31-17	PW4000	656432	8	28	50B046	PIN NO. 1 BRG SEAL ASSY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	80
72-31-17	PW4000	656433	2	28	50B048	SPACER NO.1 BRG SEAL ASSY	Package A				135
72-31-17	PW4000	656433	2	28	50B048	SPACER NO.1 BRG SEAL ASSY	Package A	CLN/INSP	CLEANING & INSPECTION	-	135
72-31-17	PW4000	656434	4	21	50A037	COLLAR NO.1 BRG SEAL ASSY	Package A				45
72-31-17	PW4000	656434	4	21	50A037	COLLAR NO.1 BRG SEAL ASSY	Package A	CLN/INSP	CLEANING & INSPECTION	-	45
72-31-18	PW4000	27509	3	28	50B037 50B205 50B206 50B207	PW4 NO.1 BEARING FACE SEAL ASSEMBLY	Package A				155
72-31-18	PW4000	27509	3	28	50B037 50B205 50B206 50B207	PW4 NO.1 BEARING FACE SEAL ASSEMBLY	Package A	CLN/INSP	CLEANING & INSPECTION	-	155
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package A				745
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	745
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package B				765
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package B	001	ANODIZE TOUCH-UP	-	765
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package C				1515
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package C	002	BLEND REPAIR VANES AND OUTER SHROUD	-	1515
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package D				465
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package D	003	CRACK REPAIR LPC STAGE 1.3 COMPRESSOR STATOR ASSEMBLY INNER SHROUD	-	465
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package E				4820
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package E	004	SILICONE RUBBER INNER AIRSEAL REPAIR	-	4820
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package F				4965

72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package F	005	SILICONE RUBBER OUTER AIRSEAL REPAIR	-	4965
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package G			-	1465
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package G	006	ALUMINUM BAND REPLACEMENT FOR INNER SHROUD	-	1465
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package J			-	7270
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package J	009	INNER OR OUTER SIDE SEALANT OUTER SHROUD	-	7270
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package L			-	2230
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package L	011	REPLACE DAMAGED VANE POTTING COMPOUND REPAIR	-	2230
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package M			-	1400
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package M	012	BOLT HOLE FUSION WELD REPAIR	-	1400
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package N			-	5550
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package N	013	RIVET HOLES WELD	-	5550
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package P			-	4020
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package P	015	BENT FLANGE STRAIGHTENING	-	4020
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package R			-	4435
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package R	017	INNER SHROUD REPLACEMENT REPAIR	-	4435
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package S			-	3570
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package S	018	SILICONE RUBBER INNER AIRSEAL REPAIR	-	3570
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package SB00			-	10075
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package SB00	PW4G-100-72-119	REPLACEMENT OR MODIFICATION OF LPC STATOR ASSY 1.6 - 3 STG 1.3 & 4.TH STG DUCT RUBBER	-	10075
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package SB01			-	8395
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package SB01	PW4G-100-72-189	REPLACEMENT OR MODIFICATION TO INCORPORATE IMPROVED INNER SHROUD RUBSTRIPS	-	8395
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package T			-	3020
72-31-20	PW4000	139785	30	28	53B013-001 53B013-01 54B613-001 54B613-01 56B713-01	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1.3 COMPRESSOR STATOR ASSEMBLY - 100"	Package T	009	VANE REPLACEMENT	-	3020
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package A			-	70
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	70
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package B			-	80
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package B	001	BLEND REPAIR	-	80
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package C			-	135
72-31-21	PW4000	139758	23	28	50B862	LOW PRESSURE COMPRESSOR (LPC) - INSERT - 100"	Package C	002	REPLACE SILICONE RUBBER SEAL	-	135
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package A			-	395
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	395
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package C			-	500
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package C	003	LOOSE OR DAMAGED CLINCH NUT REPLACEMENT REPAIR	-	500
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package D			-	1455
72-31-28	PW4000	138662	30	28	50B245-01	LOW PRESSURE COMPRESSOR (LPC) - NO. 1 BEARING SEAL SUPPORT ASSEMBLY	Package D	005	OUTER MATING DIAMETER PLASMA COAT REPAIR	(TITANIUM PART)	1455

72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package A					760
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		760
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package D					3970
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package D	003	CLINCH NUT REPLACEMENT	-		3970
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package E					2495
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package E	004	OUTER MATING DIAMETER PLASMA COAT	ALUMINIUM PART		2495
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package F					2720
72-31-28	PW4000	673662	6	28	50B198 50B770	PW4 #1 BEARING SEAL SUPPORT ASSY	Package F	005	OUTER MATING DIAMETER PLASMA COAT	TITANIUM PART		2720
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package A					355
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		355
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package AN					180
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package AN	-	MARKING OF PART IF P/N AND/OR S/N IS ILLEGIBLE	SPM TASK 70-11-00-800-001-001		180
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package B					2135
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package B	001	REPLACE COMPRESSOR INLET CONE FRONT SEGMENT PROTECTIVE FINISH	-		2135
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package C					1865
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package C	002	REPAIR COMPRESSOR INLET CONE FRONT SEGMENT SURFACE DAMAGE	-		1865
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package SB00					480
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package SB00	PW4ENG 72-619	INLET COMP. FRONT CONE SEGMENT REPL.	-		480
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package SB01					480
72-31-80	PW4000	22404	22	28	794629	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE FRONT SEGMENT	Package SB01	PW4G-100-72-70	INLET CONE SEGMENT: P/N 794629 TO 51A760	-		480
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package A					295
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package A	CLN/INSP	CLEANING AND INSPECTION	-		295
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package C					760
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package C	002	LOCAL REPAIR OF SURFACE DAMAGE	-		760
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package D					1705
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package D	003	LOCAL REPAIR OF PROTECTIVE SURFAC	-		1705
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package SB00					380
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package SB00	PW4ENG 72-619	INLET COMP. FRONT CONE SEGMENT REPL.	-		380
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package SB01					360
72-31-80	PW4000	670946	6	28	51A681 51A760	PW4 COVER FOR CONESEGMET	Package SB01	PW4G-100-72-70	INLET CONE SEGMENT: P/N 794629 TO 51A681	-		360
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package A					1385
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		1385
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package AN					80
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package AN	-	MARKING OF PART IF P/N AND/OR S/N IS ILLEGIBLE	SPM TASK 70-11-00-800-001-001		80
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package B					2980
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package B	001	REPLACE INLET CONE SEAL REPAIR	-		2980
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package B	01A	REAR SEAL REPLACEMENT REPAIR	-		2980
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package B	01B	REAR SEAL REPLACEMENT REPAIR	-		2980
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package B	01C	REAR SEAL REPLACEMENT REPAIR	-		2980
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package C					3880

72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package C	002	REPLACE PROTECTIVE FINISH (COMPLETE REPLACEMENT)	-		
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package C	004	REPAIR SURFACE DAMAGE	-	3880	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package D				835	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package D	003	REPLACE NUT PLATE	-	835	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package F				3880	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package F	005	REPAIR TRAILING EDGE DELAMINATION	-	3880	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package H				5165	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package H	007	AXIAL CRACK REPAIR	-	5165	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package I				1050	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package I	008	HEAT INLET CONE TO REMOVE MOISTURE	-	1050	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package K				3200	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package K	010	DELAMINATION REPAIR	-	3200	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package L				1175	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package L	ASSEMBLY-01	BALANCE CONE SEGMENT ACC. EM 72-31-81 ASSEMBLY 01	-	1175	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package N				2720	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package N	013	PROTECTIVE COATING - TOUCH UP REP	-	2720	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB00				1175	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB00	PW4G-100-72-217	MODIFICATION OF TO INCORPORATE A NEW SEAL TO MINIMIZE LEAKAGE FOR INCREASED ENGINE PERFORMANCE	-	1175	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB01				1140	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB01	PW4ENG 72-792	MODIFICATION OF TO INCORPORATE A NEW SEAL WITH IMPROVED RETENTION FOR INCREASED DURABILITY	-	1140	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB02				165	
72-31-81	PW4000	22465	36	28	51A043-001 51A045 51A045-002 51A112-01 51A609-01 51A709-01 52A112-01 52A517-01 52A523-01	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR INLET CONE (REAR) SEGMENT ASSEMBLY	Package SB02	PW4ENG 72-629	MODIFICATION OF TO PROVIDE A CONE ASSY	-	165	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package A				165	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	PN55A221-001 FOR SHOP VISIT ONLY	165
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package C				95	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package C	010	MOMENT WEIGHT ADJUSTMENT	-	95	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package C	INSP/CHK-05	MOMENT WEIGH BLADE ASSEMBLY	-		
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package SB00				180	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package SB00	PW4G-100-1-99	LUBRICATION OF THE 1ST STAGE LPC BLADE ASSEMBLY (FAN BLADE) ROOT	-		
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package SB00	PW4G-100-72-150	ULTRASONIC INSPECTION OF THE BLADE ROOT ATTACHMENT AREA FOR CRACKS	-	180	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package SB01				90	
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package SB01	PW4G-100-72-175	MODIFICATION OF TO INCORPORATE A MORE DURABLE BLADE ROOT COATING	-	90	

72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package S802					90
72-31-82	PW4000	139853	23	28	55A221 55A221-001 55A221-002 57A721 57A821	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE ASSEMBLY 100"	Package S802	PW4G-100-72-101	REPL. OF OR MODIFICATION OF TO REDEFINE THE GROOVE IN PLATFORM UPPER SURFACE	-		90
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package A					165
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package A	CLN/INSP	CLEANING AND INSPECTION		PN57A721-001 FOR SHOP VISIT ONLY	165
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package B					110
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package B	INSP/CHK-05	MOMENT WEIGH BLADE ASSEMBLY	-		110
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package S800					110
72-31-82	PW4000	663222	11	28	55A221-003 55A221-004 57A721-001 57A821-001 58A121	LOW PRESSURE COMPRESSOR (LPC) - STAGE 1 LPC BLADE SINGLE	Package S800	PW4G-100-199	LUBRICATION OF THE 1ST STAGE LPC BLADE ASSEMBLY (FAN BLADE) ROOT	-		110
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package A					285
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		285
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package B					340
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package B	001	REPLACE ANTIROTATION PIN	-		340
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package C					1210
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package C	002	RESTORE NICKEL CADMIUM PLATING	-		1210
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package D					4400
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package D	003	PWA 595 ALUMINUM COATING REPAIR	-		4400
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package E					135
72-31-83	PW4000	139672	31	28	50A526 51A480 52A078 52A079	LOW PRESSURE COMPRESSOR (LPC) - COMPRESSOR BLADE (STAGE 1) LOCK ASSEMBLY	Package E	INSP-03	INSP/CHECK-03 BLEND SURFACE DAMAGE	-		135
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package A					620
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package A	CLN/INSP	CLEANING AND INSPECTION	-		620
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package AN					140
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package AN	-	PART- AND SERIALNUMBER MARKING	-		140
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package B					685
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package B	001	REPLACE FAN EXIT FAIRING ANTIGALLING COMPOUND	-		685
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package C					1410
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package C	002	PUNCTURE REPAIR FAN EXIT FAIRING	-		1410
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package D					1655
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package D	003	REPAIR CHIPPED, ABRADED OR DELAMINATED FAN EXIT FAIRING	-		1655
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package G					3030
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package G	005	TOUCH-UP FAN EXIT FAIRING PROTECTIVE COATING	-		3030
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package G	006	REPLACE PROTECTIVE LAYER REPAIR	-		685
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package I					685
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package I	008	INSIDE DIAMETER SURFACE ABRASION REPAIR	-		2155
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package K					2155
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package K	010	REPLACE DAMAGED LEADING EDGE SHIELD	-		755
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package L					755
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package L	011	LEADING EDGE EROSION (HOLE) REPAIR	-		755
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package L	011	LEADING EDGE FILLER REPAIR	-		755
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package L	011	METAL SHIELD BUT JOINT GAP REPAIR	-		2005
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package M					2005
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package M	012	CRUSHED REAR EDGE REPAIR	-		885
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package S					885
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package S	018	LEADING EDGE SHIELD INNER LIP DISBOND REPAIR	-		885

72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package SB00					4375
72-31-84	PW4000	139732	31	28	50A178 50A786-01 51A541-01 51A627-01 51A630-01 51A754-01	LOW PRESSURE COMPRESSOR (LPC) - FAN EXIT FAIRING	Package SB00	PW4ENG 72-296	MODIF OF LEADING EDGE	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package A					900
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package B					815
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package B	001	REPLACE ANTIGALLANT	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package C					4630
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package C	002	PLASMA SPRAY TURBINE SHAFT COUPLING NO. 1.5 BEARING SPACER JOURNAL	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package D					4825
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package D	003	PLASMA SPRAY TURBINE SHAFT COUPLING NO. 1.5 BEARING JOURNAL	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package E					4450
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package E	004	PLASMA SPRAY TURBINE SHAFT COUPLING FAN HUB SHOULDER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package F					4175
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package F	005	PLASMA SPRAY TURBINE SHAFT COUPLING FAN HUB FRONT PILOT DIAMETER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package G					5080
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package G	006	FRONT PILOT DIAMETER PLASMA COAT REPAIR	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package H					5755
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package H	007	PLASMA SPRAY TURBINE SHAFT COUPLING NUT PILOT DIAMETER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package I					3455
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package I	008	PLASMA SPRAY TURBINE SHAFT COUPLING FAN HUB REAR PILOT DIAMETER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package J					4010
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package J	009	PLASMA SPRAY TURBINE SHAFT COUPLING REAR PILOT DIAMETER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package K					5800
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package K	010	PLASMA SPRAY TURBINE SHAFT COUPLING MOTION PICKUP DIAMETER	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package L					505
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package L	011	REPLACE TURBINE SHAFT COUPLING ASSEMBLY MOTION PICKUP WHEEL	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package M					1310
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package M	012	BLEND REPAIR	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package N					1650
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package N	013	FAN HUB SHOULDER PLASMA COAT REPAIR	FRONT		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package O					1380
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package O	014	PLASMA SPRAY REPAIR	-		
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package P					1650
72-32-01	PW4000	139728	35	28	50A281 51A275	LPC/LPT COUPLING - TURBINE SHAFT COUPLING ASSEMBLY	Package P	015	FAN HUB SHOULDER PLASMA COAT REPAIR	REAR		
72-32-02	PW4000	135955	23	28	50A022 50A092 50A093 50A696 51A653	LPC/LPT COUPLING - NO. 1.5 ROLLER BEARING	Package A					750
72-32-02	PW4000	135955	23	28	50A022 50A092 50A093 50A696 51A653	LPC/LPT COUPLING - NO. 1.5 ROLLER BEARING	Package A	CLN/INSP	CLEANING AND INSPECTION	-		
72-32-03	PW4000	137792	18	28	50A221	LPC/LPT COUPLING - NO. 1.5 BEARING SEAL SEAT	Package A					135
72-32-03	PW4000	137792	18	28	50A221	LPC/LPT COUPLING - NO. 1.5 BEARING SEAL SEAT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		
72-32-04	PW4000	137368	26	28	50A222	LPC/LPT COUPLING - NO. 1.5 BEARING (INNER RACE) RETAINING NUT	Package A					710
72-32-04	PW4000	137368	26	28	50A222	LPC/LPT COUPLING - NO. 1.5 BEARING (INNER RACE) RETAINING NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		
72-32-04	PW4000	137368	26	28	50A222	LPC/LPT COUPLING - NO. 1.5 BEARING (INNER RACE) RETAINING NUT	Package B					610
72-32-04	PW4000	137368	26	28	50A222	LPC/LPT COUPLING - NO. 1.5 BEARING (INNER RACE) RETAINING NUT	Package B	001	ANTIGALLANT REPLACEMENT	-		
72-32-80	PW4000	135966	30	28	50A593	LPC/LPT COUPLING - TURBINE SHAFT (COUPLING RETAINING) NUT	Package A					540
72-32-80	PW4000	135966	30	28	50A593	LPC/LPT COUPLING - TURBINE SHAFT (COUPLING RETAINING) NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		

72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package SB00	PWAENG 72-39	LPC, 4TH STAGE, AND, CASE ASSEMBLY, FAN EXIT, INNER - MODIFICATION OF OD SNAP DIAMETERS	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package SB01	PWAENG 72-346	REPLACEMENT OF OR MODIFICATION OF	TO INCORPORATE BOLTED - ON BELL CRANK BRACKET	790
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package SB02				10800
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package SB02	PWAENG 72-660	MODIF.OF.TO INCORP. NEW 2.5 BLD ROLLER CAM FOLLOWERS, STEEL CAM FOLLOWER SLOT LINERS, & BEARING PADS	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package T	025	REPAIR THE ABLATIVE COATING	-	1520
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package U				3335
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package U	027	WELD THE CAM SLOTS IN THE BLEED VALVE DUCT	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package V				2015
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package V	028	REPAIR DAMAGED FIRE ABLATIVE COATING WITH FIRE ABLATIVE BLANKETS	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package W				5425
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package W	029	WELD CRACKS AND RECONTOUR THE GUSSETS IN THE BLEED VALVE DUCT	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package X				2195
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package X	042	REPAIR DAMAGED FOIL ON THE FIRE ABLATIVE BLANKETS	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package Y				1805
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package Y	044	FRONT INNER CASE (NEW) REPLACEMENT REPAIR	-	
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package Z				910
72-33-04	PW4000	138252	35	35	50D373-007 50D628-003 50D628-01 50D630-003 50D937-003 50D937-01 52D286-01 53D515-01 53D924-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 94"	Package Z	045	REPLACE LINER REPAIR	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package A				2320
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AE	048	BENT SPLITTER FAIRING FLANGE REPAIR	-	990
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AJ				555
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AJ	068	CASE WALL INNER DIAMETER BLEND REPAIR	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AL				555
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AL	069	BLEND OR REAM REAR FLANGE BOLTHOLE	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AM				560
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package AM	070	BLEND OR REAM SPLITTER FAIRING FLANGE BOLTOLES	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package B				330
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package B	014	TOUCH UP ANODIZE	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package C				1120
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package C	030	REPLACE THE FAN EXIT INNER CASE GUIDE VANE PIN RIVET AND COLLAR	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package D				860
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package D	031	SCREEN REPLACEMENT	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package E				1520
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package E	032	REPLACE RUBBER SEAL	-	
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package E	060	REPLACE RUBBER SEAL	-	1520
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package F				350
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package F	033	REPLACE LPC STATOR NUT PLATES	-	350
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package G				330
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package G	034	REPLACE LPC SPLITTER FAIRING NUT OPTION	-	330
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package H				540
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package H	035	REPLACE FRONT ANGLE GANG NUT ASSEMBLIES	-	540
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package I				540
72-33-04	PW4000	139739	32	35	50D757 51D627 51D628 51D629 51D703 51D705 51D986 52D321-001 52D321-01 52D618-001 52D618-01 54D078-01	FAN CASE - FAN EXIT INNER CASE ASSEMBLY - 100"	Package I	036	REPLACE THE ANGLE GANG NUT ASSEMBLY NUT PLATES	-	540

72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package I	008	REPLACE DAMAGED INSULATION BLANKETS	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package J				565
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package J	009	REPAIR DAMAGED INSULATION BLANKETS	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package K				495
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package K	010	REPLACE ANTIGALLANT COMPOUND REPAIR	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package L				650
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package L	011	BLEND REPAIR	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package M				3905
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package M	012	CAM SLOT TAB OUTSIDE DIAMETER REPAIR	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package N				1230
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package N	013	REPLACE LINER REPAIR	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package O				1945
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package O	014	WELD A CRACKED OR OVERSIZED CAM SLOT LINER RIVET HOLE	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package P				2720
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package P	015	WELD AN OVERSIZED BEARING PAD RIVET HOLE	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package Q				1240
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package Q	016	REPAIR DAMAGED FOIL ON THE FIRE ABLATIVE BLANKETS	-	
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package Q	017	REPAIR DAMAGED FOIL ON THE FIRE ABLATIVE BLANKETS	-	1240
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package SB00				3290
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package SB00	PW4G-100-72-67	REPLACEMENT OF OR MODIFICATION OF THE BEARING PADS	-	3290
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package SB01				2625
72-33-08	PW4000	139749	27	28	51D998-001 53D062-01 53D539-01	FAN CASE - BLEED VALVE DUCT ASSEMBLY - 100"	Package SB01	PW4G-100-72-112	SLOT LINER MODIFICATION	-	2625
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package A				790
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	790
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package B				735
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package B	001	ANODIZE TOUCH-UP	-	735
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package C				1485
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package C	002	REPLACE RUBBER SEAL	-	1485
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package E				2035
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package E	004	RESTORE TEFLON COATING	-	2035
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package F				1020
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package F	005	REPLACE BUSHINGS	-	1020
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package G				1890
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package G	006	HOLE REPAIR	-	1890
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package H				1400
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package H	007	BLEND REPAIR	-	1400
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package SB00				880
72-33-09	PW4000	137762	32	28	50D151 50D151-001 52D300 53D296	FAN CASE - BLEED VALVE ASSEMBLY - 94"	Package SB00	PW4ENG 72-660	MODIFICATION OF THE 2.5 BLEED CAM FOLLOWER SLOTS	-	880
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package A				795
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	795
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package B				735
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package B	001	ANODIZE TOUCH-UP	-	735
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package H				460
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package H	007	BLEND REPAIR	-	460
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package I				1465
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package I	008	REPLACE SILICONE RUBBER SEAL	-	1465
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package J				1885
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package J	009	HOLE REPAIR	-	1885
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package L				2030
72-33-09	PW4000	139722	31	28	50D461 53D546	FAN CASE - BLEED VALVE ASSEMBLY - 100"	Package L	011	REPLACE TEFLON COATING	-	2030

72-34-01	PW4000	137716	45	28	50G849 50G849-001 50G918 50G918-001 50G918-005 51G021 51G021-001 51G021-005 51G344 51G344-001 51G478 51G478-001 51G533 51G533-001 51G538 51G538-001 51G538-003 51G699-002 51G699-003 52G052-006 52G052-01 52G057 52G057-001 52G058 52G059 52G059-002 52G060 52G060-002 52G133 52G139-01 52G142-001 52G147-01 52G148 52G149 52G209 52G209-002 52G210-001 52G210-002 52G456 52G456	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 94"	Package Z	041	APPLY ANODIZE TOUCH-UP SOLUTION	-	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package A			340	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package B			845	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package B	001	PATCH REPAIR	FLOUROELASTOMER	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package B	001	PATCH REPAIR	ORGANIC FIBRE	845
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package E			845	
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package E	004	PATCH REPAIR	EPOXY	845
72-34-01	PW4000	137835	4	28	50G533 50G534 51G546-01 51G547-01 51G685-01 51G686-01 51G686-01 51G831-01 51G832-01 51G867-01 51G869-01 51G869-01 52G046-01 52G047-01 52G048-01 52G049-01 52G241 52G242 52G243 52G244 52G374 52G375	PW4 FAIRING TO STRUT ON INTERMEDIATE CASE	Package E	004	PATCH REPAIR	FLOUROELASTOMER	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package A				450
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package B				845
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package B	044	BLEND SURFACE DAMAGE ON THE FAN EXIT CASE FLANGE ASSEMBLY	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package C				740
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package C	050	MAKE STRAIGHT AND BLEND THE FAN EXIT CASE FLANGE	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package D				685
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package D	096	TOUCH UP FAN EXIT CASE FLANGE ASSEMBLY PROTECTION LAYER REPAIR	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package E				815
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package E	097	FAN EXIT CASE FLANGE ASSEMBLY NUT PLATE REPLACEMENT	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package F				685
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package F	098	FAN EXIT CASE FLANGE ASSEMBLY ANTI-GALLANT REPAIR	-	
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package G				1890
72-34-01	PW4000	138663	30	28	50G439 51G232 51G233 51G447 52G113-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 94"	Package G	117	PLASMA SPRAY REPAIR FLANGE D1 SURFACE	-	
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package A				105
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package B				305
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package B	100	STOP DRILL FAIRING COVER CRACKS	-	
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package C				1050
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package C	101	REPLACEMENT OF FAN EXIT FAIRING	-	
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package D				90
72-34-01	PW4000	139579	10	28	51G470 51G472 51G487 51G488	PW4 (94") COVER ASSY OF FAN EXIT CASE ASSEMBLY	Package D	SPM	REPLACE STOPS ACC. SPM	-	
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package A				1185
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package AA				1565
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package AA	067	BAFFLE REPLACEMENT REPAIR	-	
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package AA	068	REPLACE THE FRONT FAN EXIT CASE BRACKET ASSEMBLIES	-	1565
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package AA	070	REPLACE THE CENTER FAN EXIT CASE BRACKET ASSEMBLIES	-	
72-34-01	PW4000	139752	44	28	51D653-001 51D653-003 51D653-004 51D653-01 51D653-201 52D348-001 52D348-002 52D348-003 52D348-004 52D348-005 52D348-006 52D348-01 52D348-010 52D348-101 52D348-201 52D348-401 52D348-501 54D028-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - 100"	Package AA	112	REPLACE THE FAN EXIT CASE MID FLANGE BRACKETS	-	1565

72-34-01	PW4000	140266	24	28	51D742-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 100"	Package D	091	NUT PLATE REPLACEMENT	-	810
72-34-01	PW4000	140266	24	28	51D742-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 100"	Package E				685
72-34-01	PW4000	140266	24	28	51D742-01	INTERMEDIATE CASE - COMPRESSOR INTERMEDIATE CASE ASSEMBLY - FLANGE - 100"	Package E	092	ANTIGALLANT COMPOUND REPLACEMENT	-	685
72-34-01	PW4000	667758	4	28	51D378-01 51D379-01 51G917-01 51G918-01 51G919-01 51G920-01 51G921-01 51G922-01 51G924-01 51G925-01 51G926-01 51G927-01 51G928-01 52G519-01 52G520-01 52G522-01 52G523-01 52G524-01 52G525-01 52G531-01 52G532-01 52G533-01 52G534-01 52G535-01 52G550-01	FAN EXIT CASE BRACKET ASSEMBLY	Package A			315	
72-34-01	PW4000	667758	4	28	51D378-01 51D379-01 51G917-01 51G918-01 51G919-01 51G920-01 51G921-01 51G922-01 51G924-01 51G925-01 51G926-01 51G927-01 51G928-01 52G519-01 52G520-01 52G522-01 52G523-01 52G524-01 52G525-01 52G531-01 52G532-01 52G533-01 52G534-01 52G535-01 52G550-01	FAN EXIT CASE BRACKET ASSEMBLY	Package A	CLN/INSP	Cleaning and inspection	-	315
72-34-01	PW4000	667758	4	28	51D378-01 51D379-01 51G917-01 51G918-01 51G919-01 51G920-01 51G921-01 51G922-01 51G924-01 51G925-01 51G926-01 51G927-01 51G928-01 52G519-01 52G520-01 52G522-01 52G523-01 52G524-01 52G525-01 52G531-01 52G532-01 52G533-01 52G534-01 52G535-01 52G550-01	FAN EXIT CASE BRACKET ASSEMBLY	Package B			425	
72-34-01	PW4000	667758	4	28	51D378-01 51D379-01 51G917-01 51G918-01 51G919-01 51G920-01 51G921-01 51G922-01 51G924-01 51G925-01 51G926-01 51G927-01 51G928-01 52G519-01 52G520-01 52G522-01 52G523-01 52G524-01 52G525-01 52G531-01 52G532-01 52G533-01 52G534-01 52G535-01 52G550-01	FAN EXIT CASE BRACKET ASSEMBLY	Package B	SPM	REPLACE NUT PLATES ACCORDING SPM	-	425
72-34-01	PW4000	672785	4	28	52G530-01	FAN EXIT CASE BRACKET ASSEMBLY	Package A				360
72-34-01	PW4000	672785	4	28	52G530-01	FAN EXIT CASE BRACKET ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	360
72-34-01	PW4000	672785	4	28	52G530-01	FAN EXIT CASE BRACKET ASSEMBLY	Package B				270
72-34-01	PW4000	672785	4	28	52G530-01	FAN EXIT CASE BRACKET ASSEMBLY	Package B	SPM	REPLACE NUTPLATES	-	270
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package A				360
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	360
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package B				660
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package B	001	TOUCH UP PROTECTION LAYER	-	660
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package C				940
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package C	002	NUT PLATE REPLACEMENT	-	940
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package D				990
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package D	003	SMOOTH SURFACE DAMAGE	-	990
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package E				670
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package E	004	REPLACE ANTI-GALLANT COMPOUND	-	670
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package H				2095
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package H	007	FAN EXIT GUIDE VANE FLANGE PLASMA COAT REPAIR	-	2095
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package I				500
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package I	008	NUT PLATE REPLACEMENT REPAIR	-	500
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package J				430
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package J	009	SURFACE DAMAGE REPAIR	-	430
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package K				660
72-34-02	PW4000	137852	30	28	50G342 52G112-01 53D717-01	INTERMEDIATE CASE - FAN EXIT CASE FLANGE ASSEMBLY	Package K	010	ANTIGALLING COMPOUND REPLACEMENT REPAIR	-	660
72-34-04	PW4000	665041	4	28	51D765	SEAL ASSY BRG.2	Package A				360
72-34-04	PW4000	665041	4	28	51D765	SEAL ASSY BRG.2	Package A	ASSEMBLY	ASSEMBLE SEAL ASSEMBLY	-	360
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package A				435
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	435
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package B				685
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package B	001	PIN REPLACEMENT REPAIR	-	685
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package C				1185
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package C	002	REPLACE HELICOIL INSERT	-	1185
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package E				3610
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package E	004	PLASMA SPRAY THE INTERMEDIATE CASE SNAP DIAMETER	-	3610
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package F				6560
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package F	005	REPAIR THE DAMPER JOURNAL WITH A BUSHING	-	6560
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package J				400
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package J	009	SURFACE DAMAGE BLEND REPAIR	-	400
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package K				685
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package K	010	OVERSIZED PIN REPLACEMENT REPAIR	-	685
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package P				3980
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package P	005	CHROME PLATE BUSHING	-	3980
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package SB00				935
72-34-06	PW4000	137641	36	28	50G417 51D766 51G082 51G250	INTERMEDIATE CASE - NO. 2 BEARING SUPPORT ASSEMBLY	Package SB00	PWAENG 72- 179	BEARINGS FRT REPLACEMENT OF OIL TUBES AND SEALS	-	935

72-34-16	PW4000	650957	13	28	51G253	HPC SHROUD 5.5TG RETAINING RING	Package B				1455
72-34-16	PW4000	650957	13	28	51G253	HPC SHROUD 5.5TG RETAINING RING	Package B	001	SHROUD RETAINING RING OUTER LUG FRONT FACE PLASMA COAT REPAIR	-	1455
72-34-16	PW4000	650957	13	28	51G253	HPC SHROUD 5.5TG RETAINING RING	Package D				530
72-34-16	PW4000	650957	13	28	51G253	HPC SHROUD 5.5TG RETAINING RING	Package D	INSP/CHK-03	VISUAL INSPECTION	-	530
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package A				385
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	385
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package C				1910
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package C	008	PLASMA SPRAY REAR SNAP DIAMETER BY (PWA 53-13 OR PWA 53-38)	-	1910
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package E				570
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package E	004	REPLACE CLINCH NUTS	-	570
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package F				570
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package F	005	REPLACE HELICAL COIL INSERTS	-	570
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package G				2925
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package G	010	UPPER BEARING JOURNAL BUSHING REPAIR	-	2925
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package SB00				1700
72-34-20	PW4000	137727	33	28	51D747 51D747-001 53D316	INTERMEDIATE CASE - NO. 1.5 BEARING SUPPORT ASSEMBLY	Package SB00	PW4ENG A72-656	INSPECTION OF THE SUPPORT FOR A THIN WALL CONDITION	-	1700
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package A				490
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package A	CLN/INSP	CLEANING AND INSPECTION	-	490
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package C				1875
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package C	002	PLASMA SPRAY REAR SNAP DIAMETER	-	1875
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package D				1965
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package D	003	PLASMA SPRAY No.1.5 BEARING JOURN	-	1965
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package E				300
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package E	004	REPLACE CLINCH NUTS	-	300
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package F				155
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package F	005	REPLACE HELICAL COIL INSERTS	-	155
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB00				1995
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB00	PW4G-100-A72-10	INSPECTION OF THE SUPPORT FOR A THIN WALL CONDITION	-	1995
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB01				70
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB01	PW4ENG 72-789	INSPECTION FOR DUPLICATE SERIAL NUMBERS ON BEARING SUPPORTS	-	70
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB02				70
72-34-20	PW4000	673659	5	28	50A182	PW4 BRG 1.5 BEARING SUPPORT ASSEMBLY ST	Package SB02	PW4ENG 72-678	INSPECTION OF TO IDENTIFY CERTAIN THAT MUST BE REMOVED FROM SERVICESUPPORTS	-	70
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package A				535
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	535
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package B				1135
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package B	001	CHROMIUM PLATE OR COAT REPAIR UPPER BEARING JOURNAL	-	1135
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package C				1800
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package C	002	CHROMIUM PLATE OR COAT LOWER BEARING JOURNAL	-	1800
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package D				600
72-34-21	PW4000	137845	25	28	50A017	INTERMEDIATE CASE - GEARBOX DRIVE BEVEL GEARSHAFT	Package D	003	SMOOTH OUT DAMAGE TO THE SURFACE	-	600
72-34-22	PW4000	137822	17	28	50G405 50G406 50G407 50G634 51G986 51G987 51G988 51G989	INTERMEDIATE CASE - GEARSHAFT ROLLER BEARING	Package A				355
72-34-22	PW4000	137822	17	28	50G405 50G406 50G407 50G634 51G986 51G987 51G988 51G989	INTERMEDIATE CASE - GEARSHAFT ROLLER BEARING	Package A	CLN/INSP	CLEANING AND INSPECTION	-	355
72-34-23	PW4000	137756	22	28	50A045 50A048 50G635 51G990 51G991 51G992	INTERMEDIATE CASE - GEARSHAFT BALL BEARING	Package A				485
72-34-23	PW4000	137756	22	28	50A045 50A048 50G635 51G990 51G991 51G992	INTERMEDIATE CASE - GEARSHAFT BALL BEARING	Package A	CLN/INSP	CLEANING AND INSPECTION	-	485
72-34-24	PW4000	652105	4	28	616464	PW4 COUPLING, GEARBOX DRIVESHAFT	Package A				290
72-34-24	PW4000	652105	4	28	616464	PW4 COUPLING, GEARBOX DRIVESHAFT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	290
72-34-25	PW4000	137371	25	21	50A353	INTERMEDIATE CASE - MAIN BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package A				435

72-34-25	PW4000	137371	25	21	50A353	INTERMEDIATE CASE - MAIN BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	435
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package A				220
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	220
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package B				305
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package B	001	PIN REPLACEMENT	-	305
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package C				275
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	275
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package D				300
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package D	003	REPLACE HELI-COIL INSERT	-	300
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package E				1315
72-34-27	PW4000	137742	28	21	50A313 50A691	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING TUBE CONNECTOR ASSEMBLY	Package E	004	BUSHING REPLACEMENT REPAIR	-	1315
72-34-29	PW4000	671176	5	28	50A317	PW4 OIL NOZZLE ASSEMBLY BRG NO. 1.5	Package A				250
72-34-29	PW4000	671176	5	28	50A317	PW4 OIL NOZZLE ASSEMBLY BRG NO. 1.5	Package A	CLN/INSP	Cleaning and inspection	-	250
72-34-30	PW4000	137372	9	28	50A609 52A022-01	PW4 NOZZLE OF #2 BEARING (100°)	Package A				650
72-34-30	PW4000	137372	9	28	50A609 52A022-01	PW4 NOZZLE OF #2 BEARING (100°)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	650
72-34-30	PW4000	137372	9	28	50A609 52A022-01	PW4 NOZZLE OF #2 BEARING (100°)	Package SB00				350
72-34-30	PW4000	137372	9	28	50A609 52A022-01	PW4 NOZZLE OF #2 BEARING (100°)	Package SB00	72-116	BRG 1.5/2, MODIFICATION FOR LESS WEAR	-	350
72-34-31	PW4000	655320	9	21	51G085 51G449	OIL PRESSURE TUBE OF GEARBOX	Package A				595
72-34-31	PW4000	655320	9	21	51G085 51G449	OIL PRESSURE TUBE OF GEARBOX	Package A	CLN/INSP	CLEANING AND INSPECTION	-	595
72-34-32	PW4000	671157	4	28	50A614	PW4 GEARBOX DRIVE (OIL) NOZZLE ASSEMBLY	Package A				340
72-34-32	PW4000	671157	4	28	50A614	PW4 GEARBOX DRIVE (OIL) NOZZLE ASSEMBLY	Package A	CLN/INSP	Cleaning and inspection	-	340
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package A				245
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	245
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package B				1440
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package B	001	SURFACE DAMAGE BLEND REPAIR	-	1440
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package C				1305
72-34-34	PW4000	1715	27	28	583887	INTERMEDIATE CASE - NO. 3 TOWER SHAFT BEARING RETAINING NUT	Package C	002	SILVER PLATE REPAIR	-	1305
72-34-35	PW4000	665040	4	28	51G175	CARBON SEAL ASSEMBLY BRG.1.5/2	Package A				315
72-34-35	PW4000	665040	4	28	51G175	CARBON SEAL ASSEMBLY BRG.1.5/2	Package A	ASSEMBLY	ASSEMBLE SEAL ASSEMBLY	-	315
72-34-36	PW4000	636094	20	28	50A220 51G096 51G176 52G379	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING SEAL SUPPORT ASSEMBLY	Package A				240
72-34-36	PW4000	636094	20	28	50A220 51G096 51G176 52G379	INTERMEDIATE CASE - NO. 1.5 AND 2 BEARING SEAL SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	240
72-34-38	PW4000	137548	2	21	50A141 50A263 50A265 51G178 51G178-001 51G180 51G180-001 51G181 51G181-002 51G181P5 51G188 51G942 51G943 52G388 53G017 53G018 53G023-01 53G024-01 53G024-101 53G025 53G026 53G027 53G028-01 53G028-101 53G037 53G038 53G040 53G043-01 53G044-01	PW4 NO.1.5 BEARING FACE SEAL ASSEMBLY	Package A				195
72-34-38	PW4000	137548	2	21	50A141 50A263 50A265 51G178 51G178-001 51G180 51G180-001 51G181 51G181-002 51G181P5 51G188 51G942 51G943 52G388 53G017 53G018 53G023-01 53G024-01 53G024-101 53G025 53G026 53G027 53G028-01 53G028-101 53G037 53G038 53G040 53G043-01 53G044-01	PW4 NO.1.5 BEARING FACE SEAL ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	195
72-34-38	PW4000	655303	5	28	50A688 51G971	PW4 CONNECTOR TO MAIN BEARING	Package A				1020
72-34-38	PW4000	655303	5	28	50A688 51G971	PW4 CONNECTOR TO MAIN BEARING	Package A	CLN/INSP	CLEANING & INSPECTION	-	1020
72-34-42	PW4000	137370	24	21	50A357	INTERMEDIATE CASE - MAIN BEARING (OUTER) SCAVENGE TUBE ASSEMBLY	Package A				270
72-34-42	PW4000	137370	24	21	50A357	INTERMEDIATE CASE - MAIN BEARING (OUTER) SCAVENGE TUBE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	270
72-34-43	PW4000	655319	6	21	50A290 51A363-01	SCAVENGE TUBE ASSY OF MAIN BEARING	Package A				1170
72-34-43	PW4000	655319	6	21	50A290 51A363-01	SCAVENGE TUBE ASSY OF MAIN BEARING	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1170
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package A				775

72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-		775
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package AC					1815
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package AC	020	SEALANT TOUCH-UP REPAIR	-		1815
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package B					560
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package B	001	TOUCH-UP PROTECTIVE COATING	-		560
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package C					595
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package C	002	REPLACE PIN	-		595
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package D					1340
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package D	003	BLEND STATOR VANES REPAIR	REP.01 INCLUDED		1340
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package G					3205
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package G	006	WELD THE LUGS ON THE OUTER SHROUD	REP.01 INCLUDED		3205
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package H					6940
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package H	007	REPLACE VANES	-		6940
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package K					1545
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package K	008	SMOOTH DAMAGE ON THE INNER SHROUD LUGS	REP.01 INCLUDED		1545
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package O					4580
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package O	009	REPLACE VANES	-		4580
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package R					1400
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package R	010	BLEND STATOR VANES (TITANIUM) REPAIR	-		1400
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package SB00					1240
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package SB00	PW4ENG 72-819	REPLACEMENT OR MODIFICATION OF, TO INCORPORATE A BOLT LOCKING FEATURE	-		1240
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package SB01					270
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package SB01	PW4ENG 72-454	IMPROV.TI-INNER SHROUD	-		270
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package U					4175
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package U	014	VANE RUBBER REPAIR	SEAL INNER SHROUD VANE		4175
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package V					3890
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package V	014	VANE RUBBER REPAIR	SEAL OUTER SHROUD VANE		3890
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package W					855
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package W	015	BLEND THE OUTER SHROUD SURFACE DAMAGED	-		855
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package X					695
72-34-50	PW4000	137547	32	28	51G174 51G174-002 51G774 51G774-001 51G874 51G874-001 52G274 53G074	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 94"	Package X	018	REMOVAL OF REMAINING CORROSION REPAIR	-		695
72-34-50	PW4000	139734	33	28	51D874-01 53G174	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 100"	Package A					780
72-34-50	PW4000	139734	33	28	51D874-01 53G174	INTERMEDIATE CASE - FOURTH STAGE COMPRESSOR STATOR ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-		780

72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	455
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package B				500
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package B	001	ANODIZE TOUCH-UP	-	500
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package B	INSP-03	BLEND REPAIR	-	
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package C				860
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package C	002	OIL PRESSURE MANIFOLD SUPPORT BRACKET REPLACEMENT	-	
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package G				1080
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package G	006	OIL PRESSURE MANIFOLD SUPPORT BRACKET BUSHING REPLACEMENT	-	
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package Q				550
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package Q	016	BOLT HOLE BLEND REPAIR	-	
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package R				1115
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package R	017	REPAIR FRONT FLANGE BOLT HOLES	-	
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package S				1115
72-34-81	PW4000	137373	30	28	50A566 50A639 50A640	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 94"	Package S	018	REPAIR REAR FLANGE BOLT HOLES	-	
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package A				450
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package B				500
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package B	001	ANODIZE TOUCH-UP	-	
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package B	INSP-03	BLEND REPAIR	-	500
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package C				855
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package C	007	OIL PRESSURE MANIFOLD SUPPORT BRACKET REPLACEMENT	-	855
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package G				1080
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package G	006	OIL PRESSURE MANIFOLD SUPPORT BRACKET BUSHING REPLACEMENT	-	1080
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package Q				550
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package Q	016	BOLT HOLE BLEND REPAIR	-	550
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package R				1115
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package R	019	REPAIR FRONT FLANGE BOLT HOLES	-	1115
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package S				1115
72-34-81	PW4000	139730	30	28	51A397-01	INTERMEDIATE CASE - NO. 1 BEARING REAR SUPPORT ASSEMBLY - 100"	Package S	020	REPAIR REAR FLANGE BOLT HOLES	-	1115
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package A				450
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	450
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package B				600
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package B	001	RESTORE PROTECTIVE COATING ON NO. 1 BEARING FRONT SUPPORT	-	600
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package C				1795
72-34-82	PW4000	137846	29	28	50A452 50A641 51A398	INTERMEDIATE CASE - NO. 1 BEARING FRONT SUPPORT	Package C	002	PLASMA SPRAY THE BEARING JOURNAL	-	1795

72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package H					990
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package H	007	72-35-07 / BLEND REPAIR TANGENTIAL SLOT RIM RAILS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY			990
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package I					7505
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package I	008	72-35-08 / RESTORE KNIFE-EDGE SEAL PLASMA COAT - HPC DRUM ROTOR (REAR) DISK ASSEMBLY			7505
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package J					3350
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package J	009	72-35-05 / PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING JOURNAL			3350
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package K					2465
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package K	010	72-35-07 / RESTORE ANTIGALLING COATING TO AXIAL BLADE SLOTS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY			2465
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package L					1920
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package L	011	72-35-07 / SURFACE DAMAGE BLEND REPAIR - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY			1920
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package M					2985
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package M	012	72-35-07 / REPLACE 9TH STAGE HPC DRUM ROTOR (FRONT) DISK TUBE ASSEMBLY - HPC DRUM ROTOR (FRONT) DISK			2985
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package N					990
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package N	011	72-35-05 / BLEND REPAIR ANTI-TORQUE LUGS			990
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package O					4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package O	014	72-35-08 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING JOURNAL - HPC DRUM ROTOR (REAR) DISK ASSEMBLY			4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package P					4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package P	015	72-35-08 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING SEAL SPACER JOURNAL - HPC DRUM ROTOR (REAR) DISK			4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Q					4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Q	016	72-35-08 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING FRONT SEAL JOURNAL - HPC DRUM ROTOR (REAR) DISK			4705
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package R					4820
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package R	017	72-35-08 / NICKEL PLATE HPC REAR HUB NO. 3 BEARING SEAL SEAT SHOULDER - HPC DRUM ROTOR (REAR) DISK A			4820
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package S					1645
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package S	018	72-35-07 / REPLACE ANTI-VORTEX TUBES			1645
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB01					1440
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB02	PWAENG 72-745 /	6TH STG DOVETAIL LUG FPI (IN COMBINATION WITH PACKAGE A)			1440
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB02					2135
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB02	PWAENG 72-515	5TH STG - MODIFICATION OF TO REMOVE THE BALANCE FLANGE			2135
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB03					695
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB03	PWAENG 72-796	FPI OF THE 13TH, 14TH, AND 15TH STAGE BLADE LOADING AND LOCKING SLOTS FOR CRACKS			695
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB04					4655
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB04	PWAENG 72-653	MODIFICATION OF THE FRONT KNIFE EDGE SEAL TO IMPROVE DURABILITY			4655
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB05					400
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB05	PWAENG 72-816	INTRODUCTION OF NEW SHOOT PEEN SPECIFICATION TO IMPROVE REAR DRUM ROTOR DURABILITY	ADMINISTRATIVE PROCESS ONLY		400
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB06					595
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB06	PWAENG 72-799	REPETITIVE INSPECTION OF ANTI-VORTEX TUBE (AVT) SHELF SLOTS FOR CRACKS			595
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB07					550
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB07	PWAENG A72-722	BORESKOPE INSPECTION OF THE 6TH TO 7TH STAGE SPACER AREA FOR CRACKS			550
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB08					3750

72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB08	PWAEENG A72-833	EDDY CURRENT AND ULTRASONIC INSPECTION OF THE 10TH STAGE DISK FOR CRACKS	PART B, AD 2016-08-09	3750
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB09				600
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB09	PWSENG 72-845	REIDENTIFY DRUM ROTOR ASSEMBLY	-	600
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package T				3495
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package T	007	72-35-06 / KNIFE-EDGE SEAL THIN PLASMA COAT REPAIR	-	3495
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package U				4250
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package U	009	72-35-07 / RESTORE KNIFE-EDGE SEAL PLASMA COAT	-	4250
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package V				810
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package V	006	72-35-06 / BLEND REPAIR KNIFE-EDGE SEALS - STAGE 5 HPC DISK	-	810
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package W				1320
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package W	008	72-35-06 / BLEND REPAIR SURFACE DAMAGE - STAGE 5 HPC DISK	-	1320
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package X				810
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package X	008	72-35-07 / BLEND REPAIR KNIFE-EDGE SEALS - STAGE 5 HPC DISK	-	810
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Y				745
72-35-01	PW4000	11470	58	35	51H778 51H878 52H578 53H973-001 53H973-01 54H668 57H678-001 57H678-004	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Y	024	72-35-08 / STRAIGHTEN KNIFE-EDGE SEAL THAT HAS NO COATING - HPC DRUM ROTOR (REAR)DISK ASSEMBLY	-	745
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package A				3255
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package A	CLN/INSP	CLEANING AND INSPECTION	-	3255
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AA				4905
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AA	026	72-35-09 / REAR HUB TURBINE PILOT DIAMETER FRONT JOURNAL CHROMIUM PLATE REPAIR	-	4905
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AB				4905
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AB	027	72-35-09 / REAR HUB TURBINE PILOT DIAMETER REAR JOURNAL CHROMIUM PLATE OR COAT REPAIR	-	4905
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AC				1380
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AC	014	72-35-10 / BLEND REPAIR SURFACE DAMAGE - DRUM ROTOR (REAR) DISK ASSEMBLY	-	1380
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AD				810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AD	015	72-35-09 / BLEND REPAIR KNIFE-EDGE SEALS - TURBINE DRIVE SHAFT	-	810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AE				810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AE	015	72-35-10 / BLEND REPAIR DAMAGED KNIFE-EDGE SEALS- DRUM ROTOR (REAR) DISK ASSEMBLY	-	810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AF				795
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AF	017	72-35-09 / BLEND REPAIR SPLINE SURFACE DAMAGE	-	795
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AG				2825
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package AG	015	72-35-06 / KNIFE EDGE THICK COATING	-	2825
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package B				3310
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package B	003	72-35-07 / SHOTPEEN BLADE SLOTS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-	3310
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package C				1415
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package C	004	72-35-06 / SHOTPEEN BLADE SLOTS - STAGE 5 HPC DISK	-	1415
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package D				1145
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package D	004	72-35-10 / SHOTPEEN BLADE SLOTS - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	1145
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package E				1880
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package E	005	72-35-06 / RESTORE ANTIGALLING COMPOUND IN DISK BLADE SLOTS	-	1880
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package F				4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package F	005	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING JOURNAL	-	4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package G				4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package G	006	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING SEAL SPACER JOURNAL	-	4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package H				7515

72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package H	006	72-35-10 / RESTORE KNIFE-EDGE SEAL PLASMA COAT (VENDOR APPLICATION)	-		7515
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package I					3495
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package I	007	72-35-06/KNIFE-EDGE SEAL THIN PLASMA COAT REPAIR	STAGE 5 HPC DISK		3495
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package J					1320
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package J	008	72-35-06 / BLEND REPAIR SURFACE DAMAGE - STAGE 5 HPC DISK	-		1320
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package K					3350
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package K	009	72-35-05 / PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING JOURNAL	-		3350
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package L					4250
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package L	009	72-35-07 / RESTORE KNIFE-EDGE SEAL PLASMA COAT (VENDOR APPLICATION)	-		4250
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package M					2465
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package M	010	72-35-07 / RESTORE ANTIGALLING COATING TO AXIAL BLADE SLOTS (STAGE 6, 7 AND 8)	-		2465
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package N					1920
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package N	011	72-35-07 / SURFACE DAMAGE BLEND REPAIR - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-		1920
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package O					990
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package O	011	72-35-05 / BLEND REPAIR ANTI-TORQUE LUGS	-		990
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package P					745
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package P	001	72-35-06 / STRAIGHTEN STAGE 5 HPC DISK KNIFE-EDGE SEAL - STAGE 5 HPC DISK	-		745
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Q					790
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Q	005	72-35-10 / BLEND REPAIR TANGENTIAL SLOT RIM RAILS - DRUM ROTOR (REAR) DISK ASSEMBLY	-		790
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package R					810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package R	006	72-35-06 / BLEND REPAIR KNIFE-EDGE SEALS - STAGE 5 HPC DISK	-		810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package S					1645
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package S	018	72-35-07 / REPLACE ANTI-VORTEX TUBES - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-		1645
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB02					520
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB02	PW4G-100-72-186	72-35-10 / FPI HPC REAR DRUM BLADE LOCKING SLOTS	AD FAA-2012-18-17		520
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB05					340
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB05	PW4G-100-72-240	REPLACEMENT OF, AND INTRODUCTION OF A NEW SHOT PEEN SPECIFICATION	-		340
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB06					595
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB06	PW4G-100-72-226	REPETITIVE INSPECTION OF ANTI-VORTEX TUBE (AVT) SHELF SLOTS FOR CRACKS	AD FAA-2010-24-14		595
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB07					3750
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB07	PW4G-100-72-255	EDDY CURRENT AND ULTRASONIC INSPECTION OF THE 10TH STAGE DISK FOR CRACKS	PART B, AD FAA 2016-08-09		3750
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB08					435
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB08	PW4G-100-72-232	BFI OF ANTI VORTEX TUBE SHELF SLOTS	-		435
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB10					1355
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB10	PW4G-100-72-239	INTRODUCTION OF, TO IMPROVE FRONT COMPRESSOR DURABILITY	-		1355
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB15					425
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package SB15	PW4G-100-72-260	HPC, NEW DRUM ROTOR DISK ASSY	-		425
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package T					990
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package T	007	72-35-07 / BLEND REPAIR TANGENTIAL SLOT RIM RAILS - DRUM ROTOR (FRONT) DISK ASSEMBLY	-		990
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package U					4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package U	007	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO.3 BEARING FRONT SEAL JOURNAL - TURBINE DRIVE SHAFT	-		4705
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package V					810

72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package V	008	72-35-07 / BLEND REPAIR KNIFE-EDGE SEALS - DRUM ROTOR (FRONT) DISK ASSEMBLY	-	810
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package W				4220
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package W	012	72-35-10 / PLASMA SPRAY BRUSH SEAL LAND - DRUM ROTOR (REAR) DISK ASSEMBLY	-	4220
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package X				2650
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package X	013	72-35-10 / BLEND LOCK SCREW DAMAGE IN BLADE SLOTS - DRUM ROTOR (REAR) DISK ASSEMBLY	-	2650
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Z				1020
72-35-01	PW4000	11471	51	35	50S192 52A520 55H878 58H678 59H078	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR STG 5 - 15	Package Z	014	72-35-09 / BLEND REPAIR SURFACE DAMAGE - TURBINE DRIVE SHAFT	-	1020
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package A				1605
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1605
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AA				1380
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AA	014	72-35-10 / SURFACE DAMAGE BLEND REPAIR - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	1380
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AB				810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AB	015	72-35-09 / BLEND REPAIR KNIFE-EDGE SEALS - HPC TURBINE DRIVE SHAFT	-	810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AC				810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AC	015	72-35-10 / BLEND REPAIR DAMAGED KNIFE EDGE SEALS - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AD				1645
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AD	018	72-35-07 / REPLACE ANTI-VORTEX TUBES - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-	1645
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AE				4900
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AE	026	72-35-09 / REAR HUB TURBINE PILOT DIAMETER REAR JOURNAL CHROMIUM PLATE REPAIR	-	4900
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AF				4905
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AF	027	72-35-09 / REAR HUB TURBINE PILOT DIAMETER REAR JOURNAL CHROMIUM PLATE - SHAFT, HPC DRIVE TURBINE	-	4905
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AG				990
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AG	011	72-35-05 / BLEND REPAIR ANTI-TORQUE LUGS - HPC FRONT HUB	-	990
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AH				2825
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AH	015	72-35-06 / KNIFE EDGE THICK COATING	-	2825
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AJ				375
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AJ	INSP/CHK-03	FLUORESCENT PENETRANT TEST AND ELECTROSTATIC APPLICATION STG.	-	375
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AK				795
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AK	017	72-35-09 / BLEND REPAIR SPLINE SURFACE DAMAGE	-	795
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AL				3495
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package AL	017	72-35-06 / KNIFE-EDGE SEAL THIN PLASMA COAT REPAIR	-	3495
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package B				745
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package B	001	72-35-06 / STRAIGHTEN STAGE 5 HPC DISK KNIFE-EDGE SEAL	-	745
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package D				3310
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package D	003	72-35-07 / SHOTPEEN BLADE SLOTS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-	3310
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package E				1415
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package E	004	72-35-06 / SHOTPEEN BLADE SLOTS - STAGE 5 HPC DISK	-	1415
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package F				1145
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package F	004	72-35-10 / SHOTPEEN BLADE SLOTS - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	1145
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package G				1880
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package G	005	72-35-06 / RESTORE ANTIGALLING COMPOUND IN DISK BLADE SLOTS	-	1880
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package H				4705

72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package H	005	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING JOURNAL - HPC TURBINE DRIVE SHAFT	-		4705
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package I					790
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package I	005	72-35-10 / BLEND REPAIR TANGENTIAL SLOT RIM RAILS - HPC DRUM ROTOR DISK (REAR HUB) ASSEMBLY	-		790
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package J					810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package J	006	72-35-06 / BLEND REPAIR KNIFE-EDGE SEALS - STAGE 5 HPC DISK	-		810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package K					4705
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package K	006	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING SEAL SPACER JOURNAL - HPC TURBINE DRIVE SHAFT	-		4705
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package L					7515
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package L	006	72-35-10 / RESTORE KNIFE-EDGE SEAL PLASMA COAT - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-		7515
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package M					3495
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package M	007	72-35-06 / KNIFE-EDGE SEAL THIN PLASMA COAT REPAIR- STAGE 5 HPC DISK	-		3495
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package N					990
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package N	007	72-35-07 / BLEND REPAIR TANGENTIAL SLOT RIM RAILS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-		990
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package O					4705
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package O	007	72-35-09 / CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING FRONT SEAL JOURNAL - HPC TURBINE DRIVE SHAFT	-		4705
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package P					810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package P	008	72-35-07 / BLEND REPAIR KNIFE-EDGE SEALS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-		810
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package R					1320
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package R	008	72-35-06 / BLEND REPAIR SURFACE DAMAGE - STAGE 5HPC	-		1320
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package S					4250
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package S	009	72-35-07 / RESTORE KNIFE-EDGE SEAL PLASMA COAT - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-		4250
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB01					845
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB01	PW4ENG 72-745	6TH STG DOVETAIL LUG FPI (IN COMBINATION WITH PACKAGE A)	PART 001		845
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB03					2350
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB03	PW4ENG 72-515	5TH STG - MODIFICATION OF TO REMOVE THE BALANCE FLANGE	-		2350
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB04					910
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB04	PW4ENG 72-796	FPI OF THE 13TH, 14TH, AND 15TH STAGE BLADE LOADING AND LOCKING SLOTS FOR CRACKS	AD FAA-2012-18-17		910
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB05					75
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB05	PW4ENG 72-816	INTRODUCTION OF NEW SHOOT PEEN SPECIFICATION TO IMPROVE REAR DRUM ROTOR DURABILITY	ADMINISTRATIVE PROCESS ONLY		75
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB06					595
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB06	PW4ENG 72-799	REPETITIVE INSPECTION OF ANTI-VORTEX TUBE (AVT) SHELF SLOTS FOR CRACKS	AD FAA-2010-24-14		595
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB07					550
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB07	PW4ENG A72-722	BORESKOPE INSPECTION OF THE 6TH TO 7TH STAGE SPACER AREA FOR CRACKS	AD FAA-2002-12-15		550
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB08					3750
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB08	PW4ENG A72-833	EDDY CURRENT AND ULTRASONIC INSPECTION OF THE 10TH STAGE DISK FOR CRACKS	PART B, AD FAA-2016-08-09		3750
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB09					600
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package SB09	PW4ENG 72-845	REIDENTIFY DRUM ROTOR ASSEMBLY	-		600
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package T					3350
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package T	009	72-35-05 / PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING JOURNAL	-		3350
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package U					2465

72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package U	010	72-35-07 / RESTORE ANTIGALLING COATING TO AXIAL BLADE SLOTS - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-	2465
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package V				1920
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package V	011	72-35-07 / SURFACE DAMAGE BLEND REPAIR - HPC DRUM ROTOR (FRONT) DISK ASSEMBLY	-	1920
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package W				2985
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package W	012	72-35-07 / REPLACE 9TH STAGE HPC DRUM ROTOR (FRONT) DISK TUBE ASSEMBLY - HPC DRUM ROTOR (FRONT) DISK	-	2985
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package X				4220
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package X	012	72-35-10 / PLASMA SPRAY BRUSH SEAL LAND - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	4220
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package Y				2650
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package Y	013	72-35-10 / BLEND LOCK SCREW DAMAGE IN BLADE SLOTS - HPC DRUM ROTOR (REAR) DISK ASSEMBLY	-	2650
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package Z				1020
72-35-01	PW4000	11474	54	35	55H778 56H378 56H378-002 57H478 57H478-002 58H575 58H578	HIGH PRESSURE COMPRESSOR (HPC) DRUM DISK ASSY STG 13	Package Z	014	72-35-09 / BLEND REPAIR SURFACE DAMAGE - HPC TURBINE DRIVE SHAFT	-	1020
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package B				9280
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package B	ASSEMBLY 03	HIGH SPEED GRINDING OF BLADE TIP	-	9280
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C				2820
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C	001	BLEND INSTALLED HPC BLADES	-	2820
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C	S800			9280
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C	PW4ENG 72-755	HIGH SPEED GRINDING OF BLADE TIP (RING CASE CONFIGURATION)	BOEING	9280
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C	PW4ENG 72-756	HIGH SPEED GRINDING OF BLADE TIP (RING CASE CONFIGURATION)	AIRBUS	
72-35-01	PW4000	139324	25	28	94" REAR COMPR ROTOR	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 94"	Package C	PW4ENG 72-757	HIGH SPEED GRINDING OF BLADE TIP (RING CASE CONFIGURATION)	MCDONNELL DOUGLAS	9280
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package A				1705
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1705
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package B				9290
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package B	ASSEMBLY 16	HIGH SPEED GRINDING OF BLADE TIP	-	9290
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package B	PW4G-100-72-118	MODI. OR REPL. BLADES TO ZIRCONIUM OXIDE COATED TIPS AND SHROUDS WIT H PWA 284-2 RUBSTRIPS	COMPRESSOR ROTOR BLADE TIP GRINDING ONLY	
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package B	PW4G-100-72-219	MODIFICATION OF TO INCORPORATE THE ADVANTAGE 70TM PERFORMANCE	COMPRESSOR ROTOR BLADE TIP GRINDING ONLY	9290
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package B	PW4G-100-72-220	CONVERSION OF PW4164 PW4168 OR PW4168A TO A PW4164-1D PW4168-1D PW4168A-1D OR PW4170 ENGINE	COMPRESSOR ROTOR BLADE TIP GRINDING ONLY	
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package C				2825
72-35-01	PW4000	139855	33	28	100" REAR COMPR ROTO	HIGH PRESSURE COMPRESSOR (HPC) REAR COMPRESSOR ROTOR ASSY - 100"	Package C	001	BLEND INSTALLED HPC BLADES	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package A				1105
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package D				1385
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package D	003	SURFACE DAMAGE BLEND REPAIR	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package E				3085
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package E	004	PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 FRONT SEAL SEAT JOURNAL	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package F				4145

72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package F	005	NO. 2 FRONT SEAL SEAT SHOULDER COAT REPAIR	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package G				2900
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package G	006	PLASMA SPRAY REPAIR - HPC FRONT HUB SNAP DIAMETER	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package H				2900
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package H	007	PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING SHOULDER	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package I				2840
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package I	008	PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING SEAL SEAT PILOT	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package J				3275
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package J	009	PLASMA SPRAY REPAIR - HPC FRONT HUB NO. 2 BEARING JOURNAL	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package K				2765
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package K	010	REPAIR ANTI-TORQUE SLOTS	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package L				980
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package L	011	BLEND REPAIR ANTI-TORQUE LUGS	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package N				660
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package N	013	THREAD BLEND REPAIR	-	
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package SB00				480
72-35-05	PW4000	137736	30	28	50H470 51H572	HIGH PRESSURE COMPRESSOR (HPC) FRONT HUB	Package SB00	PW4ENG 72-201	HPC MOD.OF FRT HUB + DRUM ROT. DISK ASSY	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package A				1705
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package AH				3870
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package AJ	015	KNIFE EDGE SEAL THICK COATING	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package AJ	017	KNIFE EDGE SEAL THIN PLASMA COATING	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package B				3275
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package B	001	STRAIGHTEN STAGE 5 HPC DISK KNIFE-EDGE SEAL	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package E				2765
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package E	004	SHOTPEEN BLADE SLOTS	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package F				2765
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package F	005	RESTORE ANTIGALLING COMPOUND IN DISK BLADE SLOTS	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package G				525
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package G	006	BLEND REPAIR KNIFE-EDGE SEALS	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package H				3870
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package H	007	KNIFE-EDGE SEAL THIN PLASMA COAT REPAIR	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package I				2520
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package I	008	BLEND REPAIR SURFACE DAMAGE	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package J				2520
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package J	009	PLASMA SPRAY REPAIR THE REAR SNAP DIAMETER	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package K				2520
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package K	010	PLASMA SPRAY REPAIR THE FRONT SNAP DIAMETER	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package O				1890
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package O	014	MACHINE REPAIR THE REAR SNAP DIAMETER	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB00				2520
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB00	PW4ENG 72-515	HPC 5TH STG DISK - REMOVAL OF BALANCE FLANGE	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB01				2765
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB01	PW4ENG 72-653	HPC 5TH STG DISK - REMOVAL OF FRONT KNIFE-EDGE SEAL	-	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB02				380
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB02	AD 2005-25-09	FPI LIFE-LIMITED PART, HPC 5TH STG DISK	IN CONJUNCTION WITH PACKAGE A	
72-35-06	PW4000	22667	35	28	51H005 51H905 54H405 54H705 54H705-001 56H605 56H705 57H105	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC DISK	Package SB03				165

72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package G	006	CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING SEAL SPACER JOURNAL	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package H				4710
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package H	007	CHROMIUM PLATE HPC REAR HUB NO. 3 BEARING FRONT SEAL JOURNAL	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package I				4825
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package I	008	NICKEL PLATE HPC REAR HUB NO. 3 BEARING SEAL SEAT SHOULDER	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package J				1340
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package J	009	BLEND REPAIR REAR HUB TORQUE SLOT LUGS	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package L				4715
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package L	011	PLASMA SPRAY HPC FRONT SNAP DIAMETER	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package O				945
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package O	014	BLEND REPAIR SURFACE DAMAGE	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package P				810
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package P	015	BLEND REPAIR KNIFE-EDGE SEALS	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package R				1185
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package R	017	BLEND REPAIR SPLINE SURFACE DAMAGE	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package U				2475
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package U	020	REPAIR THE HEAT SHIELD ANTI-ROTATION SLOT SURFACE DAMAGE	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package X				1460
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package X	023	SKIM MACHINE CUT REPAIR FRONT SNAP DIAMETER	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package Y				1460
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package Y	024	SKIM MACHINE CUT REPAIR REAR SNAP DIAMETER	-	
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package Z				480
72-35-09	PW4000	139302	36	35	54H767	HIGH PRESSURE COMPRESSOR (HPC) TURBINE DRIVE SHAFT	Package Z	025	SKIM MACHINE CUT REPAIR NO3 BEARING STACKUP SHOULDER REAR HUB	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package A				2335
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package AJ				1325
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package AJ	035	SURFACE DAMAGE BLEND REPAIR	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package B				7520
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package B	006	RESTORE KNIFE-EDGE SEAL PLASMA COAT	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package C				1325
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package C	004	SHOTPEEN BLADE SLOTS	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package D				1510
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package D	005	BLEND REPAIR TANGENTIAL SLOT RIM RAILS	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package F				5005
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package F	008	PLASMA SPRAY REPAIR REAR DRUM FRONT FLANGE SNAP DIAMETER	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package G				5005
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package G	009	PLASMA SPRAY REPAIR REAR DRUM REAR FLANGE SNAP DIAMETER	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package H				4835
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package H	012	PLASMA SPRAY BRUSH SEAL LAND	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package I				2010

72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package I	013	BLEND LOCK SCREW DAMAGE IN BLADE SLOTS	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package J				1380
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package J	014	BLEND REPAIR SURFACE DAMAGE	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package K				1365
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package K	015	BLEND REPAIR DAMAGED KNIFE-EDGE SEALS	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB00				335
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB00	AD 2005-25-09	FPI LIFE-LIMITED PART, HPC REAR DRUM	-	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB01		PW4ENG 72-565	BLADES, 14TH AND 15TH STAGE - MODIFICATION TO PROVIDE IMPROVED PLATFORM CLEARANCE AND BLADE LOCKING	
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB03		PW4G-100-72-186	FPI OF THE 13TH, 14TH, AND 15TH STAGE BLADE LOADING AND LOCKING SLOTS FOR CRACKS	AD 2012-18-17
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB04		PW4ENG 72-796	FPI OF THE 13TH, 14TH, AND 15TH STAGE BLADE LOADING AND LOCKING SLOTS FOR CRACKS	AD 2012-18-17
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB05		PW4ENG 72-816	SEAL 13TH, 14TH AND 15TH STAGE - REPLACEMENT OF AND INTRODUCTION OF A NEW SHOT PEEN SPECIFICATION	TO IMPROVE REAR DRUM ROTOR DURABILITY
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB05		PW4G-100-72-240	REPLACEMENT, INTRODUCTION OF A NEW SHOT PEEN SPECIFICATION, TO IMPROVE REAR DRUM ROTOR DURABILITY	875
72-35-10	PW4000	135931	44	35	50S813-01 53H973-001 53H973-01 54H803-001 54H803-002 54H803-01 56H013-001 56H013-01 58H236-01	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR (REAR) DISK ASSEMBLY	Package SB06		PW4G-100-72-8	BLADES, 14TH AND 15TH STAGE - MODIFICATION TO PROVIDE IMPROVED PLATFORM CLEARANCE AND BLADE LOCKING	5005
72-35-23	PW4000	62466	4	28	50S067-01 58H343 58H601-01	PW4 STG. 8 HPC BLADE OUTER AIRSEAL	Package A				400
72-35-23	PW4000	62466	4	28	50S067-01 58H343 58H601-01	PW4 STG. 8 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	400
72-35-23	PW4000	62468	4	28	58H345	PW4 STG. 9 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62468	4	28	58H345	PW4 STG. 9 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62469	4	28	58H347	PW4 STG. 10 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62469	4	28	58H347	PW4 STG. 10 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62470	4	28	58H323	PW4 STG. 12 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62470	4	28	58H323	PW4 STG. 12 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62471	4	28	58H349	PW4 STG. 11 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62471	4	28	58H349	PW4 STG. 11 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62472	4	28	58H324	PW4 STG. 13 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62472	4	28	58H324	PW4 STG. 13 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62473	4	28	58H325	PW4 STG. 14 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62473	4	28	58H325	PW4 STG. 14 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	285
72-35-23	PW4000	62477	4	28	50S066 58H326	PW4 STG. 15 HPC BLADE OUTER AIRSEAL	Package A				285
72-35-23	PW4000	62477	4	28	50S066 58H326	PW4 STG. 15 HPC BLADE OUTER AIRSEAL	Package A	CLN/INSP	Cleaning and inspection	-	285
72-35-24	PW4000	62485	20	28	50S678-01 50S678-02 50S678-03 50S678-04 58H388-01 58H388-02 58H388-03 58H388-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-24	PW4000	62485	20	28	50S678-01 50S678-02 50S678-03 50S678-04 58H388-01 58H388-02 58H388-03 58H388-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-24	PW4000	62485	20	28	50S678-01 50S678-02 50S678-03 50S678-04 58H388-01 58H388-02 58H388-03 58H388-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 COMPRESSOR STATOR SEGMENT	Package B				155

72-35-24	PW4000	62485	20	28	505678-01 505678-02 505678-03 505678-04 58H388-01 58H388-02 58H388-03 58H388-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 COMPRESSOR STATOR SEGMENT	Package B	001	BLEND REPAIR SURFACE DAMAGE	-	155
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CELANING AND INSPECTION	-	165
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package D				155
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package D	003	VANE SURFACE DAMAGE BLEND REPAIR	-	155
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package I				1170
72-35-25	PW4000	62486	19	28	505279-01 505279-02 505279-03 505279-04 505479-01 505479-02 505479-03 505479-04 59H379-01 59H379-02 59H379-03 59H379-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 COMPRESSOR STATOR SEGMENT	Package I	008	VANE SURFACE DAMAGE WELD REPAIR	-	1170
72-35-26	PW4000	62487	19	28	505680-01 505680-02 505680-03 59H380-01 59H380-02 59H380-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-26	PW4000	62487	19	28	505680-01 505680-02 505680-03 59H380-01 59H380-02 59H380-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-26	PW4000	62487	19	28	505680-01 505680-02 505680-03 59H380-01 59H380-02 59H380-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 COMPRESSOR STATOR SEGMENT	Package H				155
72-35-26	PW4000	62487	19	28	505680-01 505680-02 505680-03 59H380-01 59H380-02 59H380-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 COMPRESSOR STATOR SEGMENT	Package H	007	VANE SURFACE DAMAGE BLEND REPAIR	-	155
72-35-27	PW4000	62488	19	28	505271-01 505271-02 58H371-01 58H371-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-27	PW4000	62488	19	28	505271-01 505271-02 58H371-01 58H371-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-27	PW4000	62488	19	28	505271-01 505271-02 58H371-01 58H371-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 COMPRESSOR STATOR SEGMENT	Package G				155
72-35-27	PW4000	62488	19	28	505271-01 505271-02 58H371-01 58H371-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 COMPRESSOR STATOR SEGMENT	Package G	006	VANE SURFACE DAMAGE BLEND REPAIR	-	155
72-35-28	PW4000	62489	18	28	505372-01 505372-02 505372-03 58H372-01 58H372-02 58H372-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-28	PW4000	62489	18	28	505372-01 505372-02 505372-03 58H372-01 58H372-02 58H372-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-28	PW4000	62489	18	28	505372-01 505372-02 505372-03 58H372-01 58H372-02 58H372-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 COMPRESSOR STATOR SEGMENT	Package B				160
72-35-28	PW4000	62489	18	28	505372-01 505372-02 505372-03 58H372-01 58H372-02 58H372-03	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 COMPRESSOR STATOR SEGMENT	Package B	001	VANE SURFACE DAMAGE BLEND REPAIR	-	160
72-35-29	PW4000	62490	18	28	505283-01 505283-02 58H373-01 58H373-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-29	PW4000	62490	18	28	505283-01 505283-02 58H373-01 58H373-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-29	PW4000	62490	18	28	505283-01 505283-02 58H373-01 58H373-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 COMPRESSOR STATOR SEGMENT	Package B				160
72-35-29	PW4000	62490	18	28	505283-01 505283-02 58H373-01 58H373-02	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 COMPRESSOR STATOR SEGMENT	Package B	001	VANE SURFACE DAMAGE BLEND REPAIR	-	160
72-35-30	PW4000	62491	19	28	505174-01 505474-01 505474-02 505474-03 505474-04 58H374-01 58H374-02 58H374-03 58H374-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 14 COMPRESSOR STATOR SEGMENT	Package A				165
72-35-30	PW4000	62491	19	28	505174-01 505474-01 505474-02 505474-03 505474-04 58H374-01 58H374-02 58H374-03 58H374-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 14 COMPRESSOR STATOR SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	165
72-35-30	PW4000	62491	19	28	505174-01 505474-01 505474-02 505474-03 505474-04 58H374-01 58H374-02 58H374-03 58H374-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 14 COMPRESSOR STATOR SEGMENT	Package B				160
72-35-30	PW4000	62491	19	28	505174-01 505474-01 505474-02 505474-03 505474-04 58H374-01 58H374-02 58H374-03 58H374-04	HIGH PRESSURE COMPRESSOR (HPC) STAGE 14 COMPRESSOR STATOR SEGMENT	Package B	001	VANE SURFACE DAMAGE BLEND REPAIR	-	160
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package A				835
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package A	CLN/INSP	CLEANING & INSPECTION	-	835
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package B				175
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package B	002	BLEND REPAIR KNIFE EDGE SEAL	-	175
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package C				2795
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package C	004	PLASMA SPRAY REPAIR SNAP DIAMETER	-	2795
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package D				920
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package D	006	REPAIR OF DAMAGED BALANCE FLANGE	-	920
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package E				950
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package E	007	BLEND REPAIR SURFACE DAMAGE	-	950
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package S800				2160
72-35-31	PW4000	137549	4	28	50H021 56H279	PW4 HPC INLET AIRSEAL	Package S800	PWAENG 72-653	HPC, KNIFE EDGE MODI. TO IMPROVE DURAB.	-	2160
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package A				755

72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	755
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package B				1015
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package B	001	KNIFE-EDGE SEAL REPAIR	-	1015
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package D				790
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package D	003	BLEND REPAIR KNIFE-EDGE SEALS	-	790
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package E				2925
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package E	004	RESTORE KNIFE-EDGE SEAL PLASMA COAT	-	2925
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package F				2790
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package F	007	PLASMA REPAIR DIAMETER	-	2790
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package G				4175
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package G	008	RESTORE HARDFACE OF BRUSH SEAL LAND	-	4175
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package G	012	RESTORE HARDFACE OF BRUSH SEAL LAND	-	
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package H				3480
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package H	005	PLASMA COAT OR NICKEL PLATE REPAIR FRONT OUTSIDE DIAMETER	-	
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package J				3475
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package J	009	SURFACE DAMAGE BLEND REPAIR	-	
72-35-32	PW4000	137550	34	28	50H218 54H792 54H846	HIGH PRESSURE COMPRESSOR (HPC) DIFFUSER AIRSEAL	Package J	017	SURFACE DAMAGE BLEND REPAIR	-	3475
72-35-34	PW4000	137385	18	28	50H048 50H049 50H051 50H052 51H319 51H320 51H518 51H519 56H381 56H385	HIGH PRESSURE COMPRESSOR (HPC) INTERMEDIATE CASE - COMPRESSOR TIERODS	Package A				100
72-35-34	PW4000	137385	18	28	50H048 50H049 50H051 50H052 51H319 51H320 51H518 51H519 56H381 56H385	HIGH PRESSURE COMPRESSOR (HPC) INTERMEDIATE CASE - COMPRESSOR TIERODS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	100
72-35-35	PW4000	137386	23	28	50H053 51H517 53H118 53H119 92425-624	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR TIEROD NUTS	Package A				80
72-35-35	PW4000	137386	23	28	50H053 51H517 53H118 53H119 92425-624	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR TIEROD NUTS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	80
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package A				545
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package A	CLN/INSP	CLEANING AND INSPECTION	-	545
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package B				620
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package B	001	RESTORE ANTIGALLANT	-	620
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package C				1380
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package C	002	RESTORE CORROSION PROTECTIVE COATING	-	1380
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package D				540
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package D	003	BLEND REPAIR	-	540
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package E				540
72-35-36	PW4000	137643	26	28	50H100 53H367	HIGH PRESSURE COMPRESSOR (HPC) NO. 3 BEARING (INNER REAR HUB) HEAT SHIELD	Package E	004	FRONT FACE BLEND REPAIR	-	540
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package B				1205
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package B	ASSEMBLY 02	GRIND STAGE 9 THROUGH 12 HPC BLADE PLATFORMS - 94"	PW9-15 HPC BLADES FOR SHOP VISIT ONLY	1205
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package C				1205
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package C	ASSEMBLY 03	GRIND STAGE 13 THROUGH 15 HPC BLADE PLATFORMS - 94"	PW9-15 HPC BLADES FOR SHOP VISIT ONLY	1205
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package D				1205
72-35-38	PW4000	138267	17	28	9-15 HPC BLADES	HIGH PRESSURE COMPRESSOR (HPC) DRUM ROTOR AND BLADES (FRONT) ASSEMBLY	Package D	ASSEMBLY 03	GRIND AND MEASURE THE AXIAL COMPRESSOR ROTOR ASSEMBLY BLADE TIPS - 100"	PW9-15 HPC BLADES FOR SHOP VISIT ONLY	1205
72-35-40	PW4000	137726	48	28	50S001 50S001-001 50S007-01 50S727 51H224 51H532 51H532-001 51H532-002 52H431 52H433 53H066 53H066-001 53H066-002 53H066-003 54H025 54H134-01 55H293-01 56H194 58H006-01	HIGH PRESSURE COMPRESSOR (HPC) FRONT CASE/OUTER AIRSEAL SET	Package A				1850
72-35-40	PW4000	137726	48	28	50S001 50S001-001 50S007-01 50S727 51H224 51H532 51H532-001 51H532-002 52H431 52H433 53H066 53H066-001 53H066-002 53H066-003 54H025 54H134-01 55H293-01 56H194 58H006-01	HIGH PRESSURE COMPRESSOR (HPC) FRONT CASE/OUTER AIRSEAL SET	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1850

72-35-51	PW4000	139830	35	28	54H779-01 54H794-01 55H818-01 55H820-01 56H075-01 56H076-01	HIGH PRESSURE COMPRESSOR (HPC) INLET SYNCHRONIZING RING ASSEMBLIES - 100"	Package SB02						595
72-35-51	PW4000	139830	35	28	54H779-01 54H794-01 55H818-01 55H820-01 56H075-01 56H076-01	HIGH PRESSURE COMPRESSOR (HPC) INLET SYNCHRONIZING RING ASSEMBLIES - 100"	Package SB02	PW4G-100-72-171	REPETITIVE INSPECTION FOR TACK WELD CRACKS AND WAER				595
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package A						365
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION		PNS4H780-01 50H794 54H795-01 54H902-01 55H823-01FOR SHOP VISIT ONLY		365
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package B						1175
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package B	001	REPLACE RING ASSEMBLY PIN AND LEVER ARM				1175
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package C						670
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package C	002	REPLACE NUT PLATES				670
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package F						2445
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package F	005	WELD REPAIR OF VANE ARM PIN HOLES				2445
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package H						315
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package H	007	BLEND RING SEGMENT SURFACE DAMAGE				315
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package L						970
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package L	011	APPLY PWA 578 PAINT				970
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB00						1175
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB00	PW4ENG 72-432	SYNCHRONIZING RING - MODIFICATION OF PIN ATTACHMENT				1175
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB01						330
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB01	PW4ENG 72-474	SYNCHRONIZING RING - PAINT REMOVAL FROM ID				330
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB02						730
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB02	PW4ENG 72-527	SYNCHRONIZING RING STG 5 AND 6 - INCORPORATION OF LOCATING PIN				730
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB03						1620
72-35-52	PW4000	2710	32	28	50H794 50H795 53H932 54H780-01 54H795-01 54H799-01 54H884-001 54H885 54H902-01 55H626-01 55H823-01 55H825-01 56H079-01 56H081-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 5 HPC SYNCHRONIZING RING ASSEMBLIES - 94"	Package SB03	PW4ENG 72-114	REPLACEMENT OR MODIFICATION FOR IMPROVED HPC ARM ASSEMBLY				1620
72-35-53	PW4000	2709	34	28	50S728 50S730 51H148 51H149 53H933 53H934 54H801-01 54H801-101 54H886 54H886-001 54H886-003 54H887 54H887-101 55H635-01 55H635-101	HIGH PRESSURE COMPRESSOR (HPC) STAGE 6 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package A						365
72-35-53	PW4000	2709	34	28	50S728 50S730 51H148 51H149 53H933 53H934 54H801-01 54H801-101 54H886 54H886-001 54H886-003 54H887 54H887-101 55H635-01 55H635-101	HIGH PRESSURE COMPRESSOR (HPC) STAGE 6 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION		PNS1H149 53H934 FOR SHOP VISIT ONLY		365
72-35-53	PW4000	2709	34	28	50S728 50S730 51H148 51H149 53H933 53H934 54H801-01 54H801-101 54H886 54H886-001 54H886-003 54H887 54H887-101 55H635-01 55H635-101	HIGH PRESSURE COMPRESSOR (HPC) STAGE 6 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package B						1175

72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package A					440
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION		PWS5H831-01 FOR SHOP VISIT ONLY	440
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package B					1165
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package B	001	REPLACE RING ASSEMBLY PIN AND LEVER ARM			1165
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package C					690
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package C	002	REPLACE NUT PLATES			690
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package F					2515
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package F	005	WELD REPAIR OF VANE ARM PIN HOLES			2515
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package H					325
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package H	007	BLEND RING SEGMENT SURFACE DAMAGE			325
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package L					990
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package L	011	APPLY PWA 578 PAINT			990
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package S800					1110
72-35-54	PW4000	139836	34	28	55H831-01 55H833-01 56H087-01 56H090-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 7 HPC SYNCHRONIZING RING ASSEMBLIES - 100"	Package S800	PW4G-100-72-114	SYNCHRONIZING RING - MODIFICATION FOR IMPROVED ARM DURABILITY			1110
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package A					210
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package A	CLN/INSP	CLEANING AND INSPECTION			210
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package B					600
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package B	001	BLEND REPAIR			600
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package C					1565
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package C	002	CLEVIS BOLT HOLE BUSHING REPAIR			1565
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package E					1370
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package E	004	REPAIR CLEVIS ACTUATOR BOLT HOLE WITH BUSHING			1370
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package S800					540
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package S800	PW4ENG 72-534	ACTUATOR SUPPORT BRACKET UPPER MOUNT STUDS AND 5TH STG SYNCHRONIZING RING CLEVIS - REPLACEMENT OF			540
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package S801					570
72-35-55	PW4000	137389	27	28	50H432 50H966 50H968 52H092 52H093 54H580-01 54H582-01 54H616-01 54H733-01 54H734-01 54H735-01 55H372 55H685-01 55H687-01 58H231-01	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING CLEVIS ASSEMBLIES	Package S801	PW4ENG 72-197	HPC 5/6/7TH ST.VAR.VANE ACT.MODL.(SVS19)			570
72-35-56	PW4000	137392	28	28	50H180 50H186 50H433 50H441 54H266 54H588 54H590 54H592 55H602 55H603	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING PLATES	Package A					210
72-35-56	PW4000	137392	28	28	50H180 50H186 50H433 50H441 54H266 54H588 54H590 54H592 55H602 55H603	HIGH PRESSURE COMPRESSOR (HPC) SYNCHRONIZING RING PLATES	Package A	CLN/INSP	CLEANING AND INSPECTION			210

72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package R	017	REPAIR CRACKED SEGMENT END FLANGE HOLES	-	1975
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package S			-	1525
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package S	018	WELD REPAIR CRACKS IN THE OUTER SHROUD LUG	-	1525
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package V			-	1310
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package V	021	REPLACE THE INNER AIR SEAL ANTI-ROTATION PINS	-	1310
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package X			-	3180
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package X	023	WELD THE 9TH STAGE VANE DAMAGE	-	3180
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package Y			-	1225
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package Y	024	AXIAL FLANGE SQUARENESS REPAIR	-	1225
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package Z			-	1700
72-35-60	PW4000	673035	6	35	56H519-01	PW4 STAGE 9 AND 10 COMPRESSOR STATOR SET	Package Z	025	BORESCOPE BOSS REPLACEMENT REPAIR	-	1700
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package A			-	1175
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1175
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package AA			-	14850
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package AA	026	WELD FEATHERSEAL SLOT AND FELTMETAL RUBSTRIP	-	14850
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package E			-	4505
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package E	004	REPLACE FELTMETAL STG.12 OS 25501	-	4505
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package F			-	4505
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package F	005	REPLACE FELTMETAL STG.13 OS 25501	-	4505
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package H			-	8415
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package H	007	INDIVIDUAL VANE REPLACEMENT OS 255007	-	8415
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package O			-	1170
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package O	014	REPLACE PWA 53-78 PLASMA COAT	-	1170
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package P			-	645
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package P	015	BLEND STAGE 11 AND 12 HPC	-	645
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package R			-	1580
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package R	017	WELD CRACKS IN ANTI ROTATION SLOT	-	1580
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package S			-	1295
72-35-61	PW4000	673029	4	28	56H191-01	PW4 STG 11 & 12 COMPRESSOR STATOR SET	Package S	018	WELD CRACKS IN THE OUTER SHROUD LUG	-	1295
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package A			-	1850
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1850
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AA			-	1875
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AA	026	WELD CRACKS IN THE ANTI-ROTATION SLOTS	-	1875
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AB			-	1130
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AB	027	WELD CRACKS IN THE OUTER SHROUD LUG	-	1130
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AF			-	1630
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AF	031	BOROSCOPE BOSS REPLACEMENT REPAIR	-	1630
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AG			-	8435
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package AG	032	FEATHERSEAL SLOT AND FELTMETAL RUBSTRIP POCKET WELD	-	8435
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package B			-	555
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package B	001	BLEND REPAIR	-	555
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package E			-	3440
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package E	004	REPLACE FELTMETAL STG.14 OS 25501	-	3440
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package F			-	3440
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package F	005	REPLACE FELTMETAL STG.15 OS 25501	-	3440
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package R			-	2125
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package R	017	DUAL ARC WIRE COATING OF THE FRONT FACE FOR WEAR UP	-	2125
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package S			-	940
72-35-62	PW4000	673032	4	28	57H283-01	PW4 STG 13 AND 14 COMPRESSOR STATOR SET	Package S	018	REMOVE AND REPLACE PWA 53-78	-	940
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package A			-	575

72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package A	CLN/INSP	CLEANING AND INSPECTION	-		575
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB00					740
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB00	72-679	MODIFICATION OF TO INCORPORATE CERAMIC THERMAL BARRIER COATING AT THE 5TH STAGE	-		740
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB01					540
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB01	72-755	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	BOEING		540
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB02					540
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB02	72-756	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	AIRBUS		540
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB03					540
72-35-63	PW4000	137745	4	28	50S055-001 50S055-002 50S055-01 52H031 53H555-01 55H255-001 55H255-01 56H855-001 56H855-01 58H055	PW4 HPC 5 SHROUD SET (6 SEGMENTS)	Package SB03	72-757	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	MD11		540
72-35-65	PW4000	139786	4	28	53H257-01 56H457 56H757-01	PW4 (100") STG 7 HPC SHROUD SET	Package A					140
72-35-65	PW4000	139786	4	28	53H257-01 56H457 56H757-01	PW4 (100") STG 7 HPC SHROUD SET	Package A	CLN/INSP	CLEANING AND INSPECTION	-		140
72-35-65	PW4000	139786	4	28	53H257-01 56H457 56H757-01	PW4 (100") STG 7 HPC SHROUD SET	Package SB00					75
72-35-65	PW4000	139786	4	28	53H257-01 56H457 56H757-01	PW4 (100") STG 7 HPC SHROUD SET	Package SB00	PW4G-100-72-118	HPC BLADES/STATORS 6-9 STG - ZIOX BLADE	-		75
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package A					405
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		405
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package B					2740
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package B	001	PLASMA COAT INNER FLANGE SNAP DIAMETER	-		2740
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package D					2495
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package D	003	PLASMA COAT OUTER FLANGE FRONT FACE	-		2495
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package E					2495
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package E	004	PLASMA COAT OUTER FLANGE SNAP DIAMETER (POST SB PW4ENG 72-298 AND SB PW4G-100-72-52)	-		2495
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package G					9425
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package G	EA-12KC24	PLASMA COAT OUTER FLANGE FRONT FACE	EXTENDED LIMITS FOR MPN 55H302 ONLY		9425
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package J					2515
72-35-67	PW4000	137740	30	28	50H953	HIGH PRESSURE COMPRESSOR (HPC) HPC REAR SUPPORT	Package J	009	INNER FACE FRONT FLANGE PLASMA COAT REPAIR	-		2515
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package A					445
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		445
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package B					2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package B	001	PLASMA COAT INNER FLANGE SNAP DIAMETER	-		2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package D					2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package D	003	PLASMA COAT OUTER FLANGE FRONT FACE	-		2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package E					2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package E	004	PLASMA COAT OUTER FLANGE SNAP DIAMETER	-		2420
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package F					1295
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package F	005	RESTORE CORROSION PROTECTIVE COATING	-		1295
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package J					2220
72-35-67	PW4000	673637	4	28	51H530 55H302	PW4 HPC REAR SUPPORT	Package J	009	INNER FACE FRONT FLANGE PLASMA COAT REPAIR	-		2220
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package B					11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package B	ASSEMBLY02	MACHINE STAGE 5 - 15 OUTER AIR SEAL SET	-		11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB00					11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB00	PW4ENG 72-755	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	BOEING		11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB00	PW4ENG 72-756	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	AIRBUS		11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB00	PW4ENG 72-757	MODIFICATION OF TO INCORPORATE A RING CASE CONFIGURATION REAR HPC	MD11		11990
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB01					11675
72-35-69	PW4000	14014	21	28	58H574 58H596	HIGH PRESSURE COMPRESSOR (HPC) STAGES 5 THROUGH 15 HPC OUTER AIR SEAL SET	Package SB01	PW4ENG 72-845	INTRO OF NEW HPC FRONT DRUM	-		11675

72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package O	054	INNER REAR FLANGE NUT PLATE REPLACEMENT REPAIR	-	1275
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package P				6245
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package P	015	WELD REPAIR FLANGE J BOLT HOLE CRACKS	-	6245
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Q				1340
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Q	056	SURFACE DAMAGE BLEND REPAIR	-	1340
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Y				6245
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Y	051	PISTON RING SEAL DIA. PLASMACOAT	-	6245
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Z				3625
72-35-69	PW4000	72341	25	28	58H367	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 94"	Package Z	070	CASE WALL CRACK WELD REPAIR	-	3625
72-35-69	PW4000	139326	16	28	HPC REAR CASE-14.	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package B				4780
72-35-69	PW4000	139326	16	28	HPC REAR CASE-14.	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package B	-	MACHINING OF ASSY STATORS (STAGE 8-15)	-	4780
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package A				1355
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1355
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AA				4390
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AA	048	REAR SNAP DIAMETER PLASMA COAT REPAIR	-	4390
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AE				5280
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AE	052	REAR W SEAL SHOULDER PLASMA COAT OR DUAL WIRE ELECTRIC ARC COAT REPAIR	-	5280
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AF				4995
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AF	053	STAGE 9 W SEAL SHOULDER PLASMA COAT REPAIR	-	4995
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AI				1455
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AI	056	SURFACE DAMAGE BLEND REPAIR	-	1455
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AL				2025
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AL	071	INSERT REPLACEMENT REPAIR	-	2025
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AM				1380
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AM	054	INNER REAR FLANGE NUT PLATE AND GANG NUT CHANNEL REPLACEMENT REPAIR	-	1380
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AN				2425
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package AN	072	REAR SUPPORT REPLACEMENT REPAIR	-	2425
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package C				3120
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package C	017	WELD REPAIR INNER FLANGE BOLT HOLE CRACKS	-	3120
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package D				785
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package D	022	REPLACE HELICAL COIL INSERTS	-	785
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package E				5460
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package E	023	REPLACE HARDFACE ON 8/9TH STG STATOR BEARING SURFACE	-	5460

72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package V	041	REPLACE THE IDENTIFICATION BRACKET	-	2000
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package W				2755
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package W	067	REAR CASE ASSEMBLY WELD REPAIR	-	2755
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package Z				2590
72-35-69	PW4000	139822	41	28	50S060-01 50S061 55H203-01 56H397-01	HIGH PRESSURE COMPRESSOR (HPC) HPC OUTER REAR CASE ASSEMBLY - 100"	Package Z	047	FRONT FLANGE FACE PLASMA COAT REPAIR	-	2590
72-35-69	PW4000	671061	4	28	50S069	PW4 RCC REAR SUPPORT HPC REAR CASE	Package A				620
72-35-69	PW4000	671061	4	28	50S069	PW4 RCC REAR SUPPORT HPC REAR CASE	Package A	CLN/INSP	CLEANING & INSPECTION	-	620
72-35-71	PW4000	137752	19	28	50R402 70H249	HIGH PRESSURE COMPRESSOR (HPC) GEARBOX DRIVESHAFT HOUSING SUPPORT CLEVIS	Package A				95
72-35-71	PW4000	137752	19	28	50R402 70H249	HIGH PRESSURE COMPRESSOR (HPC) GEARBOX DRIVESHAFT HOUSING SUPPORT CLEVIS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	95
72-35-72	PW4000	673782	3	28	50R403 70R148	PW4 GEARBOX DRIVESHAFT HOUSING SUPPORT	Package A				225
72-35-72	PW4000	673782	3	28	50R403 70R148	PW4 GEARBOX DRIVESHAFT HOUSING SUPPORT	Package A	CLN/INSP	CLEANING & INSPECTION	-	225
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package A				445
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	445
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package AN				650
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package AN	-	STOP NUTS REPLACEMENT	ACCORDING SPM 70-00-00	650
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package B				5175
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package B	001	NICKEL PLATE REPAIR FOR COMPRESSOR CYLINDER SUPPORT ASSEMBLY LOWER JOURNALS	-	5175
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package C				5955
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package C	002	NICKEL PLATE REPAIR FOR COMPRESSOR CYLINDER SUPPORT ASSEMBLY UPPER JOURNALS	-	5955
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package D				4205
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package D	003	NICKEL PLATE REPAIR FOR HOLES	-	4205
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package E				3140
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package E	004	REPAIR OF WORN LOWER ATTACHMENT HOLES	-	3140
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package F				3215
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package F	005	RESTORE THICKNESS OF WORN LOWER SUPPORT LEAVES - (SVA BRACKET)	-	3215
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package I				3215
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package I	008	RESTORE THICKNESS OF WORN LOWER SUPPORT LEAVES	-	3215
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package K				3600
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package K	010	REPAIR OF CRACKS IN SVA BRACKET FLANGE	-	3600
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package M				3420
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package M	012	RIVET REPLACEMENT REPAIR ON STIFFENING PANELS	-	3420
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package Q				1400
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package Q	016	EPOXY COAT REPLACEMENT REPAIR	-	1400
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package R				2145

72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package R	017	NUT PLATE NUT REPLACEMENT REPAIR	-	2145
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package S800				1100
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package S800	PWAENG 72-685	PROVIDE A NEW COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY WITH A BRACE THAT HAS A CLEARANCE CUT	-	1100
72-35-73	PW4000	138380	30	28	51H229-01 53H036-01 53H214-01 54H967 54H974-01 54H975-01 58H032-01 58H033-01	HIGH PRESSURE COMPRESSOR (HPC) COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY	Package S800	PW4G-100-72-130	PROVIDE A NEW COMPRESSOR STATOR CYLINDER SUPPORT ASSEMBLY WITH A BRACE THAT HAS A CLEARANCE CUT	-	
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package A				1075
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package B				1705
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package B	001	PLASMA SPRAY HPC INLET LEVER OD JOURNAL	-	
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package S800				600
72-35-74	PW4000	138166	24	28	50H552 53H090	HIGH PRESSURE COMPRESSOR (HPC) LEVER SET	Package S800	PWAENG 72-246	INCORPORATION OF A MORE DURABLE COMPRESSOR STATOR CYLINDER SUPPORT WITH REVISED RIG PIN SLOTS	-	
72-35-76	PW4000	654928	4	28	1A7891 50H602 54H933	PW4 HPC CLEAVISES	Package A				165
72-35-76	PW4000	654928	4	28	1A7891 50H602 54H933	PW4 HPC CLEAVISES	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-78	PW4000	135900	25	28	1A4447	HIGH PRESSURE COMPRESSOR (HPC) ROD END BEARINGS	Package A				185
72-35-78	PW4000	135900	25	28	1A4447	HIGH PRESSURE COMPRESSOR (HPC) ROD END BEARINGS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-78	PW4000	135900	25	28	1A4447	HIGH PRESSURE COMPRESSOR (HPC) ROD END BEARINGS	Package B				335
72-35-78	PW4000	135900	25	28	1A4447	HIGH PRESSURE COMPRESSOR (HPC) ROD END BEARINGS	Package B	001	BEARING REPLACEMENT	-	
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package A				515
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package B				1510
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package B	001	ANTIGALLING COMPOUND REPLACEMENT REPAIR	-	
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package C				445
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package C	002	WASHER OR RIVET REPLACEMENT REPAIR	-	
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package D				3845
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package D	003	PLASMA COAT REPAIR	-	
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package S800				1935
72-35-80	PW4000	62545	33	28	50S027 50S028 50S311-01 58H401 58H402 58H404 58H416-01 58H417-01 58H418 58H419 58H420 58H422-01 58H423 58H424	HIGH PRESSURE COMPRESSOR (HPC) HEAT SHIELDS	Package S800	PWAENG 72-783	MODIFY THE LOWER HALF OF THE HEATSHIELD TO INCORPORATE AN ANTI-ROTATION FEATURE (PART B)	-	
72-35-81	PW4000	655333	4	28	50S025-01 50S026-01 58H403 58H425 58H426 58H567	PW4 RETAINER AND COVER, HEAT SHIELD HPC	Package A				360
72-35-81	PW4000	655333	4	28	50S025-01 50S026-01 58H403 58H425 58H426 58H567	PW4 RETAINER AND COVER, HEAT SHIELD HPC	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-82	PW4000	655336	3	28	58H438-01	PW4 SPACER SET, HPC	Package A				210
72-35-82	PW4000	655336	3	28	58H438-01	PW4 SPACER SET, HPC	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package A				560
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package B				375
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package B	001	BLEND THE SURFACE DAMAGE	-	
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package C				375
72-35-83	PW4000	62452	20	28	58H344-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 8 HPC CASE ASSEMBLY	Package C	002	REPLACE THE REAR FLANGE BOLTS	-	
72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package A				570
72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package F				2450
72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package F	005	PLASMA SPARY THE REAR SNAP DIAMETERS	-	
72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package G				2450

72-35-84	PW4000	62426	22	28	50S013-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 9 HPC CASE ASSEMBLY	Package G	006	PLASMA SPRAY THE REAR FLANGE FACE	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package A				355
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package F				565
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package F	005	FLANGE BOLTS REPLACEMENT REPAIR	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package G				430
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package G	006	SURFACE DAMAGE BLEND REPAIR	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package H				535
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package H	007	PIN (FLARED ASSEMBLY) REPLACEMENT REPAIR	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package I				650
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package I	008	BORESCOPE BOSS REPLACEMENT REPAIR	-	
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package J				620
72-35-85	PW4000	62427	19	28	58H348-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 10 HPC CASE ASSEMBLY	Package J	009	NUT ASSEMBLY REPLACEMENT REPAIR	-	
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package A				380
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package F				505
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package F	005	TOUCH-UP COAT REPAIR (PWA 77 COATED PARTS)	-	
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package G				500
72-35-86	PW4000	62428	19	28	58H317	HIGH PRESSURE COMPRESSOR (HPC) STAGE 11 HPC CASE ASSEMBLY	Package G	006	SURFACE DAMAGE BLEND REPAIR (PWA 77 COATED PARTS)	-	
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package A				375
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package F				525
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package F	005	FRONT AND REAR FLANGE BOLTS REPLACEMENT REPAIR	-	
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package G				490
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package G	006	TOUCH UP COAT REPAIR	-	
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package H				435
72-35-87	PW4000	62429	19	28	58H318-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 12 HPC CASE ASSEMBLY	Package H	007	SURFACE DAMAGE BLEND REPAIR	-	
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package A				380
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package F				395
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package F	005	REAR FLANGE BOLTS REPLACEMENT REPAIR	-	
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package G				505
72-35-88	PW4000	62451	19	28	58H320-01	HIGH PRESSURE COMPRESSOR (HPC) STAGE 13 HPC CASE ASSEMBLY	Package G	006	TOUCH-UP COAT REPAIR	-	

72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package G	006		SMOOTH OUT DAMAGE TO THREADS	-	
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package I					495
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package I	008		REPAIR THREADED HOLES - HELICAL COIL REPLACEMENT	-	
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package J					495
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package J	009		BLEND SURFACE DAMAGE	-	
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package K					270
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package K	INSP/CHK-05		LEAK CHECK	-	
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package S800					340
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package S800	PW4ENG 72-684		INSPECTION FOR MICROSHREEN KAGE	-	
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package U					540
72-41-08	PW4000	137765	29	28	503362 503362-001 503362-001P10 503362-001P15 503362-001P20 503362-001P5 503362P10 503362P15 503362P5 511153	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 94"	Package U	020		JACKSCREW HOLE THREAD REPAIR	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package A					600
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package A	CLN/INSP		CLEANING AND INSPECTION	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package F					1065
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package F	005		REPLACE RETAINING PIN(S)	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package G					535
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package G	006		SMOOTH OUT DAMAGE TO THREADS	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package I					765
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package I	008		REPAIR THREADED HOLES - HELICAL COIL REPLACEMENT	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package K					810
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package K	010		CLINCH NUT REPLACEMENT	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package S					795
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package S	018		BLEND SURFACE DAMAGE	-	
72-41-08	PW4000	139762	29	28	50J764 50J764-001 50J764-001P10 50J764-001P15 50J764-001P20 50J764-001P5 50J764P5	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) SEAL RING HOLDER ASSEMBLY - 100"	Package S800	72-216526		INSPECTION OF NO. 3 BRG COMPRESSOR FRONT SUMP THIN WALL	-	
72-41-09	PW4000	137634	8	21	50J059 50J584 50J584-001 50J623 50J623-001 50J625-001 50J640 50J696 50J776 50J776-001 50J777 50J777-001 50J818-001 50J819 50J820 51J323-01 51J331-01 51J333	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) FACE SEAL ASSEMBLY - 94"	Package A					300
72-41-09	PW4000	137634	8	21	50J059 50J584 50J584-001 50J623 50J623-001 50J625-001 50J640 50J696 50J776 50J776-001 50J777 50J777-001 50J818-001 50J819 50J820 51J323-01 51J331-01 51J333	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (FRONT) FACE SEAL ASSEMBLY - 94"	Package A	CLN/INSP		CLEANING AND INSPECTION	-	
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package A					405
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package A	CLN/INSP		CLEANING AND INSPECTION	-	
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package B					680
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package B	001		SMOOTH OUT DAMAGE TO THREADS	-	
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package E					3335
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package E	004		NICKEL PLATE REPAIR THE COOLING DUCT FRONT SNAP DIAMETER	-	
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package E	004		PLASMA COAT REPAIR THE COOLING DUCT FRONT SNAP DIAMETE	-	3335
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package F					3605
72-41-10	PW4000	137771	29	28	50J337 50J504 50J782	DIFFUSER AND COMBUSTOR - NO. 3 BEARING HOUSING	Package F	005		NICKEL PLATE REPAIR THE COOLING DUCT REAR SNAP DIAMETER	-	3605

72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package S	018	REPLACE NO. 4 THROUGH 6 LINERS REPAIR	-	4830
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB00				2670
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB00	PW4ENG 72-152	IGNITOR PLUG INSP. OF FOR WEAR	& COMBUSTION CHAMBER ASSEMBLY, OUTER IGNITOR GUIDE - MODIFICATION OF	2670
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB04				11915
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB04	PW4ENG 72-572	CONVERSION OF A PW4152, PW4156A, PW4158 ENGINE TO A PW4152(-3), PW4156A(-3), OR PW4158(-3) ENGINE	AIRBUS	11915
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB05				555
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package SB05	PW4ENG 72-601	CHAMBER ASSY, OUTER COMBUSTION - MODIF. OF TO INCORP. AN IGNITER GUIDE ASSEMBLY THAT WILL NOT ROTATE	-	555
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package U				2145
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package U	020	REPLACE BULKHEAD ASSEMBLY REPAIR	-	2145
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package W				745
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package W	022	REPLACE BULKHEAD HARDFACE REPAIR	-	745
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package X				2145
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package X	023	REPLACE ONE NOZZLE STATOR AND POSITIONING RINGS	-	2145
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Y				2800
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Y	024	REPAIR FUEL NOZZLE GUIDE RIVET HOLE	-	2800
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Z				2520
72-41-11	PW4000	137576	30	28	503464-001 503464-01 503488-001 503488-01 503612-01 503748-01 503943-001 503943-01 503944-001 503944-01 503994-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Z	025	WELD THE MOUNT LUGS	-	2520
72-41-11	PW4000	139736	24	28	511092 511102 511104 511105 511106 511204 511206 511208 511209 511301 511303 511504 521202 521203 521205 521207 521210	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - LINER SEGMENT - 100"	Package B				555
72-41-11	PW4000	139736	24	28	511092 511102 511104 511105 511106 511204 511206 511208 511209 511301 511303 511504 521202 521203 521205 521207 521210	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - LINER SEGMENT - 100"	Package B	060	PLASMA COATING REPLACEMENT	-	555
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package A				3165
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	3165
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AA				3330
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AA	026	WELD REPAIR WEAR ON BULKHEAD FRONT FACE	-	3330
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AC				1645
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AC	037	STRESS-RELIEF CYCLE FOR OUTER COMBUSTION CHAMBER ASSEMBLY	-	1645
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AG				1830
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AG	041	PLASMA COAT BUILD-UP REPAIR	-	1830
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AI				1310
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AI	064	COMBUSTION CHAMBER DOME DAMAGE WELD REPAIR	-	1310
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AJ				1080
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AJ	035	RADIAL SHRINKAGE ON DOME SNAP DIAMETER REPAIR	-	1080
72-41-11	PW4000	139750	35	28	521200 521200-001 541200 541300 541300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AM				1255

72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AM	071	REAR SHELL STIFFENER WELD REPAIR	-	1235
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AN				1575
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package AN	073	REAR STIFFENER WELD REPAIR	-	1575
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package D				785
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package D	003	REPLACE THE HARDFACE ON THE SNAP DIAMETER REPAIR	-	785
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package E				670
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package E	036	REPLACE HARDFACE ON REAR STIFFENER REPAIR	-	670
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package F				3850
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package F	005	BULKHEAD CRACK WELD REPAIR	-	3850
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package G				5435
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package G	006	BULKHEAD CRACK PATCH REPAIR	-	5435
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package H				1065
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package H	007	MOUNT LUG BUSHING REPLACEMENT	-	1065
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package O				1620
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package O	039	REPLACE IGNITER GUIDE ASSEMBLY	-	1620
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package P				670
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package P	040	RESIZE REAR STIFFENER PLASMA REPAIR	-	670
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Q				6995
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Q	038	REPLACE LINER SEGMENTS	-	6995
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package S800				615
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package S800	PW4G-100-72-74	MODIFICATION OF TO INCORPORATE A SPARK IGNITER GUIDE WITH ANTI-ROTATION FEATURE	-	615
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package S801				4630
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package S801	PW4G-100-72-253	REPLACEMENT OF, WITH WASPALOY NUTS TO REDUCE NUT LIBERATION	-	4630
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package W				600
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package W	022	REPLACE BULKHEAD HARDFACE REPAIR	-	600
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package X				2590
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package X	023	REPLACE ONE NOZZLE STATOR AND POSITIONING RINGS	-	2590
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Y				2900
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Y	024	REPAIR FUEL NOZZLE GUIDE RIVET HOLE	-	2900
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Z				3035
72-41-11	PW4000	139750	35	28	52J200 52J200-001 54J200 54J300 54J300-001	DIFFUSER AND COMBUSTOR - OUTER COMBUSTION CHAMBER ASSEMBLY - 100"	Package Z	025	WELD THE MOUNT LUGS	-	3035
72-41-11	PW4000	144410	5	28	50J479 50J781	PW4 (94") STATOR, FUEL NOZZLE	Package B				170
72-41-11	PW4000	144410	5	28	50J479 50J781	PW4 (94") STATOR, FUEL NOZZLE	Package B	001	REPLACE FUEL NOZZLE GUIDE HARDFACE	-	170
72-41-11	PW4000	144410	5	28	50J479 50J781	PW4 (94") STATOR, FUEL NOZZLE	Package C				105
72-41-11	PW4000	144410	5	28	50J479 50J781	PW4 (94") STATOR, FUEL NOZZLE	Package C	002	REPLACE FUEL NOZZLE GUIDE CERAMIC COAT	-	105

72-41-19	PW4000	137849	31	21	501489-01 501605-01 501614 501662-01 501762-01 511032-01 511035-01 511194-01 511196-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (BREATHER) TUBE ASSEMBLY	Package SB00	PW4ENG 72-696	INSPECTION OF WELD BEAD GROOVE	-	255
72-41-19	PW4000	137849	31	21	501489-01 501605-01 501614 501662-01 501762-01 511032-01 511035-01 511194-01 511196-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (BREATHER) TUBE ASSEMBLY	Package SB03				270
72-41-19	PW4000	137849	31	21	501489-01 501605-01 501614 501662-01 501762-01 511032-01 511035-01 511194-01 511196-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (BREATHER) TUBE ASSEMBLY	Package SB03	PW4G-100-72-144	NO3 BRG BREATHER TUBE,INSP.WELD GROOVE	-	270
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package A				210
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	PN501108 FOR SHOP VISIT ONLY	210
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB00				270
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB00	PW4G-100-72-193	INSPECTION OF TO REMOVE TUBES WHICH MAY HAVE WELD CONTAMINATION	-	270
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB01				160
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB01	AOWC9264-G57233	NUMBER 3 BEARING COMPARTMENT OIL PRESSURE TUBE WELD CRACK	-	160
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB02				80
72-41-20	PW4000	137798	29	21	501108 501604-01 511041-01	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OIL) PRESSURE TUBE ASSEMBLY	Package SB02	AD 2010-24-09	INSPECTION ACC. AD	IN CONJUNCTION WITH PACKAGE A	80
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package A				205
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package A	CLN/INSP	CLEANING AND INSPECTION	PN501352P10 501352P15 FOR SHOP VISIT ONLY	205
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package B				105
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package B	INSP-03	BLEND REPAIR	-	105
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package C				2350
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package C	002	CHROMIUM PLATE NO. 3 BEARING TRANSFER TUBE INSIDE DIAMETER FOR WEAR GREATER THAN 2.3265 INCHES	-	2350
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package D				270
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package D	003	REPAIR SEAL RING GROOVE	-	270
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package E				1545
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package E	004	WELD REPAIR SEAL LANDS	-	1545
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package F				240
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package F	005	REPAIR SEAL RING GROOVE	-	240
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package G				1545
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package G	006	SEAL LANDS WELD REPAIR	-	1545
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package H				1175
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package H	007	LUGS WELD REPAIR	-	1175
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package I				1105
72-41-21	PW4000	137912	24	21	501352 501352P10 501352P15 5013926	DIFFUSER AND COMBUSTOR - NO. 3 BEARING PACKING TRANSFER TUBE	Package I	008	PLASMA COAT REPAIR	-	1105
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package A				245
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package A	CLN/INSP	CLEANING AND INSPECTION	-	245
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package C				905
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package C	002	REPAIR SEAL RING GROOVE	PN 501603-01	905
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package C	005	REPAIR SEAL RING GROOVE	PN 511039-01	
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package D				415
72-41-22	PW4000	137656	25	28	501603-01 511039-01	NO.3 BEARING AND AIRFRAME (OIL VENT AND TURBINE COOLING AIR DUCT SENSING OUTER) MANIFOLD ASSEMBLIES	Package D	003	RESTORE ANTIGALLING COMPOUND	-	

72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package D	003	REPAIR SEAL RING GROOVE	-	255
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package E				920
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package E	004	REPAIR SEAL LANDS	-	920
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package F				170
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package F	005	REPAIR SEAL RING GROOVE	-	170
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package G				1550
72-41-28	PW4000	137406	16	21	501233 50J916	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING FRONT) TUBE	Package G	006	SEAL LANDS WELD REPAIR	-	1550
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package A				500
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package A	CLN/INSP	CLEANING AND INSPECTION	-	500
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package C				1770
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package C	002	CHROMIUM PLATE SEAL RING TRANSFER TUBE INSIDE DIAMETER FOR WEAR GREATER THAN 1.2015 INCHES (30.518MM)	-	1770
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package D				410
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package D	003	REPAIR SEAL RING GROOVE	-	410
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package E				845
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package E	004	REPAIR SEAL LANDS	-	845
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package F				165
72-41-29	PW4000	137914	20	21	501234 50J925	DIFFUSER AND COMBUSTOR - SEAL RING TRANSFER (NO. 3 BEARING COOLING REAR) TUBE	Package F	005	REPAIR SEAL RING GROOVE	-	165
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package A				185
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	185
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package B				2155
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package B	001	CHROMIUM PLATE ID SEAL LAND	-	2155
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package C				2060
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package C	002	NICKEL PLATE REAR OD PILOT DIAMETER	-	2060
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package D				695
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package D	003	SHIELD WELD BEAD REPAIR	-	695
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package E				780
72-41-30	PW4000	137403	26	21	50J093	DIFFUSER AND COMBUSTOR - NO. 3 BEARING ELBOW ASSEMBLY (NO. 3 BEARING COMPARTMENT COOLING TUBE)	Package E	004	SHIELD CRACK WELD REPAIR	-	780
72-41-31	PW4000	137836	31	21	501112 50J619-01 51J033-01	DIFFUSER AND COMBUSTOR - TURBINE BLADE COOLING TUBES	Package A				210
72-41-31	PW4000	137836	31	21	501112 50J619-01 51J033-01	DIFFUSER AND COMBUSTOR - TURBINE BLADE COOLING TUBES	Package A	CLN/INSP	CLEANING AND INSPECTION	-	210
72-41-31	PW4000	137836	31	21	501112 50J619-01 51J033-01	DIFFUSER AND COMBUSTOR - TURBINE BLADE COOLING TUBES	Package B				1950
72-41-31	PW4000	137836	31	21	501112 50J619-01 51J033-01	DIFFUSER AND COMBUSTOR - TURBINE BLADE COOLING TUBES	Package B	002	CHROMIUM PLATE TURBINE BLADE COOLING TUBES INSIDE DIAMETER	-	1950

72-41-81	PW4000	137834	28	28	50A076 51J322	DIFFUSER AND COMBUSTOR - NO. 3 BEARING SEAL SPACER	Package E	INSP	BLEND DAMAGE INSPECTION/CHECK-03	-	
72-41-82	PW4000	137571	4	28	50A126 50A127 50A128 51A726 52A115	PW4 BEARING ROLLER NO. 3 MAIN	Package A				800
72-41-82	PW4000	137571	4	28	50A126 50A127 50A128 51A726 52A115	PW4 BEARING ROLLER NO. 3 MAIN	Package A	CLN/INSP	Cleaning and inspection	-	
72-41-82	PW4000	137571	4	28	50A126 50A127 50A128 51A726 52A115	PW4 BEARING ROLLER NO. 3 MAIN	Package A				425
72-41-82	PW4000	137571	4	28	50A126 50A127 50A128 51A726 52A115	PW4 BEARING ROLLER NO. 3 MAIN	Package A	PW4ENG 72-372	NO.3 BRG. EDDY CURRENT INSP./SPEC.UNITS	-	
72-41-83	PW4000	137790	25	28	50A160	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OUTER RACE) RETAINING NUT	Package A				285
72-41-83	PW4000	137790	25	28	50A160	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OUTER RACE) RETAINING NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-41-83	PW4000	137790	25	28	50A160	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OUTER RACE) RETAINING NUT	Package B				765
72-41-83	PW4000	137790	25	28	50A160	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OUTER RACE) RETAINING NUT	Package B	001	REPLACE SILVER PLATE	INCLUDING CLEANING, FPI AND INSPECTION	
72-41-83	PW4000	137790	25	28	50A160	DIFFUSER AND COMBUSTOR - NO. 3 BEARING (OUTER RACE) RETAINING NUT	Package B	002	BLEND REPAIR	-	765
72-41-84	PW4000	137572	3	28	50A532 51A367	PW4 NO.3 BEARING REAR SEAL SEAT	Package A				225
72-41-84	PW4000	137572	3	28	50A532 51A367	PW4 NO.3 BEARING REAR SEAL SEAT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	225
72-41-85	PW4000	668091	5	28	51A562-002	CARBON SEAL ASSEMBLY BRG.3 REAR	Package A				1085
72-41-85	PW4000	668091	5	28	51A562-002	CARBON SEAL ASSEMBLY BRG.3 REAR	Package A	CLN/INSP	DISASSEMBLY, CLEANING, ASSEMBLY, TEST	-	1085
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package A				420
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package A	CLN/INSP	CLEANING AND INSPECTION	-	420
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package A	INSP-05	LEAK CHECK	-	
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package D				3055
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package D	003	REPLACE RETAINING PIN	-	
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package F				305
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package F	005	INSERT REPLACEMENT REPAIR	-	
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package M				305
72-41-86	PW4000	137773	12	28	50A712-01	NO. 3 BEARING SEAL RING HOLDER	Package M	012	BLEND SURFACE DAMAGE (MPN 50A712-01)	-	
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package A				420
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package A	INSP-05	INSP/CHK-05 LEAK CHECK	-	420
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package B				2790
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package B	001	NICKEL PLATE INSIDE SNAP DIA	-	2790
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package C				1275
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package C	002	SEAL RING GROOVE REPAIR	-	1275
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package D				3055
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package D	003	REPLACE RETAINING PIN	-	3055
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package E				2790
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package E	004	NICKEL PLATE FRONT SNAP INNER DIA	-	2790
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package F				305
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package F	005	INSERT REPLACEMENT REPAIR	-	305
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package L				305
72-41-86	PW4000	673681	4	28	50A478	PW4 NO.3 BEARING SEAL RING HOLDER NICKEL	Package L	011	BLEND SURFACE DAMAGE	MPN 50A478	305
72-41-87	PW4000	137570	2	28	50A099 50A472 50A707 50A707-001 50A757 50A757-001 51A082-001 51A085 51A273 51A369 51A369-001 51A370 51A370-001 51A559-001 51A560 51A561 51J324-01 51J332-01 51J334	PW4 NO.3 BEARING (REAR) FACE SEAL ASSY	Package A				285
72-41-87	PW4000	137570	2	28	50A099 50A472 50A707 50A707-001 50A757 50A757-001 51A082-001 51A085 51A273 51A369 51A369-001 51A370 51A370-001 51A559-001 51A560 51A561 51J324-01 51J332-01 51J334	PW4 NO.3 BEARING (REAR) FACE SEAL ASSY	Package A	CLN/INSP	CLEANING & INSPECTION	-	285
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package A				380
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	380
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package B				1655
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package B	001	NICKEL PLATE REPAIR OF NO. 3 BEARING REAR COOLING DUCT ASSEMBLY OUTER SNAP DIAMETER	-	1655
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package C				1555
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package C	002	NICKEL PLATE REPAIR OF NO. 3 BEARING REAR COOLING DUCT ASSEMBLY INNER SNAP DIAMETER	-	1555
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package D				665
72-41-88	PW4000	137806	29	28	50A435	DIFFUSER AND COMBUSTOR - NO. 3 BEARING REAR COOLING DUCT ASSEMBLY	Package D	003	RESTORE ANTIGALLING COMPOUND	-	665

72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package P	015	INNER FLANGE BOLT HOLE CRACKS WELD REPAIR	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package R				3070
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package R	017	OUTER FLANGE FRONT FACE PLASMA SPRAY REPAIR	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB00				3405
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB00	PW4G-100-72-109	INCORP. OF ADDITIONAL PLATFORM AND AIRFOIL COOLING WHICH REQUIRES A NEW FIRST STAGE HPT COOLING DUCT	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB01				630
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB01	PW4G-100-72-172	INSPECTION AND MODIFICATION OF THE VANE CAVITIES	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB02				1465
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB02	PW4G-100-72-219	MODIFICATION OF TO INCORPORATE THE ADVANTAGE 70 PERFORMANCE	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB03				2425
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB03	PW4G-100-72-220	CONVERSION OF PW4164 PW4168 OR PW4168A TO A PW4164-1D PW4168-1D PW4168A-1D OR PW4170 ENGINE	MODIFY OLD ASSY TO THE NEW FLOW CONFIGURATION	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB04				3250
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package SB04	000696-ED01	MODIFICATION TO INCREASE TOBI FLOW	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package Y				2955
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package Y	024	OUTER FLANGE REAR FACE PLASMA COAT REPAIR	-	
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package Z				530
72-51-03	PW4000	139725	27	28	50K138-001 50K138-01 50K373-001 50K373-01 50K610-01 50K610-101	TURBINE NOZZLE - STAGE 1 HPT (BLADE) COOLING DUCT ASSEMBLY-100"	Package Z	025	BLEND REPAIR	-	
72-51-04	PW4000	652198	3	28	50A197 50A710	PW4 DEFLECTOR, HPT COOLING DUCT	Package A				260
72-51-04	PW4000	652198	3	28	50A197 50A710	PW4 DEFLECTOR, HPT COOLING DUCT	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package A				2215
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package A				2215
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AA				1575
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AA	026	STRESS RELIEVE	-	1575
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AC				835
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AC	028	SIZE THE REAR SUPPORT	-	835
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AH				3250
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AH	033	SUPPORT MATING FACE PLASMA COAT REPAIR	-	3250
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AK				945
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AK	006	WELD REPAIR INNER LINER CRACKS IN THE CONSTANT THICKNESS SECTION	2ND WELD REPAIR	945
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AL				945
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package AL	007	WELD REPAIR INNER LINER CRACKS EXTENDING INTO DOUBLE PASS SECTION	2ND WELD REPAIR	945
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package C				440

72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package C	001	ONE LUG NUT PLATE REPLACEMENT REPAIR	-	440
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package D				630
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package D	002	HARDFACE SUPPORT MATING FACE REPAIR	-	630
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package E				740
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package E	004	HARDFACE FRONT LINER	-	740
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package F				3680
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package F	005	RESTORE PWA 265 PLASMA COAT REPAIR	SOURCE DEMO	3680
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package G				3680
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package G	006	WELD REPAIR INNER LINER CRACKS IN THE CONSTANT THICKNESS SECTION	-	3680
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package H				3480
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package H	007	WELD REPAIR INNER LINER CRACKS EXTENDING INTO DOUBLE PASS SECTION	-	3480
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package I				3950
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package I	008	PATCH WELD REP. INNER LINER CRACKS > 0.030 INCH (0.762 MM) AND EXT. INTO THE DOUBLE PASS SECTION	-	3950
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package J				255
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package J	009	RESTORE COMBUSTION CHAMBER LOUVER GAP	-	255
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package K				2720
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package K	010	CRACK WELD REPAIR COMBUSTION CHAMBER ASSEMBLY REAR SUPPORT PLATE	-	2720
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package L				1885
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package L	011	REPLACE INNER COMBUSTION CHAMBER (REAR) SUPPORT PLATE	-	1885
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package N				3275
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package N	013	REPLACE NO. 1 AND 2 COMBUSTION CHAMBER LINER SEGMENTS	-	3275
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package O				6245
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package O	014	REPLACE NO. 4 AND 5 COMBUSTION CHAMBER LINER SEGMENTS	-	6245
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package P				3125
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package P	015	REPLACE NO. 7 AND 8 COMBUSTION CHAMBER LINER SEGMENTS	-	3125
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Q				1230
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package Q	016	SIZE THE FRONT LINER	-	1230
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package R				2350
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package R	017	WELD REPAIR LINER LOUVER TRAILING EDGE	-	2350
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package S800				2340
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package S800		MODIFICATION OF COMBUSTION CHAMBER OUTER/INNER LINER	ACCORDING TO SB PW4ENG 72-187.1 AND SB PW4ENG 73-73, PAGE 2	2340
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package S801				4985
72-51-05	PW4000	137581	33	28	50K359-01 50K464-01 50K488-01	TURBINE NOZZLE - INNER COMBUSTION CHAMBER ASSEMBLY - 94"	Package S801	PW4ENG 72-490	CONVERSION OF A PW4460 OR PW4460 (-3) OR PW4462 (-3)	MCDONELL DOUGLAS	4985

72-51-10	PW4000	652199	4	28	50K069 50K258-01 51K210-01	COMBUSTION CHAMBER GUIDE PLATE	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package A				745
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package B				1095
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package B	001	HPT BRUSH SEAL REPLACEMENT REPAIR	-	
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package E				305
72-51-12	PW4000	139229	32	28	50K154-01	TURBINE NOZZLE - STAGE 1 HPT BRUSH SEAL AND SUPPORT ASSEMBLY	Package E	004	SURFACE DAMAGE BLEND REPAIR	-	
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package A				400
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package B				980
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package B	001	HARDFACE REPLACEMENT REPAIR	-	
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package C				505
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package C	002	TAB BLEND REPAIR	-	
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package D				1400
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package D	003	TAB WELD REPAIR	-	
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package E				1340
72-51-80	PW4000	139738	26	28	50K037 51K209-01 51K211-01	TURBINE NOZZLE - COMBUSTION CHAMBER CLAMP ASSEMBLY	Package E	004	WELD JOINT CRACK WELD REPAIR	-	
72-51-99	PW4000	135901	23	28	50A176 50A726-01	TURBINE NOZZLE - TURBINE NOZZLE MISCELLANEOUS PARTS - 94"	Package A				150
72-51-99	PW4000	135901	23	28	50A176 50A726-01	TURBINE NOZZLE - TURBINE NOZZLE MISCELLANEOUS PARTS - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-51-XX	PW4000	661211	2	21	PW4000 MOD-51/1	PW4 INNER COMBUSTION CASE (PARTS) 94"	Package A				1030
72-51-XX	PW4000	661211	2	21	PW4000 MOD-51/1	PW4 INNER COMBUSTION CASE (PARTS) 94"	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package A				1215
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package B				2515
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package B	001	AIRSEAL DIAMETER PLASMA SPRAY REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package C				4005
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package C	002	INNER FRONT DIAMETER PLASMA COAT REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package D				5065
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package D	003	INNER DIAMETER PLASMA COAT REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package E				1975
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package E	004	SURFACE DAMAGE BLEND REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package F				5305
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package F	005	PLASMA SPRAY REPAIR TURBINE INTERMEDIATE HUB (STAGE 2) MATING SNAP DIAMETER	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package G				3730
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package G	006	FRONT INNER ROTATING AIRSEAL SNAP DIAMETER PLASMA SPRAY REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package H				1990
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package H	007	FRONT BEARING SPACER MATING FACE MACHINE REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package I				860
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package I	008	FRONT HUB SHOTPEEN REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package J				780
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package J	009	LOCK LUGS BLEND REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package K				935
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package K	010	CLINCH NUT REPLACEMENT REPAIR	-	
72-52-05	PW4000	45343	34	28	50LS01 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package L				5240

72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package L	011	FRONT INNER ROTATING AIRSEAL OUTER SNAP DIAMETER PLASMA SPRAY REPAIR	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package O				1225
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package O	014	FRONT BEARING SPACER MATING FACE PLASMA COAT REPAIR	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package P				2025
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package P	015	MACHINE FRONT OUTER AIRSEAL DIAMETER TO SIZE	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package Q				1510
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package Q	016	REAR OUTER SNAP DIAMETER PLASMA COAT REPAIR	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package R				685
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package R	017	SURFACE DAMAGE REPAIR	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S800				520
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S800	AD 2005-25-09	FPI LIFE-LIMITED PART, HUB TURBINE FRONT	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S801				520
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S801	PW4ENG 72-736	PW4152(-3), PW4156A(-3), OR PW4158(-3) ENGINE	-	
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S801	PW4G-100-72-176	FPI OF HPT HUBS & OUTER AIRSEAL, 1ST & 2ND STG	-	520
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S802				5080
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S802	PW4ENG 72-504	CONVERSION OF A PW4052, PW4056, PW4060 TO A PW4052(-3), PW4056(-3) OR PW4060(-3)	-	5080
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S803				165
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S803	PW4ENG 72-795	INTRODUCTION OF THE ADVANTAGE PERFORMANCE UPGRADE CONFIGURATION TO IMPROVE HPT PERFORMANCE	(INSPECTION ONLY)	165
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S804				2525
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S804	PW4ENG 72-572	CONVERSION OF A PW4152, PW4156A, PW4158 ENGINE TO A PW4152(-3), PW4156A(-3), OR PW4158(-3) ENGINE	-	2525
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S805				455
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S805	PW4ENG 72-828	INTRODUCTION OF FOR COMMONALITY AND PROVIDE A PROCEDURE TO IDENTIFY FRONT HUBS THAT HAVE FULL LIFE	-	455
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S806				2525
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S806	PW4ENG 72-490	CONVERSION OF A PW4460 OR PW4462 TO A PW4460 (-3) OR PW4462 (-3)	-	2525
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S807				455
72-52-05	PW4000	45343	34	28	50L501 51L201 51L201-021 51L901 52L301 52L401 55L061 55L111	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 1)	Package S807	PW4G-100-72-250	PROVIDE A PROCEDURE TO IDENTIFY FRONT HUB ASSEMBLIES THAT HAVE FULL LIFE	-	455
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package A				1215
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1215
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package B				7125
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package B	001	PLASMA SPRAY OUTER SNAP DIAMETER - STAGE 2 (ROTATING) AIRSEAL CONTACT WEAR	-	7125
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package C				7125
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package C	002	PLASMA SPRAY INNER SNAP DIAMETER - STAGE 2 (ROTATING) AIRSEAL CONTACT WEAR	-	7125
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package D				1890
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package D	003	MACHINE NUT COUPLING MATING FACE	-	1890
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package E				1365
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package E	004	SHOTPEEN HUB	-	1365
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package F				4080
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package F	005	NICKEL PLATE REPAIR STAGE 2 HPT BLADE RETAINING PLATE AXIAL SNAP TURBINE INTERMEDIATE HUB (STAGE 2)	-	4080
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package I				2095
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package I	008	SURFACE DAMAGE BLEND REPAIR	-	2095
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package J				4715
72-52-06	PW4000	24651	46	28	50L602 50L602-001 50L602-021 50L602-022 50L602-023 50L602-024 50L602-025 50L602-026 50L602-027 50L902 50L902-021 50L902-022 50L902-023 52L002 52L002-021 52L402 52L802 53L602 55L102 55L112	HIGH PRESSURE TURBINE (HPT) - TURBINE FRONT HUB (STAGE 2)	Package J	009	INNER HPC SHAFT PILOT DIAMETER PLASMA COAT/DUAL WIRE ELECTRIC ARC COAT REPAIR	-	4715

72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB00	PW4ENG 72-490	CONVERSION OF A PW4460 OR PW4460 (-3) OR PW4462 (-3)	-	520
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB01				500
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB01	PW4ENG 72-504	CONVERSION OF A PW4052, PW4056, PW4060, TO A PW4052(-3), PW4056(-3), OR PW4060(-3)	-	500
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB02				520
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB02	PW4ENG 72-572	CONVERSION OF A PW4152, PW4156A, PW4158 ENGINE TO A PW4152(-3), PW4156A(-3), OR PW4158(-3) ENGINE	-	520
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB03				1310
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB03	PW4ENG 72-157	CASE & VANE ASSY, TURBINE - MODIFICATION OF TO INCORPORATE A SECOND STAGE TURBINE BORESCOPE PORT.	-	1310
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB04				6780
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB04	PW4ENG 72-392	CASE ASSY, HPT - MAKE A MODIFICATION TO MACHINE SCALLOPS IN M AND N FLANGES	-	6780
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB05				3050
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB05	PW4ENG 72-34	CASE & VANE ASSY, TURBINE - MODIF. OF THE CAST CASE ASSY & THE 1ST STG HPT DUCT SUPPORT	& REPL. OF THE 2ND & 1ST STG HPT DUCT SUPPORT SEALS, & 2ND STG HPT DUCT SUPPORT ASSEMBLY.	3050
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB06				2790
72-52-30	PW4000	137767	37	28	50L291 50L324 50L324-001 50L338-002 50L440 50L440-001 50L440-003 50L440-004 50L533 50L533-001 50L533-002 50L542 50L548-003 50L669 50L870 50L870-001 50L870-002 50L870-003 50L888-01	HIGH PRESSURE TURBINE (HPT) - TURBINE CASE ASSEMBLY	Package SB06	PW4ENG 72-462	ROTOR AND STATOR, HPT MODULE - INCORPORATE OF ADDITIONAL COOLING HOLES AND NEW SEALS	-	2790
72-52-31	PW4000	137582	12	28	50L276 50L278 50L371 50L372 53L218 55L028	PW4 STAGE 1 HPT DUCT SUPPORT ASSEMBLY	Package A				100
72-52-31	PW4000	137582	12	28	50L276 50L278 50L371 50L372 53L218 55L028	PW4 STAGE 1 HPT DUCT SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	100
72-52-31	PW4000	137582	12	28	50L276 50L278 50L371 50L372 53L218 55L028	PW4 STAGE 1 HPT DUCT SUPPORT ASSEMBLY	Package SB00				125
72-52-31	PW4000	137582	12	28	50L276 50L278 50L371 50L372 53L218 55L028	PW4 STAGE 1 HPT DUCT SUPPORT ASSEMBLY	Package SB00	PW4NG 72-34	MODIFICATION OF THE CASTCASE ASSY AND 1ST STAGE HPT DUCT SUPPORT ASSY	REPLACEMENT OF 2ND AND 1ST STAGE HPT DUCT SUPPORT SEALS AND 2ND STAGE HPT DUCT SUPPORT ASSY	125
72-52-32	PW4000	137751	5	28	50L494 50L497 50L627 50L628 53L133 53L228 53L236	PW4000 STAGE 1 HPT DUCT SEGMENT	Package A				95
72-52-32	PW4000	137751	5	28	50L494 50L497 50L627 50L628 53L133 53L228 53L236	PW4000 STAGE 1 HPT DUCT SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	95
72-52-32	PW4000	137751	5	28	50L494 50L497 50L627 50L628 53L133 53L228 53L236	PW4000 STAGE 1 HPT DUCT SEGMENT	Package C				500
72-52-32	PW4000	137751	5	28	50L494 50L497 50L627 50L628 53L133 53L228 53L236	PW4000 STAGE 1 HPT DUCT SEGMENT	Package C	002	GRIND REPLACEMENT DUCT SEGMENTS	-	500
72-52-33	PW4000	139276	19	28	50L247-01 55L032-01	HIGH PRESSURE TURBINE (HPT) - STAGE 1 HPT BAND SEGMENT	Package A				335
72-52-33	PW4000	139276	19	28	50L247-01 55L032-01	HIGH PRESSURE TURBINE (HPT) - STAGE 1 HPT BAND SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	335
72-52-33	PW4000	139276	19	28	50L247-01 55L032-01	HIGH PRESSURE TURBINE (HPT) - STAGE 1 HPT BAND SEGMENT	Package B				735
72-52-33	PW4000	139276	19	28	50L247-01 55L032-01	HIGH PRESSURE TURBINE (HPT) - STAGE 1 HPT BAND SEGMENT	Package B	001	CRACK REPAIR	-	735
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package A				95
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	95
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package C				500
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package C	002	GRIND REPLACEMENT DUCT SEGMENTS	-	500
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB00				480
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB00	72-795	INTRODUCTION OF THE ADVANTAGE PERFORMANCE UPGRADE CONFIGURATION TO IMPROVE HPT PERFORMANCE	-	480
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB01				480
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB01	PW4G-100-72-219	INCORPORATION OF THE ADVANTAGE 70 PERFORMANCE AND DURABILITY UPGRADE KIT	-	480
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB02				480
72-52-35	PW4000	137744	5	28	50L629 53L135	PW4 STAGE 2 DUCT SEGMENT	Package SB02	PW4G-100-72-220	CONVERSION OF A PW4168A ENGINE TO A PW4164-1D, PW4168-1D, PW4168A-1D, OR PW4170 ENGINE	-	480
72-52-36	PW4000	137419	18	28	50L246-01	HIGH PRESSURE TURBINE (HPT) - STAGE 2 HPT (DUCT) BAND SEGMENT	Package A				105
72-52-36	PW4000	137419	18	28	50L246-01	HIGH PRESSURE TURBINE (HPT) - STAGE 2 HPT (DUCT) BAND SEGMENT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	105
72-52-36	PW4000	137419	18	28	50L246-01	HIGH PRESSURE TURBINE (HPT) - STAGE 2 HPT (DUCT) BAND SEGMENT	Package B				680
72-52-36	PW4000	137419	18	28	50L246-01	HIGH PRESSURE TURBINE (HPT) - STAGE 2 HPT (DUCT) BAND SEGMENT	Package B	001	STAGE 2 HPT (DUCT) BAND SEGMENT ASSEMBLY	-	680
72-52-37	PW4000	137587	5	28	50L287 50L678	PW4 STAGE 2 HPT DUCT SUPPORT (SEGMENT)	Package A				340
72-52-37	PW4000	137587	5	28	50L287 50L678	PW4 STAGE 2 HPT DUCT SUPPORT (SEGMENT)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	340

72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package F	004	PLASMA SPRAY REPAIR REAR AIRSEAL SNAP DIAMETER (OD)	-	2035
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package G				2065
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package G	005	PLASMA SPRAY REPAIR FRONT AIRSEAL SNAP DIAMETER	-	2065
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package H				720
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package H	007	SHOTPEEN REPAIR	-	720
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package I				2160
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package I	008	PLASMA SPRAY AIRSEAL MATING FACE	-	2160
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package SB00				500
72-53-13	PW4000	137926	29	28	50N003 50N803	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT DISK	Package SB00	2005-25-09	FLUORESCENT PENETRANT INSPECTION (FPI)	IN CONJUNCTION WITH PACKAGE A	500
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package A				1360
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1360
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package B				1135
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package B	001	SURFACE DAMAGE BLEND REPAIR	-	1135
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package C				845
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package C	002	MACHINE REPAIR FRONT FACE	-	845
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package D				2950
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package D	003	REAR FLANGE FACE PLASMA SPRAY REPAIR	-	2950
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package E				4920
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package E	004	FRONT FLANGE FACE PLASMA SPRAY REPAIR	-	4920
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package F				3520
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package F	005	PLASMA SPRAY REPAIR REAR SNAP DIAMETER	-	3520
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package G				3520
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package G	006	PLASMA SPRAY REPAIR FRONT SNAP DIAMETER	-	3520
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package I				3660
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package I	008	REAR SNAP DIAMETER PLASMA SPRAY REPAIR	-	3660
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package J				3660
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package J	009	FRONT SNAP DIAMETER PLASMA SPRAY REPAIR	-	3660
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package K				4180
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package K	010	REAR FLANGE FACE PLASMA SPRAY REPAIR	-	4180
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package L				600
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package L	011	SHOTPEEN REPAIR	-	600
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package N				720
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package N	012	MACHINE REPAIR UNDERSIZED REAR SNAP INNER DIAMETER	-	720
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB00				1730
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB00	PW4G-100-72-105	MODIFICATION OF ENLARGING THE COOLING AIR HOLE AREA	-	1730
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB01				1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB02	AD 2005-25-09	FLUORESCENT PENETRANT INSPECTION (FPI)	IN CONJUNCTION WITH PACKAGE A	1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB02				1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB02	PW4ENG 72-657	ENLARGING OF THE COOLING AIR HOLE AREA	-	1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB03				1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB03	PW4G-100-72-264	LPT; REPL. AND/OR MOD. OF DISK & SEALS	-	1015
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB04				235
72-53-14	PW4000	15023	34	28	50N024 50N724 50N924 51N304 51N404 51N404-001 51N604	LOW PRESSURE TURBINE (LPT) - STAGE 4 LPT DISK ASSEMBLY	Package SB04	PW4ENG 72-658	INTRODUCTION OF A NEW SPARE PART DISK FOR ENGINES PRIOR TO SB PW4ENG 72-634	-	235
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package A				630
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package A	CLN/INSP	CLEANING AND INSPECTION	-	630
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package B				1015
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package B	001	SURFACE DAMAGE BLEND REPAIR	-	1015
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package C				1185
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package C	002	FRONT FACE MACHINE REPAIR	-	1185
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51N405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package D				3700

72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package D	003	FRONT FLANGE FACE PLASMA SPRAY REPAIR	-	3700
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package E			-	3395
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package E	004	INNER SNAP DIAMETER PLASMA SPRAY REPAIR	-	3395
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package F			-	3395
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package F	005	AIRSEAL MATING DIAMETER PLASMA COAT REPAIR	-	3395
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package G			-	3245
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package G	006	MATING SNAP DIAMETER PLASMA SPRAY REPAIR	-	3245
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package H			-	3405
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package H	007	MATING SNAP DIAMETER PLASMA SPRAY REPAIR	-	3405
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package J			-	2755
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package J	009	AIRSEAL SNAP DIAMETER PLASMA SPRAY REPAIR	-	2755
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package K			-	540
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package K	010	SHOTPEEN REPAIR	-	540
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package S800			-	440
72-53-15	PW4000	138148	23	28	50M405 50N505 51N305 51M405 51N505	LOW PRESSURE TURBINE (LPT) - STAGE 5 REAR TURBINE HUB	Package S800	AD 2005-25-09	FPI OF LIFE LIMITED PARTS	-	440
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package A			-	1250
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1250
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package B			-	635
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package B	001	KNIFE-EDGE SEALS BLEND REPAIR	-	635
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package C			-	910
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package C	002	SURFACE DAMAGE BLEND REPAIR	-	910
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package D			-	4930
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package D	003	FRONT FLANGE FACE PLASMA SPRAY REPAIR	-	4930
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package E			-	3825
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package E	004	SNAP DIAMETER PLASMA SPRAY REPAIR	-	3825
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package F			-	3825
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package F	005	RESTORE KNIFE-EDGE SEAL PLASMA COATING	-	3825
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package G			-	905
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package G	006	REPLACE FLANGE SEALS	-	905
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package P			-	610
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package P	015	SHOTPEEN REPAIR	-	610
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package S800			-	1225
72-53-16	PW4000	135911	27	28	50N286 50N486-01 50N666-01	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 94°	Package S800	AD 2005-25-09	FLUORESCENT PENETRANT INSPECTION (FPI)	IN CONJUNCTION WITH PACKAGE A	1225
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package A			-	1250
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1250
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package B			-	520
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package B	001	KNIFE-EDGE SEALS BLEND REPAIR	-	520
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package C			-	910
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package C	002	SURFACE DAMAGE BLEND REPAIR	-	910
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package J			-	4925
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package J	009	FRONT FLANGE FACE PLASMA SPRAY REPAIR	-	4925
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package K			-	3120
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package K	010	FRONT DIAMETER PLASMA SPRAY	-	3120
72-53-16	PW4000	139765	26	28	50N886 51N706	LOW PRESSURE TURBINE (LPT) - STAGE 6 LPT DISK ASSEMBLY - 100°	Package M			-	3510

72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - REAR TURBINE (LPT) CASE - 100°	Package AA	026	REPLACE RIVETED- ON ANGLED BRACKET (POST SB PW4ENG 72-336)	-	590
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AC			-	5800
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AC	039	MACHINE REPAIR VANE ANTI-ROTATION SLOTS TO REMOVE CRACKS (STAGE 3 AND STAGE 4)	-	5800
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AD			-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AD	029	STAGE 3 VANE REAR SUPPORT LIP MATING SURFACE PLASMA COAT REPAIR	-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AE			-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AE	030	STAGE 4 VANE REAR SUPPORT LIP MATING SURFACE PLASMA COAT REPAIR	-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AF			-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AF	031	STAGE 5 VANE REAR SUPPORT LIP MATING SURFACE PLASMA COAT REPAIR	-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AG			-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AG	032	STAGE 6 VANE REAR SUPPORT LIP MATING SURFACE PLASMA COAT REPAIR	-	5830
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AH			-	12620
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AH	033	STAGE 3 VANE HOOK INNER DIAMETER PLASMA COAT REPAIR	-	12620
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AK			-	3005
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AK	036	PLASMA SPRAY REPAIR FRONT FLANGE FACE (WITHOUT BRACKET)	-	3005
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AL			-	570
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AL	075	CRACK BLEND REPAIR STG. 3-6	-	570
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AM			-	455
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AM	038	REAR FLANGE BRACKET REPLACEMENT REPAIR	-	455
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AN			-	2980
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package AN	069	PLASMA REPAIR STG.4 VANE HOOK INN	-	2980
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package B			-	855
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package B	001	REPLACE FRONT FLANGE LOCATING PIN	-	855
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package C			-	1105
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package C	002	REPLACE REAR FLANGE LOCATING PIN	-	1105
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package D			-	580
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package D	003	REPAIR FRONT AND REAR FLANGE THREADS WITH HELICAL COIL INSERTS	-	580
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package F			-	1695
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package F	005	SURFACE DAMAGE BLEND REPAIR	-	1695
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package G			-	3440
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package G	006	STAGE 2 HPT SEAL MATING SURFACE PLASMA COAT REPAIR	-	3440
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package H			-	3350
72-53-17	PW4000	139782	31	35	51N348-01 51N548-01	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE - REAR TURBINE (LPT) CASE - 100°	Package H	037	PLASMA SPRAY REPAIR REAR FLANGE FACE (WITH BRACKET)	-	3350

72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package H	007	STUD REPLACEMENT REPAIR	-	715
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB00				1310
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB00	PW4ENG 72-513	3RD STG DUCT AND SEAL SUPPORT MODIFICATION	-	1310
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB01				1310
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB01	PW4ENG 72-294	3RD STG REPLACEMENT OF LPT DUCT SEAL	-	1310
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB02				1310
72-53-18	PW4000	137640	26	21	50N260 50N331 50N536	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) DUCT ASSEMBLY	Package SB02	PW4G-100-72-41	REPLACE/MODIFY THE 3RD STAGE LPT SEALING RING SUPPORT ASSY AND 3RD STAGE LPT DUCT SEGMENTS.	-	1310
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package A				535
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	535
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package B				980
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package B	001	REPLACE HARDFACE	-	980
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package D				5815
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package D	003	CRACK WELD REPAIR	-	5815
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package K				530
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package K	SPM	REMOVE AND INSTALL DAMPER RING	ACC. SPM 70-43-00	530
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package SB00				500
72-53-19	PW4000	137764	30	28	50N266 50N382-01 50N529-01 50N529-101	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING ASSEMBLY	Package SB00	PW4G-100-A72	LPT; REPL. AND/OR MOD. OF DISK & SEALS	-	500
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package A				490
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	490
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package B				505
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package B	001	REPLACE NUT PLATES	-	505
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package C				805
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package C	002	REPLACE DUCT	-	805
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package D				2055
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package D	003	PLASMA SPRAY REAR OUTER SURFACE	-	2055
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package H				4760
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package H	007	SUPPORT FLANGE AND SLOT WELD BUILD-UP REPAIR	-	4760
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package I				3300
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package I	008	SUPPORT FLANGE (FRONT FACE) WEAR AREA PLASMA SPRAY REPAIR	-	3300
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package K				1880
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package K	010	RIVET HOLE PLUG WELD REPAIR	-	1880
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package L				2960
72-53-20	PW4000	21176	20	28	50N265 50N537	LOW PRESSURE TURBINE (LPT) - STAGE 3 LPT (INNER) SEALING RING SUPPORT ASSEMBLY	Package L	011	RIVET HOLES WELD ATTACHMENT REPAIR	-	2960

72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	475
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package B				1005
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package B	001	REPLACE THE REAR FLANGE LOCATING PIN	-	1005
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package D				2405
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package D	003	PLASMA SPRAY REPAIR FRONT FLANGE SNAP DIAMETER	-	2405
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package E				2405
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package E	004	PLASMA SPRAY REPAIR REAR SNAP DIAMETER	-	2405
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package G				3480
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package G	006	WELD REPAIR VANE ANTI-ROTATION SLOT	-	3480
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package H				2605
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package H	007	PLASMA SPRAY REPAIR VANE REAR OD PLATFORM MATING SURFACE	-	2605
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package I				2605
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package I	008	PLASMA SPRAY REPAIR THE VANE REAR PLATFORM MATING FACE	-	2605
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package J				905
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package J	009	SURFACE DAMAGE BLEND REPAIR	-	905
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package J	010	ANTIROTATION SLOT FILLET RADII CRACK BLEND REPAIR	-	
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package L				3305
72-53-67	PW4000	139778	30	28	51N249-01	LOW PRESSURE TURBINE (LPT) - STAGE 7 LPT CASE ASSEMBLY - 100"	Package L	011	ANTIROTATION SLOT FILLET RADII CRACK WELD REPAIR	-	
72-53-70	PW4000	139780	2	28	51N418-01	PW4 STG 7 LPT (OUTER) AIRSEALING RING S	Package A				70
72-53-70	PW4000	139780	2	28	51N418-01	PW4 STG 7 LPT (OUTER) AIRSEALING RING S	Package A	CLN/INSP	CLEANING & INSPECTION	-	
72-53-71	PW4000	139764	24	28	50N322-01 50N565-01	LOW PRESSURE TURBINE (LPT) - TURBINE CASE (STAGE 6 AIRSEALING RING) HEAT SHIELD ASSEMBLY	Package A				105
72-53-71	PW4000	139764	24	28	50N322-01 50N565-01	LOW PRESSURE TURBINE (LPT) - TURBINE CASE (STAGE 6 AIRSEALING RING) HEAT SHIELD ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-71	PW4000	139764	24	28	50N322-01 50N565-01	LOW PRESSURE TURBINE (LPT) - TURBINE CASE (STAGE 6 AIRSEALING RING) HEAT SHIELD ASSEMBLY	Package B				610
72-53-71	PW4000	139764	24	28	50N322-01 50N565-01	LOW PRESSURE TURBINE (LPT) - TURBINE CASE (STAGE 6 AIRSEALING RING) HEAT SHIELD ASSEMBLY	Package B	001	DAMAGE AREA PATCH REPAIR	-	
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package A				1110
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AA				3975
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AA	026	NICKEL PLATE REPAIR FOR 7TH STAGE LPT AIRSEAL SHOULDER	-	
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AB				4200
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AB	027	FLANGE FACE PLASMA SPRAY REPAIR	-	
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AC				4200
72-53-80	PW4000	1275	32	35	51A377-01 52A519-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100"	Package AC	028	FLANGE SNAP DIAMETER PLASMA SPRAY REPAIR	-	

72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package O	014	FLANGE SNAP DIAMETER PLASMA SPRAY REPAIR	-	4075
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package P				2330
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package P	015	LOCAL TOUCH-UP REPAIR PROTECTIVE COATING (STEEL SHAFT)	-	2330
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package Q				1505
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package Q	016	SHAFT BALANCE (BY WAX APPLICATION) REPAIR	-	1505
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package SB00				280
72-53-80	PW4000	2382	47	35	50A077	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 94"	Package SB00	A72-328	EDDY CURRENT INSPECTION	-	280
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package A				1305
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	1305
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AA				4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AA	026	NICKEL PLATE REPAIR FOR 7TH STAGE LPT AIRSEAL SHOULDER	-	4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AB				4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AB	027	FLANGE FACE PLASMA SPRAY REPAIR	-	4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AC				4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AC	028	FLANGE SNAP DIAMETER PLASMA SPRAY REPAIR	-	4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AF				3350
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AF	031	INNER DIAMETER SPACER BORE PLASMA SPRAY REPAIR	-	3350
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AI				2390
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AI	034	PLASME COATE 6TH STAGE LPT AIRSEAL FRONT SNAP MATING DIAMETER	-	2390
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AM				3915
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AM	040	PROTECTIVE COAT REMOVAL AND COAT REPAIR	-	3915
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AN				2200
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package AN	039	COAT TOUCH-UP BY PWA 36252	-	2200
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package E				1340
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package E	004	REPAIR NO. 4 BEARING RETAINING PLATE HOLES	-	1340
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package R				4205

72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package R	017	SHAFT BALANCE (BY WAX APPLICATION) REPAIR	-	4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package S				4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package S	018	SURFACE DAMAGE BLEND REPAIR	-	4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package S	032	SHOTPEEN AFTER BLEND REPAIR	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package SB01				3605
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package SB01	PW4G-100-72-263	REPLACEMENT COATING	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package U				3980
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package U	020	REAR COUPLING PILOT DIAMETER PLASMA SPRAY REPAIR	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package V				875
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package V	021	FRONT COUPLING PILOT DIAMETER PLA	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package W				2670
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package W	022	NICKEL PLATE REPAIR NO. 4 BEARING RETAINING PLATE MATING DIAMETER	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package X				3980
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package X	023	MACHINE REPAIR FRONT SPACER SURFACE	-	
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package Z				4205
72-53-80	PW4000	655052	20	35	52A402-01 52A402-101 52A577-01	LOW PRESSURE TURBINE (LPT) - FRONT COMPRESSOR DRIVE TURBINE (LPT) SHAFT - 100" (POST SB 72-229)	Package Z	025	TIEBOLD HOLES BUSHING REPAIR	-	
72-53-81	PW4000	137318	25	28	50A083CL1 50A083CL10 50A083CL11 50A083CL12 50A083CL13 50A083CL14 50A083CL15 50A083CL16 50A083CL17 50A083CL18 50A083CL19 50A083CL2 50A083CL20 50A083CL21 50A083CL22 50A083CL23 50A083CL24 50A083CL25 50A083CL26 50A083CL27 50A083CL28 50A083CL29 50A083CL3 50A083CL30 50A083CL31 50A083CL32 50A083CL33 50A083CL34 50A083CL35 50A083CL36 50A083CL37 50A083CL38 50A083CL39	LOW PRESSURE TURBINE (LPT) - TURBINE SHAFT SPACER	Package A				155
72-53-81	PW4000	137318	25	28	50A083CL1 50A083CL10 50A083CL11 50A083CL12 50A083CL13 50A083CL14 50A083CL15 50A083CL16 50A083CL17 50A083CL18 50A083CL19 50A083CL2 50A083CL20 50A083CL21 50A083CL22 50A083CL23 50A083CL24 50A083CL25 50A083CL26 50A083CL27 50A083CL28 50A083CL29 50A083CL3 50A083CL30 50A083CL31 50A083CL32 50A083CL33 50A083CL34 50A083CL35 50A083CL36 50A083CL37 50A083CL38 50A083CL39	LOW PRESSURE TURBINE (LPT) - TURBINE SHAFT SPACER	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-81	PW4000	137318	25	28	50A083CL1 50A083CL10 50A083CL11 50A083CL12 50A083CL13 50A083CL14 50A083CL15 50A083CL16 50A083CL17 50A083CL18 50A083CL19 50A083CL2 50A083CL20 50A083CL21 50A083CL22 50A083CL23 50A083CL24 50A083CL25 50A083CL26 50A083CL27 50A083CL28 50A083CL29 50A083CL3 50A083CL30 50A083CL31 50A083CL32 50A083CL33 50A083CL34 50A083CL35 50A083CL36 50A083CL37 50A083CL38 50A083CL39	LOW PRESSURE TURBINE (LPT) - TURBINE SHAFT SPACER	Package B				535
72-53-81	PW4000	137318	25	28	50A083CL1 50A083CL10 50A083CL11 50A083CL12 50A083CL13 50A083CL14 50A083CL15 50A083CL16 50A083CL17 50A083CL18 50A083CL19 50A083CL2 50A083CL20 50A083CL21 50A083CL22 50A083CL23 50A083CL24 50A083CL25 50A083CL26 50A083CL27 50A083CL28 50A083CL29 50A083CL3 50A083CL30 50A083CL31 50A083CL32 50A083CL33 50A083CL34 50A083CL35 50A083CL36 50A083CL37 50A083CL38 50A083CL39	LOW PRESSURE TURBINE (LPT) - TURBINE SHAFT SPACER	Package B	001	MACHINE SPACER TO CHANGE CLASS	-	
72-53-82	PW4000	137366	18	28	50A433 51A312	LOW PRESSURE TURBINE (LPT) - TURBINE (SHAFT) TIEROD	Package A				80
72-53-82	PW4000	137366	18	28	50A433 51A312	LOW PRESSURE TURBINE (LPT) - TURBINE (SHAFT) TIEROD	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-83	PW4000	130005	20	28	51A299 51A306 51A307 51A535 51A536 51A569 51A570 51A571 787448 787449 787454 787455 H54133-8	LOW PRESSURE TURBINE (LPT) - TIEROD NUT	Package A				90
72-53-83	PW4000	130005	20	28	51A299 51A306 51A307 51A535 51A536 51A569 51A570 51A571 787448 787449 787454 787455 H54133-8	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE (LPT) - TIEROD NUT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-83	PW4000	130005	20	28	51A299 51A306 51A307 51A535 51A536 51A569 51A570 51A571 787448 787449 787454 787455 H54133-8	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE (LPT) - TIEROD NUT	Package B				95
72-53-83	PW4000	130005	20	28	51A299 51A306 51A307 51A535 51A536 51A569 51A570 51A571 787448 787449 787454 787455 H54133-8	LOW PRESSURE TURBINE (LPT) - LOW PRESSURE TURBINE (LPT) - TIEROD NUT	Package B	001	RESTORE SILVER PLATE	-	
72-53-84	PW4000	138805	13	28	51A578	LOW PRESSURE TURBINE (LPT) - NO 4 BEARING RETAINING PLATE	Package A				395
72-53-84	PW4000	138805	13	28	51A578	LOW PRESSURE TURBINE (LPT) - NO 4 BEARING RETAINING PLATE	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-53-84	PW4000	138805	13	28	51A578	LOW PRESSURE TURBINE (LPT) - NO 4 BEARING RETAINING PLATE	Package B				1005
72-53-84	PW4000	138805	13	28	51A578	LOW PRESSURE TURBINE (LPT) - NO 4 BEARING RETAINING PLATE	Package B	001	NICKEL PLATE REPAIR SNAP DIAMETER	-	

72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package L	057	CRACKS IN STRUT TO CASE ORIGINAL EQUIPMENT MANUFACTURER WELD BEAD WELD REPAIR	IN ASSEMBLED CONDITION	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package M				10090
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package M	012	REPLACE NO. 4 BEARING CARBON SEAL HOUSING	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package N				5560
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package N	013	PLASMA SPRAY REPAIR THE REAR OUTER FLANGE SNAP DIAMETER	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package O				5560
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package O	014	NICKEL PLATE REPAIR THE OUTER FRONT FLANGE SNAP DIAMETER	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package P				1520
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package P	015	OUTER FRONT FLANGE BOLTHOLE RADIAL EXTENTION	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Q				5265
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Q	016	PLASMA SPRAY REPAIR REAR INTERMEDIATE FLANGE SNAP DIAMETER	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package R				5005
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package R	017	WELD REPAIR INNER CASE AND SUPPORT STRUCTURE CRACKS	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S				5865
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S	018	PATCH REPAIR INNER CASE AND SUPPORT STRUCTURE	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S800				6840
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S800	PWAENG 79-	ROUTING OF THE BEARING NO. 4 OIL TUBES	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S801	76			1950
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S801	024	REPLACE STRUTS	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S802				1690
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S802	011	REPLACE NO. 4 BEARING SHIELD AND HEAT SHIELD ASSEMBLY	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S803				10960
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package S803	047	WELD REPAIR STRUT TO OUTER CASE FILLET RADIUS CRACKS	REWORK OF CARBON SEAL HOUSING NOT INCLUDED. SEE ATA 72-54-01.	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package T				7360
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package T	019	WELD REPAIR, LIGHTENING SLOT CRACKS (FLANGES R AND S)	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package U				4880
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package U	020	CHROMIUM PLATE NO. 4 BEARING SHOULDER	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package V				6260
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package V	021	BEARING SHOULDER CHROMIUM PLATE REPAIR	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package W				1895
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package W	058	OUTER CASE WALL INNER CENTER BODY, STRUT BODY STRUT INNER AND OUTER STAND-UPS WELD REPAIR	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package X				4200
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package X	023	SURFACE DAMAGE BLEND REPAIR	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Y				4200
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Y	053	STRUT OUTER STAND-UP TRAILING EDGE CRACK WELD REPAIR	-	
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Z				2205
72-54-01	PW4000	2553	52	35	50P027 50P174-01 50P200-01 50P416-001 50P417-001 50P418-001 50P418-01	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - 94*	Package Z	025	DRILL PURGE AND DRAIN HOLES IN EXHAUST CASE OUTER WALL AT STRUT LOCATIONS	-	
72-54-01	PW4000	137931	23	28	50P024	TURBINE EXHAUST CASE - HOUSING NO. 4 BRG SEAL OF TURBINE EXHAUST CASE	Package B				1755
72-54-01	PW4000	137931	23	28	50P024	TURBINE EXHAUST CASE - HOUSING NO. 4 BRG SEAL OF TURBINE EXHAUST CASE	Package B	047	NICKEL PLATE REPAIR THE FIT BETWEEN CARBON SEAL HOUSING AND TEC FLANGE INNER DIAMETER	-	
72-54-01	PW4000	137932	24	28	50P138 50P263	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - NO. 4 BRG HEATSHIELD	Package A				245
72-54-01	PW4000	137932	24	28	50P138 50P263	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - NO. 4 BRG HEATSHIELD	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-54-01	PW4000	137932	24	28	50P138 50P263	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - NO. 4 BRG HEATSHIELD	Package AB				990
72-54-01	PW4000	137932	24	28	50P138 50P263	TURBINE EXHAUST CASE - TURBINE EXHAUST CASE ASSEMBLY - NO. 4 BRG HEATSHIELD	Package AB	027	WELD REPAIR RIVET HOLE DAMAGE	TURBINE EXHAUST CASE ASSY REQUIRED!	

72-61-23	PW4000	137729	22	28	70R051 70R911	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package G	006	NICKEL PLATE THE FLANGE FACE	-	
72-61-23	PW4000	137729	22	28	70R051 70R911	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package H				990
72-61-23	PW4000	137729	22	28	70R051 70R911	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package H	007	REPLACE THE BUSHINGS IN THE MOUNT CLEVISSES	-	
72-61-23	PW4000	137729	22	28	70R051 70R911	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package I				2065
72-61-23	PW4000	137729	22	28	70R051 70R911	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package I	008	REPAIR THE REAR ID WITH A BUSHING	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package A				1020
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package B				280
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package B	001	LAP CARBON SEAL MATING FACE	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package C				1730
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package C	002	CHROMIUM PLATE CARBON SEAL MATING FACE	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package D				2475
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package D	003	CHROMIUM PLATE FRONT BEARING JOURNAL	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package D	005	PLATE THE FRONT BEARING SHOULDER WITH CHROMIUM	-	2475
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package E				2475
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package E	004	CHROMIUM PLATE REAR BEARING JOURNAL	-	2475
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package E	006	PLATE THE REAR BEARING SHOULDER WITH CHROMIUM	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package H				735
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package H	007	REPLACE THE BOLT	-	
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package S800				495
72-61-24	PW4000	137786	25	28	70R077 71R147-01	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package S800	PW4ENG 72-802	MODIFICATION AND REPLACEMENT TO IMPROVE DURABILITY	-	
72-61-25	PW4000	1711	10	28	70R650	PW4 COUPLING, GEARBOX (STARTER DRIVE)	Package A				935
72-61-25	PW4000	1711	10	28	70R650	PW4 COUPLING, GEARBOX (STARTER DRIVE)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package B				375
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package C				300
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package D				885
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package D	003	NICKEL PLATE THE OD	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package E				755
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package E	004	REPAIR THE FRONT ID WITH A BUSHING	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package F				755
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package F	005	REPAIR THE MIDDLE ID WITH A BUSHING	-	
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package G				875
72-61-26	PW4000	137732	22	28	70R065 71R117 71R169	MAIN GEARBOX - GEARBOX (STARTER DRIVE) GEARSHAFT ASSEMBLY	Package G	006	REPAIR THE REAR ID WITH A BUSHING	-	

72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package C	002	CHROMIUM PLATE FRONT BEARING JOURNAL	-	
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package C	004	PLATE THE FRONT BEARING SHOULDER WITH CHROMIUM	-	2590
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package D				2590
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package D	003	CHROMIUM PLATE REAR BEARING JOURNAL	-	2590
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package D	006	PLATE THE REAR BEARING SHOULDER WITH CHROMIUM	-	
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package E				510
72-61-29	PW4000	137832	27	28	70R010	MAIN GEARBOX - GEARBOX (REAR HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package E	005	LAP THE SEALING FACE	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package B				520
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package C				680
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package D				1380
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package D	003	NICKEL PLATE THE OD	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package E				1795
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package E	004	REPAIR THE FRONT ID WITH A BUSHING	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package F				1795
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package F	005	REPAIR THE MIDDLE ID WITH A BUSHING	-	
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package G				1795
72-61-30	PW4000	137730	23	28	70R061	MAIN GEARBOX - GEARBOX BEARING HOUSING ASSEMBLY	Package G	006	REPAIR THE REAR ID WITH A BUSHING	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package A				1065
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package B				370
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package B	001	LAP CARBON SEAL MATING FACE	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package C				630
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package C	002	REPLACE OIL SCOOP	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package D				1460
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package D	003	CHROMIUM PLATE FRONT SEALING FACE	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package E				1575
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package E	004	CHROMIUM PLATE SEALING FACE	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package F				2200
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package F	005	CHROMIUM PLATE FRONT BEARING JOURNAL	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package F	007	PLATE THE FRONT BEARING SHOULDER WITH CHROMIUM	-	2200
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package G				2200
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package G	006	CHROMIUM PLATE REAR BEARING JOURNAL	-	2200
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package G	008	PLATE THE REAR BEARING SHOULDER WITH CHROMIUM	-	
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package S800	PW4ENG 72-581	MODIFICATION OT TO REMOVE THE CUP PLUG	-	155
72-61-31	PW4000	137738	27	28	70R508 70R509 70R693 71R071 71R165	MAIN GEARBOX - GEARBOX IDG DRIVE SPUR GEARSHAFT ASSEMBLY	Package S801	PW4ENG 72-802	MODIFICATION AND REPLACEMENT TO IMPROVE DURABILITY	-	2200
72-61-31	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package B				520
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package C				325
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package D				1380

72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package D	003	NICKEL PLATE THE OD	-	
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package E				1795
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package E	004	REPAIR THE FRONT ID WITH A BUSHING	-	
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package F				1795
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package F	005	REPAIR THE MIDDLE ID WITH A BUSHING	-	
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package J				115
72-61-32	PW4000	137733	24	28	70R067	MAIN GEARBOX - GEARBOX IDG DRIVE BEARING HOUSING ASSEMBLY	Package J	SPM	REMOVE DEFECTIVE BOLTS FROM CLAMP	SPM 70-00-00-350-006/ SPOP 416	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package B				510
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package C				500
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package D				1050
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package D	003	NICKEL PLATE THE OIL METERING PLUG HOLE OUTSIDE BORE	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package E				1050
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package E	004	NICKEL PLATE THE OIL METERING PLUG HOLE INSIDE BORE	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package F				1115
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package F	005	NICKEL PLATE THE OD	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package G				1015
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package G	006	REPLACE DAMAGED OR LOOSE STUDS	-	
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package H				1210
72-61-33	PW4000	138379	22	28	70R529 70R637 70R698 70R969 70R976	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) BEARING HOUSING ASSEMBLY	Package H	007	BEARING SUPPORT BORE NICKEL PLATE REPAIR	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package A				1060
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package B				300
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package B	001	LAP CARBON SEAL MATING FACE	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package C				1140
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package C	002	NICKEL/CHROMIUM PLATE SEALING FACE	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package D				1140
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package D	003	CHROMIUM PLATE FRONT BEARING JOURNAL	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package E				1140
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package E	004	CHROMIUM PLATE REAR BEARING JOURNAL	-	
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package F				1140
72-61-34	PW4000	137831	24	28	70R011 70R691	MAIN GEARBOX - GEARBOX (FRONT HYDRAULIC PUMP DRIVE) SPUR GEARSHAFT	Package F	005	PLATE THE BEARING SHOULDER WITH CHROMIUM	-	

72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package C				500
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package C	002	APPLY ANODIZE TOUCH-UP SOLUTION	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package D				1175
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package D	003	NICKEL PLATE THE OD	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package E				1095
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package E	004	REPAIR THE FRONT ID WITH A BUSHING	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package F				1095
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package F	005	REPAIR THE MIDDLE ID WITH A BUSHING	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package G				380
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package G	006	REPLACE HELICAL COIL INSERTS	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package H				550
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package H	007	PMA DRIVE HOUSING BLEND REPAIR	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package I				415
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package I	008	PMA DRIVE HOUSING BLEND REPAIR	-	
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package SB00				500
72-61-47	PW4000	138381	22	28	70R234 70R633 70R771 70R902 71R003	MAIN GEARBOX - GEARBOX GENERATOR (EEC/PMA ALTERNATOR) HOUSING ASSEMBLY	Package SB00	78F-98.A	EEC GENERATOR HOUSING - TAPPING OF HOLES	-	
72-61-48	PW4000	138121	23	28	70R229 70R738	MAIN GEARBOX - GEARBOX BEARING SEAL SEAT	Package B				280
72-61-48	PW4000	138121	23	28	70R229 70R738	MAIN GEARBOX - GEARBOX BEARING SEAL SEAT	Package B	001	LAP CARBON SEAL MATING FACE	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package B				145
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package C				120
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package C	002	APPLY ANODIZE TOUCH-UP SOLUTION	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package D				135
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package D	003	PIN REPLACEMENT	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package E				1170
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package E	004	FRONT OUTER MATING DIAMETER NICKEL PLATE REPAIR	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package F				1170
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package F	005	REAR OUTER MATING DIAMETER NICKEL PLATE REPAIR	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package G				1230
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package G	006	FRONT FACE NICKEL PLATE REPAIR	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package H				1170
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package H	007	REAR FACE NICKEL PLATE REPAIR-	-	
72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package I				120

72-61-50	PW4000	139842	15	28	70R673	MAIN GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY (REAR)	Package I	008	INSERT REPLACEMENT REPAIR	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package A				365
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package B				280
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package C				275
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package C	002	APPLY ANODIZE TOUCH-UP SOLUTION	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package D				1140
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package D	003	NICKEL PLATE FRONT ID	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package F				1655
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package F	005	NICKEL PLATE TRANSFER TUBE HOLE ID	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package G				1815
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package G	006	NICKEL PLATE REAR FLANGE FACE	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package H				1385
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package H	007	BUSHING REPLACEMENT IN MOUNT CLEVISES	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package I				1015
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package I	008	NICKEL PLATE REAR ID	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package J				1795
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package J	009	NICKEL PLATE FRONT FLANGE FACE	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package K				1795
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package K	010	NICKEL PLATE ALTERNATOR PORT ID	-	
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package L				2350
72-61-52	PW4000	139843	25	28	70R675	MAIN GEARBOX - GEARBOX DRIVE SHAFT HOUSING ASSEMBLY (FRONT)	Package L	011	NICKEL PLATE BUSHING HOLE	-	
72-61-57	PW4000	136092	23	21	70R050	MAIN GEARBOX - GEARBOX DRIVESHAFT PRESSURE TUBE ASSEMBLY	Package B				565
72-61-57	PW4000	136092	23	21	70R050	MAIN GEARBOX - GEARBOX DRIVESHAFT PRESSURE TUBE ASSEMBLY	Package B	001	REPLACE ANTIGALLANT	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package B				370
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package C				305
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package D				765
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package D	003	REPAIR THE FRONT ID WITH A BUSHING	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package E				765
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package E	004	REPAIR THE MIDDLE IDS WITH A BUSHING	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package F				765
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package F	005	REPAIR THE REAR BORES WITH BUSHINGS	-	
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package H				660
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package H	006	REPLACE DAMAGED OR LOOSE STUDS	-	

72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package H	007	REPLACE DAMAGED OR LOOSE STUDS	-	660
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package S800				1050
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package S800	PW4ENG 72-701	MGB-OIL FILTER HOUSING-MODIF.WITH STUDS	-	1050
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package S801				915
72-61-60	PW4000	137734	24	28	51R184 70R093 70R647 70R647-001 70R654 70R914 70R914-001 70R962	MAIN GEARBOX - MAIN OIL FILTER HOUSING ASSEMBLY	Package S801	PW4ENG 72-525	OIL FILTER HOUSING ; NEW DUAL ELEMENT FILTER	-	915
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package A				130
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package A	CLN/INSP	CLEANING AND INSPECTION	-	130
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package AA	SPOP-21	Cadmium Plating	-	1730
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package B				500
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package B	001	Nickel Plate The Front OD Seal Lands	-	500
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package C				500
72-61-61	PW4000	137820	5	28	70R113	PW4 RELIEF VALVE HOUSING (PRESSURE REGULATOR)	Package C	002	Nickel Plate The Rear OD Seal Lands	-	500
72-61-62	PW4000	601742	3	28	70R114	PW4 PRESSURE (REGULATOR) RELIEF VALVE	Package B				405
72-61-62	PW4000	601742	3	28	70R114	PW4 PRESSURE (REGULATOR) RELIEF VALVE	Package B	001	CHROMIUM PLATE PILOT DIAMETER	-	405
72-61-63	PW4000	673857	2	28	70R112 70R115	PW4000 RELIEF VALVE PLUG AND SPRING	Package A				155
72-61-63	PW4000	673857	2	28	70R112 70R115	PW4000 RELIEF VALVE PLUG AND SPRING	Package A	CLN/INSP	CLEANING & INSPECTION	-	155
72-61-65	PW4000	139300	3	28	664508 740535	PW4 PRESSURE RELIEF VALVE (FILTER ELEMENT)	Package A				435
72-61-65	PW4000	139300	3	28	664508 740535	PW4 PRESSURE RELIEF VALVE (FILTER ELEMENT)	Package A	TEST	PRESSURE TEST	-	435
72-61-66	PW4000	664060	2	28	50R175 50R176 70R116 70R118 70R657 70R945-01 70T028	PW4 PACKING TRANSFER TUBES	Package A				205
72-61-66	PW4000	664060	2	28	50R175 50R176 70R116 70R118 70R657 70R945-01 70T028	PW4 PACKING TRANSFER TUBES	Package A	CLN/INSP	CLEANING & INSPECTION	-	205
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package A				390
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package A	CLN/INSP	CLEANING AND INSPECTION	-	390
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package B				1125
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package B	001	CHROMIUM PLATE LUG	-	1125
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package C				1220
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package C	002	NICKEL-CADMIUM PLATE REPAIR	-	1220
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package D				1400
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package D	001	NICKEL / CHROMIUM PLATE LUG	-	1400
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package S800				325
72-61-68	PW4000	2120	25	28	70R147 70R591 70R986 71R018 71R136	MAIN GEARBOX - GEARBOX LUG	Package S800	PW4ENG 72-538	MGB-INCORPORATE OF LUG WITH THREADED HOLE	-	325
72-61-69	PW4000	137710	22	28	70R639 70R666 70T520	MAIN GEARBOX - OIL TANK DEAERATOR ASSEMBLY	Package B				305
72-61-69	PW4000	137710	22	28	70R639 70R666 70T520	MAIN GEARBOX - OIL TANK DEAERATOR ASSEMBLY	Package B	001	ANODIZE TOUCH-UP	-	305
72-61-69	PW4000	137710	22	28	70R639 70R666 70T520	MAIN GEARBOX - OIL TANK DEAERATOR ASSEMBLY	Package C				370
72-61-69	PW4000	137710	22	28	70R639 70R666 70T520	MAIN GEARBOX - OIL TANK DEAERATOR ASSEMBLY	Package C	002	REPLACE HELICAL COIL INSERTS	-	370
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package A				240
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	240
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package B				970
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package B	001	REPLACE NUT PLATE	PNS0R315-01 FOR SHOP VISIT ONLY	970
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package C				635
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package C	002	WELD LOOSE INTERNAL PARTS	-	635
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package D				1450
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package D	003	NICKEL PLATE MOUNT FLANGE SEAL LANDS	-	1450
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package E				955
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package E	004	WELD OIL TANK CRACK AND SKIN PENETRATION	-	955
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package F				1185
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package F	005	REPAIR DENTS	-	1185
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package G				570
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package G	006	SURFACE DAMAGE BLEND REPAIR	-	570
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package I				2335
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package I	020	WELD OIL TANK CRACK AND SKIN PENETRATION	-	2335
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package J				1480
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package J	021	NICKEL PLATE REPAIR	-	1480
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package K				1480

72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package K	022	TUBE BOSS INNER DIAMETER NICKEL PLATE REPAIR	-	1480
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB00				2200
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB00	PW4ENG 79-56	INCORPORATION OF AN OIL FILLER NECK BRACE	-	2200
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB01				270
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB01	PW4ENG 79-47	REMOVAL OF OIL TANK REMOTE FILL OPTION	-	270
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB02				80
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package SB02	PW4ENG 79-65	RELOCAT, FILLER NECK, MINIMIZE DIHEDRAL	-	80
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package X				1450
72-61-73	PW4000	137907	28	28	50R315-01 50R367-01 50R380-01 51R053-01 51R118-01 51R126-01	MAIN GEARBOX - LUBE OIL TANK ASSEMBLY	Package X	023	WELD REPAIR ON SUMP PUMP LOCK WIRE TAB	-	1450
72-61-74	PW4000	138141	22	28	50R280-01 51R059-01 51R120-01	MAIN GEARBOX - OIL TANK HEAT SHIELD ASSEMBLY	Package B				440
72-61-74	PW4000	138141	22	28	50R280-01 51R059-01 51R120-01	MAIN GEARBOX - OIL TANK HEAT SHIELD ASSEMBLY	Package B	001	REPAIR DAMAGED AREA	-	440
72-61-75	PW4000	135917	22	28	50T067	MAIN GEARBOX - OIL TANK SUMP ASSEMBLY	Package B				310
72-61-75	PW4000	135917	22	28	50T067	MAIN GEARBOX - OIL TANK SUMP ASSEMBLY	Package B	001	REPAIR OF SURFACE DAMAGE	-	310
72-61-75	PW4000	135917	22	28	50T067	MAIN GEARBOX - OIL TANK SUMP ASSEMBLY	Package C				505
72-61-75	PW4000	135917	22	28	50T067	MAIN GEARBOX - OIL TANK SUMP ASSEMBLY	Package C	002	WELD REPAIR OF CRACKS	-	505
72-61-80	PW4000	652109	2	18	50R044 50R450	PW4 DRIVESHAFT, GEARBOX	Package A				1315
72-61-80	PW4000	652109	2	18	50R044 50R450	PW4 DRIVESHAFT, GEARBOX	Package A	CLN/INSP	CLEANING & INSPECTION	-	1315
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package A				580
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-	580
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package B				925
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package B	001	NICKEL PLATE THE FRONT SNAP DIAMETER	-	925
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package C				990
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package C	002	NICKEL PLATE THE REAR SNAP DIAMETER	-	990
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package D				410
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package D	003	SURFACE DAMAGE BLEND REPAIR	-	410
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package E				480
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package E	004	PIN AND COLLAR SEALING COMPOUND REPAIR	-	480
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package F				980
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package F	005	CRACK WELD REPAIR	-	980
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package G				380
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package G	006	BENT MOUNT TAB COLD STRAIGHTENING REPAIR	-	380
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package H				755
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package H	007	FLANGE BOLT HOLE WELD REPAIR	-	755
72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package M				315

72-61-81	PW4000	137737	25	28	50A559 51A006-01	MAIN GEARBOX - GEARBOX DRIVESHAFT (FRONT) HOUSING / HOUSING AND STRAINER ASSEMBLY	Package M	INSP/CHECK 3	REPLACE DRIVE SHAFT HOUSING HELICOIL	-		315
72-61-84	PW4000	656280	3	28	70T328	PW4 LINK GEARBOX SUPPORT	Package A					250
72-61-84	PW4000	656280	3	28	70T328	PW4 LINK GEARBOX SUPPORT	Package A	CLN/INSP	CLEANING AND INSPECTION	-		250
72-61-87	PW4000	673649	4	28	70T334	PW4 GEARBOX SUPPORT LINK LOWER HOLLOW PIN	Package A					175
72-61-87	PW4000	673649	4	28	70T334	PW4 GEARBOX SUPPORT LINK LOWER HOLLOW PIN	Package A	CLN/INSP	Cleaning and Inspection	-		175
72-61-90	PW4000	654914	3	28	70T332	GEARBOX UPPER SUPPORT LINK PIN SPACER	Package A					115
72-61-90	PW4000	654914	3	28	70T332	GEARBOX UPPER SUPPORT LINK PIN SPACER	Package A	CLN/INS	CLEANING & INSPECTION	-		115
72-61-93	PW4000	139844	13	28	70R680	MAIN GEARBOX - GEARBOX SPUR GEAR	Package A					345
72-61-93	PW4000	139844	13	28	70R680	MAIN GEARBOX - GEARBOX SPUR GEAR	Package A	CLN/INSP	CLEANING AND INSPECTION	-		345
72-61-93	PW4000	139844	13	28	70R680	MAIN GEARBOX - GEARBOX SPUR GEAR	Package B					1285
72-61-93	PW4000	139844	13	28	70R680	MAIN GEARBOX - GEARBOX SPUR GEAR	Package B	001	SILVER FLASH REPAIR	-		1285
72-61-99	PW4000	135938	4	28	51T430 52U565-01	MOUNT IGNITION EXCITER	Package A					390
72-61-99	PW4000	135938	4	28	51T430 52U565-01	MOUNT IGNITION EXCITER	Package A	CLN/INSP	CLEANING AND INSPECTION	-		390
72-61-99	PW4000	135938	4	28	51T430 52U565-01	MOUNT IGNITION EXCITER	Package B					460
72-61-99	PW4000	135938	4	28	51T430 52U565-01	MOUNT IGNITION EXCITER	Package B	SPM	REPLACE MOUNT RESILIENT	SPM 70-43-00 RIVETING		460
72-61-99	PW4000	626263	19	28	51U093 59T303-01 70R749 70R768 70R779-01	MAIN GEARBOX - MAIN GEARBOX MISCELLANEOUS PARTS	Package A					955
72-61-99	PW4000	626263	19	28	51U093 59T303-01 70R749 70R768 70R779-01	MAIN GEARBOX - MAIN GEARBOX MISCELLANEOUS PARTS	Package A	CLN/INSP	CLEANING AND INSPECTION	-		955
72-61-99	PW4000	626263	19	28	51U093 59T303-01 70R749 70R768 70R779-01	MAIN GEARBOX - MAIN GEARBOX MISCELLANEOUS PARTS	Package B					2010
72-61-99	PW4000	626263	19	28	51U093 59T303-01 70R749 70R768 70R779-01	MAIN GEARBOX - MAIN GEARBOX MISCELLANEOUS PARTS	Package B	001	PROTECTIVE COAT REPLACEMENT REPAIR	-		2010
72-62-00	PW4000	665212	4	28	50G000 50G000-002 51G000 51G000-01	GEARBOX ASSEMBLY-ANGLE	Package A					2325
72-62-00	PW4000	665212	4	28	50G000 50G000-002 51G000 51G000-01	GEARBOX ASSEMBLY-ANGLE	Package A	ASSEMBLY	ASSEMBLY AIRBUS	-		2325
72-62-00	PW4000	665212	4	28	50G000 50G000-002 51G000 51G000-01	GEARBOX ASSEMBLY-ANGLE	Package A	ASSEMBLY	ASSEMBLY BOEING	-		2325
72-62-00	PW4000	665212	4	28	50G000 50G000-002 51G000 51G000-01	GEARBOX ASSEMBLY-ANGLE	Package A	ASSEMBLY	ASSEMBLY MD11	-		2325
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package A					1575
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		1575
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package B					730
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-		730
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package C					440
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-		440
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package D					535
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package D	003	SURFACE DAMAGE BLEND REPAIR	-		535
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package E					2095
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package E	004	PLATE THE GEARBOX HOUSING ID WITH NICKEL	-		2095
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package F					1840
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package F	005	BOTTOM COVER ID NICKEL PLATE REPAIR	-		1840
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package G					2590
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package G	006	PLATE THE SNOUT WITH NICKEL	-		2590
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package H					1305
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package H	007	HOLLOW PIN REPLACEMENT REPAIR	-		1305
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package I					1815
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package I	008	REPLACE THE BUSHING	-		1815
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package J					2465
72-62-01	PW4000	137718	22	28	50G001	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package J	009	UPPER BEARING JOURNAL BUSHING REPAIR	-		2465
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package A					370
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package A	CLN/INSP	CLEANING AND INSPECTION	-		370
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package B					1105
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package B	001	CHROMIUM PLATE OR PWA 36206□1 COAT FRONT BEARING JOURNAL	-		1105
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package C					1140
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package C	002	CHROMIUM PLATE OR PWA 36206□1 COAT REAR BEARING JOURNAL	-		1140
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package D					1175
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package D	002	NICKEL AND CHROMIUM PLATE REAR BEARING JOURNAL	-		1175
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package E					1105

72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package E	003	CHROMIUM PLATE OR PWA 36206□1 COAT FRONT BEARING SHOULDER	-	1105
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package F				1105
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package F	004	CHROMIUM PLATE OR PWA 36206□1 COAT REAR BEARING SHOULDER	-	1105
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package G				530
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package G	005	SURFACE DAMAGE BLEND REPAIR	-	530
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package H				670
72-62-03	PW4000	138114	11	28	50G057 51G373	ANGLE GEARBOX BEVEL GEARSHAFT ASSY	Package H	006	REPLACE THE CUP PLUG	-	670
72-62-04	PW4000	2086	20	28	50G010 50G011 50G013 50G113 50G114 50G115 50G399 50G401 50G402 50G403 50G404 50G630 50G631 50G633 50G865 50G866 50G868 50G983 51G994 51G995 51G996 51G997 51G998 51G999 52G000 52G001 52G002 52G003 52G004 52G005 52G006 52G007 71R081 71R082	ANGLE GEARBOX - ANGLE GEARBOX BEARINGS	Package A				615
72-62-04	PW4000	2086	20	28	50G010 50G011 50G013 50G113 50G114 50G115 50G399 50G401 50G402 50G403 50G404 50G630 50G631 50G633 50G865 50G866 50G868 50G983 51G994 51G995 51G996 51G997 51G998 51G999 52G000 52G001 52G002 52G003 52G004 52G005 52G006 52G007 71R081 71R082	ANGLE GEARBOX - ANGLE GEARBOX BEARINGS	Package A	CLN/INSP	CLEANING AND INSPECTION	-	615
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package B				1560
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package B	001	REPLACE HELICAL COIL INSERTS	-	1560
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package B	006	REPAIR THE BORE WITH A BUSHING	-	
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package C				235
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package C	002	ANODIZE TOUCH-UP	-	
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package D				235
72-62-10	PW4000	137717	23	28	50G034	ANGLE GEARBOX - ANGLE GEARBOX HOUSING ASSEMBLY	Package D	003	SURFACE DAMAGE BLEND REPAIR	-	
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package B				145
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package B	001	ANODIZE TOUCH-UP	-	
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package C				465
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package C	002	SURFACE DAMAGE BLEND REPAIR	-	
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package C	010	SURFACE DAMAGE BLEND REPAIR	-	465
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package D				190
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package D	003	REPLACE HELICAL COIL INSERTS	-	190
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package E				1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package E	004	NICKEL PLATE REPAIR THE REAR FACE	-	1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package F				1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package F	005	NICKEL PLATE REPAIR THE REAR ID	-	1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package G				1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package G	006	NICKEL PLATE REPAIR THE FRONT FACE	-	1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package H				1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package H	007	NICKEL PLATE REPAIR THE FRONT OD	-	1105
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package I				2755
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package I	008	REAR BEARING JOURNAL BUSHING REPAIR	-	2755
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package J				2085
72-62-12	PW4000	136094	23	28	50G003	ANGLE GEARBOX - GEARBOX DRIVESHAFT HOUSING ASSEMBLY	Package J	009	FRONT BEARING JOURNAL BUSHING REPAIR	-	2085
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package A				390
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package A	CLN/INSP	CLEANING AND INSPECTION	-	390
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package B				170
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package B	001	SPLINE TEETH SURFACE DAMAGE BLEND REPAIR	-	170
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package C				980
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package C	002	FRONT FACE CHROMIUM PLATE REPAIR	-	980
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package D				1040
72-62-13	PW4000	137827	5	28	50G038	PW4 GEARBOX DRIVE COUPLING	Package D	003	FRONT INNER DIAMETER CHROMIUM PLATE REPAIR	-	1040
72-62-15	PW4000	137896	3	28	50G911 51G090 71R050	PW4000 NOZZLE ASSY ANGLE GEARBOX	Package B				175
72-62-15	PW4000	137896	3	28	50G911 51G090 71R050	PW4000 NOZZLE ASSY ANGLE GEARBOX	Package B	001	REPLACE PROTECTIVE COATING	-	175
72-62-15	PW4000	137896	3	28	50G911 51G090 71R050	PW4000 NOZZLE ASSY ANGLE GEARBOX	Package S800				715
72-62-15	PW4000	137896	3	28	50G911 51G090 71R050	PW4000 NOZZLE ASSY ANGLE GEARBOX	Package S800	PW4ENG 72-131	MODIFICATION OF AGB OIL NOZZLE ASSIES	-	715
72-62-17	PW4000	137895	3	28	50G492 51G088	PW4 ANGLE GEARBOX (REAR OIL) NOZZLE ASSY	Package B				175
72-62-17	PW4000	137895	3	28	50G492 51G088	PW4 ANGLE GEARBOX (REAR OIL) NOZZLE ASSY	Package B	001	REPLACE PROTECTIVE COATING	-	175
72-62-17	PW4000	137895	3	28	50G492 51G088	PW4 ANGLE GEARBOX (REAR OIL) NOZZLE ASSY	Package S800				715
72-62-17	PW4000	137895	3	28	50G492 51G088	PW4 ANGLE GEARBOX (REAR OIL) NOZZLE ASSY	Package S800	PW4ENG 72-131	MODIFICATION OF AGB OIL NOZZLE ASSIES	-	715

72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package E	006	INSTALL HELICAL TWINSETS	72-33-08		510
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package E	006	REPLACE HELICAL INSERTS	72-33-08		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package F					565
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package F	009	REPAIR DAMAGED INSULATION BLANKETS	72-33-08		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package G					1230
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package G	013	REPLACE LINER REPAIR	72-33-08		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package H					330
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package H	014	TOUCH UP ANODIZE REPAIR	72-33-04		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package I					1845
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package I	014	(ALUMINUM LINER) FAN CASE LINER	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package J					1650
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package J	014	(WIRE MESH LINER) FAN CASE LINER	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package K					3055
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package K	015	REPAIR FOR WEAR AND HOLES IN RUBSTRIP	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package L					635
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package L	019	BLEND SURFACE DAMAGE	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package M					1240
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package M	020	BLEND SURFACE DAMAGE	72-34-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package N					2645
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package N	023	ACUSTIC LINER BLEND REPAIR	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package N	023	LINER PROTECTIVE COATING REPLACEMENT	72-33-01		2645
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package N	023	REPLACE FOURTH STATOR MOUNTING FLANGE HELICAL COIL INSERTS	72-34-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package O					945
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package O	024	REPLACE HELICAL COIL INSERTS AT 2, 4 AND 8 O'CLOCK POSITION	72-34-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package P					1120
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package P	030	REPLACE PIN RIVET AND COLLAR	72-33-04		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Q					8155
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Q	034	FAIRING REPLACEMENT	72-34-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package R					330
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package R	034	REPLACE LPC SPLITTER FAIRING NUT	72-33-04		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package S					1465
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package S	34-1	LINER JOINT DISBOND REPAIR	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package S	34-2	LINER-INSERT DISBOND REPAIR	72-33-01		1465
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package S	34-3	LINER-JOINT FILLER REPAIR	72-33-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package T					540
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package T	035	REPLACE FRONT ANGLE GANG	72-33-04		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package U					715
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package U	041	APPLY ANODIZE TOUCH-UP SOLUTION	72-34-01		
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package U	063	APPLY ANODIZE TOUCH-UP SOLUTION	72-34-01		715
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package V					2195
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package V	042	REPAIR OF DAMAGED FOIL ON THE FIRE ABLATIVE BLANKETS	72-33-04		2195
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package W					1370
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package W	044	BLEND SURFACE DAMAGE ON THE FAN EXIT CASE FLANGE ASSEMBLY	72-34-01		1370
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package X					780
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package X	047	REPLACE FIRE SHIELD SEGMENT	72-33-04		780
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Y					4250
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Y	055	SEALANT REPAIR	72-34-01		4250
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Z					715
72-XX-XX	PW4000	672294	5	28	33_34_MOD_INSP_100	FAN AND INTERMEDIATE CASE ASSY 100"	Package Z	056	HELICAL E-FLANGE SCREW THREAD INSERTS	72-34-01		715
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package AN					2390

72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package AN	039	TOUCH-UP P/N 52A402-101 AND 52A577-01	72-53-80		2390
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package B					2190
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package B	001	FEATHERSEAL REPLACEMENT	72-00-53		2190
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package C					2190
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package C	002	FEATHERSEAL REPLACEMENT	72-00-53		2190
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package D					1730
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package D	003	3STG LEADING EDGE BLEND REPAIR	72-00-53		1730
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package P					2330
72-XX-XX	PW4000	672466	3	28	-	LOW PRESSURE TURBINE (LPT)	Package P	015	LOCAL TOUCH-UP COATING	72-53-80		2330
73-11-04	PW4000	131637	21	21	212844	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94" - BODY RELIEF VALVE	Package B					755
73-11-04	PW4000	131637	21	21	212844	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94" - BODY RELIEF VALVE	Package B	-	MASCHINE THE PISTON SEAT	ACCORDING CHM		755
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package B					2585
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package B	TEST	BENCH TEST	-		2585
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package C					370
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package C	TEST	PRE-TEST	-		370
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package E					4275
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package E	MEDIUM	REPAIR	-		4275
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package G					7395
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package G	-	OVERHAUL	EASA, FAA		7395
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB00					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB00	711000-73-7/ATC	PW4-FUEL PUMP-THRUST BEAR.ANTI FRETT.PAD	-		480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB01					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB01	711000-73-11	PW4-FUEL PUMP-IMPR.STATIONARY SHAFT SEAL	-		480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB02					940
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB02	PW4ENG 73-104	PW4-FUEL PUMP-NEW PUMP HOUSING	-		940
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB03					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB03	711000-73-15/AT	INTRODUCTION OF NEW FILTER COVER LOCKING NUTS	-		480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB04					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB04	711000-73-14/AT	INTRODUCTION OF NEW MAIN STAGE BEARING	-		480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB05					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB05	711000-73-16/AT	REPLACEMENT OF STATIONARY SHAFT SEAL PREFORMED PACKING	-		480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB06					480
73-11-04	PW4000	132793	12	21	718801-5 718801-6 718801-7 720301-5 720301-6 720301-7 721001-7	FUEL PUMP	Package SB06	IA 069881	PW4-FUEL PUMP HOUSING-CRACK INSP./REPAIR	-		480
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package B					2670
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package B	TEST	BENCH TEST	READJUSTMENT AND TESTING		2670
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package C					105
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package C	-	CRACK INSPECTION OF GEAR HOUSING	-		105
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package C	TEST	PRE TEST AND TROUBLE SHOOTING	IN CONJUNCTION WITH PACKAGE LIGHT, MEDIUM OR HEAVY		2315
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package D					2315
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package D	LIGHT	DISASSEMBLY,CLEANING, INSPECTION, ASSEMBLY AND FINAL TEST. EXCLUDED PIECE PART REPAIRS.	EXAMPLE: BODY RELIEF VALVE OR PISTON RELIEF VALVE OR SEAL SHAFT STATIONARY REPLACEMENT		3175
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package E					3175
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package E	MEDIUM	DISASSEMBLY,CLEANING, INSPECTION, ASSEMBLY AND FINAL TEST. EXCLUDED PIECE PART REPAIRS.	EXAMPLE: SHAFT DRIVE MAIN REPLACEMENT		4605
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package F					4605
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package F	HEAVY	DISASSEMBLY,CLEANING, INSPECTION, ASSEMBLY AND FINAL TEST. EXCLUDED PIECE PART REPAIRS.	EXAMPLE: BEARING THRUST OR HOUSING OR GEAR MATCHED SET REPLACEMENT		6230
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package G					6230
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package G	OVERHAUL	DISASSEMBLY,CLEANING, INSPECTION, ASSEMBLY AND FINAL TEST. EXCLUDED PIECE PART REPAIRS.	-		115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB00					115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB00	711000-73-14	INTRODUCTION OF NEW MAIN STAGE BEARINGS	IN CONJUNCTION WITH HEAVY OR OV		115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB01					115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB01	711000-73-15	INTRODUCTION OF NEW FILTER COVER LOCKING NUTS	IN CONJUNCTION WITH LIGHT		115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB02					115

73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB02	711000-73-16	REPLACEMENT OF STATIONARY SHAFT SEAL PREFORMED PACKING	IN CONJUNCTION WITH LIGHT	
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB03				115
73-11-04	PW4000	133477	23	21	825501-10 825501-11 825501-12 825501-8 825501-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 94"	Package SB03	711000-73-13	INTRODUCTION OF ALTERNATIVE O-RING PACKINGS	IN CONJUNCTION WITH HEAVY OR OV	
73-11-04	PW4000	137442	12	21	217346	FUEL PUMP - 94" - SHAFT DRIVE MAIN	Package A				235
73-11-04	PW4000	137442	12	21	217346	FUEL PUMP - 94" - SHAFT DRIVE MAIN	Package A	-	CRACK INSPECTION, MPI	ACCORDING CMM	
73-11-04	PW4000	138809	22	21	217563-1	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - INLET HOUSING	Package B				1400
73-11-04	PW4000	138809	22	21	217563-1	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - INLET HOUSING	Package B	-	REPLACE SLEEVE BEARING	ACCORDING CMM	
73-11-05	PW4000	130101	4	21	212842	PISTON RELIEF VALVE	Package A				190
73-11-05	PW4000	130101	4	21	212842	PISTON RELIEF VALVE	Package A	CLN/INSP	CLEANING & INSPECTION	-	
73-11-05	PW4000	130101	4	21	212842	PISTON RELIEF VALVE	Package B				265
73-11-05	PW4000	130101	4	21	212842	PISTON RELIEF VALVE	Package B	-	REWORK PISTON SEAT	-	
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB00				115
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB00	723300-73-1	INTRODUCTION OF NEW MAIN STAGE BEARINGS	IN CONJUNCTION WITH PACKAGE HEAVY OR OVERHAUL	
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB01				115
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB01	723300-73-3	REPLACEMENT OF STATIONARY SHAFT SEAL PREFORMED PACKING	IN CONJUNCTION WITH PACKAGE LIGHT, MEDIUM, HEAVY OR OVERHAUL	
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB02				115
73-11-05	PW4000	134183	21	21	723301 723301-10 723301-11 723301-12 723301-8 723301-9	FUEL-PUMP/DISTRIBUTION VALVE - FUEL PUMP - 100"	Package SB02	723300-73-2	INTRODUCTION OF NEW FILTER COVER LOCKING NUTS	IN CONJUNCTION WITH PACKAGE LIGHT, MEDIUM, HEAVY OR OVERHAUL	
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package C				745
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package D				1935
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package E				5055
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package F				6480
73-21-18	PW4000	610901	19	21	420684 55T139	EEC WIRING HARNESS WF04 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package C				745
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package D				1935
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package E				5055
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package F				6480
73-21-18	PW4000	610903	19	21	420012 55T125	EEC WIRING HARNESS WF05 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package C				745
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package D				1935
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package E				5055
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package F				6480
73-21-18	PW4000	610904	19	21	420686 55T137	EEC WIRING HARNESS WF06 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package C				945
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package D				2390
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package E				6495
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package F				8390
73-21-18	PW4000	610905	19	21	420687 55T140	EEC WIRING HARNESS WF07 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package C				465
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package D				1710
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package E				3520
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package F				4390
73-21-18	PW4000	610906	19	21	420015 55T128	EEC WIRING HARNESS WF08 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package C				425
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package D				1115
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package E				2225
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package F				2665
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
73-21-18	PW4000	610907	20	21	420016 421137 51U563 55T129	EEC WIRING HARNESS WF09 - 100"	Package SB00				280

73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package G	-	OVERHAUL	DISASSEMBLY,CLEANING, INSPECTION, ASSEMBLY AND FINAL TEST. EXCLUDED PIECE PART REPAIRS.	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package H				2510
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package H	1-1	REPLACE STUDS	ASSEMBLED	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB00				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB00	JFC131-2-73:	INCORPORATION OF IMPROVED PRESSURE SWITCH	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB02				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB02	JFC131-2-73:	REPLACE PREFORMED PACKINGS BLACK TO BROWN	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB03				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB03	JFC131-2-73:	REPLACEMENT OF ALL INCORRECT MATERIAL PACKINGS	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB04				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB04	JFC131-2-73:	ADD EPOXY TO RESOLVER COVER SCREWS	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB05				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB05	JFC131-2-73:	REPLACEMENT OF THE SEGMENT GEAR	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB06				1725
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB06	JFC131-2-73:	RESOLVER PROCUREMENT OF RESOLVER WITH ADHESIVE PREAPPLIED TO THE COVER SCREW HEADS	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB07				180
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB07	JFC131-2-73:	TORQUE MOTOR NOZZLE INSPECTION	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB08				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB08	JFC131-2-73:	INCORPORATION OF NEW METERING VALVE, SLEEVE AND PISTON	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB09				280
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB09	JFC131-2-73:	REPLACEMENT OF THE SPUR GEAR AND SEGMENT GEAR	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB10				600
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB10	JFC131-2-73:	ADD SPRING TO METERING VALVE(MV) AND MODIFY CONTROL ORIFICE	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB11				600
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB11	JFC131-2-73:	ADDS A WASHERLESS GUIDE SHAFT FOR THE PRESSURE REGULATING VALVE	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB12				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB12	JFC131-2-73:	REPLACEMENT OF THE SEGMENT GEAR	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB13				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB13	JFC131-2-73:	ELIMINATION OF ADJUSTMENT SCREW SHIMS AND PIN	-	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB14				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB14	JFC131-2-73:	ADDITIONAL CABLE STRAPS AND ADDED INSULATION SLEEVING FOR ELECTRICAL WIRING	-	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB15				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB15	JFC131-2-73:	INCORPORATE NEW START-RUN SOLENOID	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB18				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB18	JFC131-2-12/H	NEW START/RUN SOLENOID	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB19				150
73-21-64	PW4000	2869	28	21	801000-1 801000-2 801000-3 801000-4	FUEL METRING UNIT - JFC131-2	Package SB19	SIR JFC131-2:00	FMU - ORIFICE SELECTION INFORMATION	IN CONJUNCTION WITH PACKAGE MEDIUM OR OVERHAUL	
73-21-64	PW4000	137464	21	21	798612-2 798612-4 798612-5	FUEL METRING UNIT - JFC131-2 - RESOLVER AND CONTACTS	Package F				300
73-21-64	PW4000	137464	21	21	798612-2 798612-4 798612-5	FUEL METRING UNIT - JFC131-2 - RESOLVER AND CONTACTS	Package F	5-2	REPAIR OF THE TRANSMITTER RESOLVER AND CONTACTS WHEN THE SPUR GEAR IS WORN IN TWO OPPOSITE QUADRANTS	-	
73-21-64	PW4000	137464	21	21	798612-2 798612-4 798612-5	FUEL METRING UNIT - JFC131-2 - RESOLVER AND CONTACTS	Package SB00				615
73-21-64	PW4000	137464	21	21	798612-2 798612-4 798612-5	FUEL METRING UNIT - JFC131-2 - RESOLVER AND CONTACTS	Package SB00	JFC131-2-73:	ADD EPOXY TO RESOLVER COVER SCREWS	-	
73-21-64	PW4000	138811	20	21	800999-1	FUEL METRING UNIT - JFC131-2 - HOUSING	Package B				695
73-21-64	PW4000	138811	20	21	800999-1	FUEL METRING UNIT - JFC131-2 - HOUSING	Package B	1-1	REMOVAL AND REPLACEMENT OF RING LOCKED STUDS	-	
73-21-64	PW4000	139575	22	21	800967-1	FUEL METRING UNIT - JFC131-2 - GEAR	Package F				290
73-21-64	PW4000	139575	22	21	800967-1	FUEL METRING UNIT - JFC131-2 - GEAR	Package F	5-2	REPAIR OF THE TRANSMITTER RESOLVER AND CONTACTS WHEN THE SPUR GEAR IS WORN IN TWO OPPOSITE QUADRANTS	-	

73-31-24	PW4000	631334	10	21	420650 420660 420661 420662 420663 420664 420665 420666 420754 420755	FIRE DETECTION AND THRUST REVERSER HARNESS	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
73-31-24	PW4000	631334	10	21	420650 420660 420661 420662 420663 420664 420665 420666 420754 420755	FIRE DETECTION AND THRUST REVERSER HARNESS	Package F				1420
73-31-24	PW4000	631334	10	21	420650 420660 420661 420662 420663 420664 420665 420666 420754 420755	FIRE DETECTION AND THRUST REVERSER HARNESS	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package A				580
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package A	-	TEST	-	
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package B				920
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package B	-	REPAIR	-	
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package C				1130
74-21-08	PW4000	132815	10	21	10-609660-9 50U683	CABLE EXCITER TO SPARK IG.	Package C	-	OVERHAUL	-	
75-24-00	PW4000	139613	3	21	51T857 51U728 51U729 53T593 56T430	PWATCC IDLER ARM LINKAGE WITH BEARING	Package B				95
75-24-00	PW4000	139613	3	21	51T857 51U728 51U729 53T593 56T430	PWATCC IDLER ARM LINKAGE WITH BEARING	Package B	-	REPLACE BEARING	-	
75-24-13	PW4000	27164	20	21	1602080-001 1604220-001 1605140-001 1605140-002 1606130-001 1606130-002 50U822 53T574 56T761 59T756	AIR-OIL HEAT EXCH VALVE/TCC VALVE - TURBINE CASE COOLING AIR VALVE-CONTROL CABLE	Package A				330
75-24-13	PW4000	27164	20	21	1602080-001 1604220-001 1605140-001 1605140-002 1606130-001 1606130-002 50U822 53T574 56T761 59T756	AIR-OIL HEAT EXCH VALVE/TCC VALVE - TURBINE CASE COOLING AIR VALVE CONTROL CABLE	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
75-26-13	PW4000	650120	15	21	55T439 55T440 58T383 77989 77989-1	NACELLE CORE COMPARTMENT COOLING SYSTEM - COOLING DUCT SEAL BELLOW 100"	Package A				435
75-26-13	PW4000	650120	15	21	55T439 55T440 58T383 77989 77989-1	NACELLE CORE COMPARTMENT COOLING SYSTEM - COOLING DUCT SEAL BELLOW 100"	Package A	CLN/INSP	CLEANING AND INSPECTION	-	
75-37-00	PW4000	137535	22	21	-	TUBES-DIFFUSER AIR VENT SEAL	Package AN				540
75-37-00	PW4000	137535	22	21	-	TUBES-DIFFUSER AIR VENT SEAL	Package AN	-	REPLACE INSERT	ACCORDING SPM SPOP 415	
75-37-00	PW4000	137535	22	21	-	TUBES-DIFFUSER AIR VENT SEAL	Package AN				1135
75-37-00	PW4000	137535	22	21	-	TUBES-DIFFUSER AIR VENT SEAL	Package AN				1135
75-41-01	PW4000	1288	2	21	57T251 HAD20836	PROBE-THERMOCOUPLE	Package B				945
75-41-01	PW4000	1288	2	21	57T251 HAD20836	PROBE-THERMOCOUPLE	Package B	-	OVERHAUL	-	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package C				440
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package C	-	PRE-TEST	TESTING AND FAULT ISOLATION	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package D				905
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package E				2035
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package F				2765
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package I				330
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package I	-	ASSEMBLY AND DISASSEMBLY	-	
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package I				1010
77-21-04	PW4000	611190	20	21	26257-000 50P090 50P228 50P281 50P487 HAD18919 HAD19490 HAD20458 HAD20459 HAD20460	EGT (T4.95) THERMOCOUPLE BOX AND CABLE	Package SB00	SB1-77-21-04	EGT HARNESS AND JUNCTION BOX - REPLACEMENT NUTS, RETAINING	IN CONJUNCTION WITH PACKAGE MEDIUM OR HEAVY	
77-21-05	PW4000	132791	4	21	50P029 50P109 5255 5255G 5255J HAD18540	THERMOCOUPLE EEC	Package C				380
77-21-05	PW4000	132791	4	21	50P029 50P109 5255 5255G 5255J HAD18540	THERMOCOUPLE EEC	Package C	TEST	PRE TEST	-	
77-21-05	PW4000	132791	4	21	50P029 50P109 5255 5255G 5255J HAD18540	THERMOCOUPLE EEC	Package C	TEST	TEST	-	380
77-21-05	PW4000	132791	4	21	50P029 50P109 5255 5255G 5255J HAD18540	THERMOCOUPLE EEC	Package D				815
77-21-05	PW4000	132791	4	21	50P029 50P109 5255 5255G 5255J HAD18540	THERMOCOUPLE EEC	Package D	-	OVERHAUL	for PN: 5255; 5255J; HAD18540	815
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package C				425
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package C	TEST	PRE TEST	TESTING AND FAULT ISOLATION	425
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package D				1565
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package D	LIGHT	REPAIR AND FINAL TEST	NO CONNECTIONS ARE AFFECTED	1565
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package E				4060
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST	LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	4060
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package F				5245
77-21-06	PW4000	611194	19	21	23830-000 HAD21339 HAD21988	EGT (T3)THERMOCOUPLE BOX AND CABLE - 100"	Package F	HEAVY	REPAIR AND FINAL TEST	MORE THAN 50% OF CONNECTIONS ARE AFFECTED	5245
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package C				665
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package C	-	BENCH TEST	TESTING AND FAULT ISOLATION	665
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package D				765
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package D	-	REPAIR	-	765
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package E				765
77-21-11	PW4000	133447	11	21	50P392 HAD20899 HAD21368	PROBE-THERMOCOUPLE T4.95	Package E	-	OVERHAUL	-	765
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package B				645
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package B	-	BENCH TEST	-	645
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package E				835
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package E	-	MEDIUM	-	835
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package G				1670
77-24-03	PW4000	133519	11	21	22640-005 51U552 53T424 HAC19460	THERMOCOUPLE IMMERSION	Package G	-	OVERHAUL	-	1670
77-32-14	PW4000	611204	19	21	922-224-000-031	VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package C				360

77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package C	TEST	PRE TEST		TESTING AND FAULT ISOLATION	360
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package D					670
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package D	LIGHT	REPAIR AND FINAL TEST		NO CONNECTIONS ARE AFFECTED	670
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package E					1475
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package E	MEDIUM	REPAIR AND FINAL TEST		LESS THAN OR EQUAL TO 50% OF THE CONNECTIONS ARE AFFECTED	1475
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package F					1835
77-32-14	PW4000	611204	19	21	922-224-000-031		VIBRO-METER ENGINE VIBRATION ACCELEROMETER HARNESS - 100"	Package F	HEAVY	REPAIR AND FINAL TEST		MORE THAN 50% OF CONNECTIONS ARE AFFECTED	1835
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package A					2080
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package A	CLN/INSP	CLEANING AND INSPECTION			2080
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package B					2350
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package B	001	WELD REPAIR OF CRACKS IN THE PERFORATED OUTER SKIN			2350
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package C					2350
78-10-03	PW4000	133455	11	21	221-4027-505 221-4027-511 221-4027-513 221-4036-501 221-4037-501		PLUG EXHAUST	Package C	010	WELD CONE			2350
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package A					2080
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package A	CLN/INSP	CLEANING AND INSPECTION			2080
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package B					2670
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package B	001	INCONEL SKIN CRACK			2670
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package C					4315
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package C	002	INCONEL SKIN TO CORE DELAMINATION			4315
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package D					3115
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package D	003	INCONEL PANEL SKIN REPAIR			3115
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package J					3400
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package J	009	NOZZLE OUTER BARREL TITANIUM SKIN			3400
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package L					3635
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package L	011	BARREL ALUMINUM SKIN FLUSH PATCH			3635
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package O					10190
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package O	014	NOZZLE BULKHEAD RING REPLACEMENT			10190
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package P					7455
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package P	015	PATCH SEAL SPRING DAMAGE TO AFT UPPER OUTER BARREL			7455
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package T					3220
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package T	INSP	CHECK AND REPLACE STOP-NUTS	ACC. 78-10-04-CHECK		3220
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package U					400
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package U	INSP	REAPPLY DRY FILM LUBRICANT	ACC. 78-10-04-CHECK		400
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package V					255
78-10-04	PW4000	133512	21	35	221-0051-511 221-0051-517 221-0051-519 221-0051-521 221-0051-523 221-0051-529 221-0051-533 221-0051-535 221-0051-537 221-0066-101		EXHAUST NOZZLE ASSEMBLY - 94"	Package V	-	REPLACE DEFECTIVE PARTS REFER TO IPL			255
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package A					900
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package A	CLN/INSP	CLEANING AND INSPECTION			900
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package B					2900
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package B	1-1	RUB STRIP AND SEAL MEMBER REPLACEMENT			2900
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package J					1010
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package J	2-1 / 9	REPAIR OF HOLES OR PUNCTURES UP TO ONE INCH MAXIMUM LENGTH OF SOLID SKIN			1010
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package K					1420
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package K	2-1 / 10	REPAIR OF CRACKS UP TO SIX INCH LENGTH IN SOLID SKIN, NOT ADJACENT TO PANEL WELDS			1420
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package O					1270
78-11-06	PW4000	133457	18	35	314T3310-1 314T3310-10 314T3310-3 314T3310-5 314T3310-6 314T3310-7 314T3310-9		PRIMARY EXHAUST SLEEVE ASSEMBLY	Package O	2-1 / 14	REPAIR OF LONGITUDINAL CRACKS IN THE OUTER SLEEVE			1270
78-11-11	PW4000	629647	4	21	71A304-001 76A013-1 76A013-3		PW4 (100") SADDLE OF NOZZLE ASSY	Package B					3145
78-11-11	PW4000	629647	4	21	71A304-001 76A013-1 76A013-3		PW4 (100") SADDLE OF NOZZLE ASSY	Package B	R.ESEE.000 899	CHANNEL WEAR WELD REPAIR			3145
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package A					395
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package A	CLN/INSP	CLEANING AND INSPECTION			395
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package L					815
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package L	011	REMOVE AND REPL. PLUG END CAP			815
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package N					1140
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package N	013	REMOVE BLIND RIVETS AND INSTALL SOLID RIVETS			1140
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package O					1140
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package O	014	REMOVE AND REPL. BOLT CATCHER			1140
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package SB00					1140
78-11-12	PW4000	134180	23	21	75A001-11 75A001-21		PLUG ASSY OF EXHAUST - 100"	Package SB00	PW4G-100-78-96	REPLACE END CAP ATTACHMENT RIVETS TO IMPROVE DURABILITY	PART 001		1140
78-11-12	PW4000	665124	9	21	75A007-5		EXHAUST PLUG END CAP	Package A					365
78-11-12	PW4000	665124	9	21	75A007-5		EXHAUST PLUG						

